


Serial Number

**QT**  
**3.9L**  
**70kW**  
**Models**

# STANDBY GENERATOR OWNER'S MANUAL



*A new standard of reliability*

**GENERAC<sup>®</sup>**  
POWER SYSTEMS, INC.

This manual should remain with the unit.

| <b>SECTION</b>                            | <b>PAGE</b> |                                               |             |
|-------------------------------------------|-------------|-----------------------------------------------|-------------|
| <b>SAFETY RULES</b>                       | <b>1-1</b>  | <b>OPERATION</b>                              | <b>9-1</b>  |
| <b>INTRODUCTION</b>                       | <b>1-3</b>  | Generator Control and Operation               | 9-1         |
| Read this Manual Thoroughly               | 1-3         | Operating Unit with Manual Transfer Switch    | 9-1         |
| Operation and Maintenance                 | 1-3         | Engine Start-up and Transfer                  | 9-1         |
| How to Obtain Service                     | 1-3         | Retransfer and Shutdown                       | 9-1         |
| <b>IDENTIFICATION RECORD</b>              | <b>2-1</b>  | Operating Unit with Automatic Transfer Switch | 9-1         |
| Data Label                                | 2-1         | <b>MAINTENANCE</b>                            | <b>10-1</b> |
| <b>EQUIPMENT DESCRIPTION</b>              | <b>3-1</b>  | Maintenance Performed by Authorized           |             |
| Equipment Description                     | 3-1         | Service Facilities                            | 10-1        |
| Engine Oil Requirements                   | 3-1         | Cooling System                                | 10-1        |
| Coolant Recommendations                   | 3-1         | Checking Fluid Levels                         | 10-1        |
| <b>ENGINE PROTECTIVE DEVICES</b>          | <b>4-1</b>  | Check Engine Oil                              | 10-1        |
| High Coolant Temperature Switch           | 4-1         | Battery Fluid                                 | 10-1        |
| Low Coolant Level Sensor                  | 4-1         | Engine Coolant                                | 10-1        |
| Low Oil Pressure Switch                   | 4-1         | Maintenance Owner/Operator Can Perform        | 10-2        |
| Overcrank Shutdown                        | 4-1         | Check Engine Oil Level                        | 10-2        |
| Overspeed Shutdown                        | 4-1         | Check Battery                                 | 10-2        |
| RPM Sensor Loss Shutdown                  | 4-1         | Exercise System                               | 10-2        |
| DC Fuse                                   | 4-1         | Inspect Cooling System                        | 10-2        |
| <b>FUEL SYSTEMS</b>                       | <b>5-1</b>  | Check Engine Coolant Level                    | 10-2        |
| Fuel Requirements                         | 5-1         | Perform Visual Inspection                     | 10-2        |
| Natural Gas Fuel System                   | 5-1         | Inspect Exhaust System                        | 10-2        |
| Propane Vapor Withdrawal Fuel System      | 5-1         | Check Fan Belt                                | 10-2        |
| LP Fuel System                            | 5-1         | Inspect Engine Governor                       | 10-2        |
| <b>SPECIFICATIONS</b>                     | <b>6-1</b>  | Changing Engine Oil                           | 10-2        |
| Generator                                 | 6-1         | Changing the Engine Air Cleaner               | 10-3        |
| Engine                                    | 6-1         | Spark Plugs                                   | 10-3        |
| Cooling System                            | 6-1         | Coolant Change                                | 10-3        |
| Fuel System                               | 6-1         | Miscellaneous Maintenance                     | 10-3        |
| Electrical System                         | 6-1         | Cleaning the Generator                        | 10-3        |
| Cold Weather Kit                          | 6-2         | Battery                                       | 10-3        |
| <b>GENERAL INFORMATION</b>                | <b>7-1</b>  | Battery Maintenance                           | 10-4        |
| Generator AC Lead Connections             | 7-1         | Battery Replacement                           | 10-4        |
| Four-lead, Single-phase Stator            | 7-1         | <b>SERVICE SCHEDULE</b>                       | <b>11-1</b> |
| Alternator Power Winding Connections      | 7-1         | 20 kW - 40 kW Standby Gas Engine              |             |
| 3-phase Alternators                       | 7-1         | Driven Generator Sets                         | 11-1        |
| <b>INSTALLATION</b>                       | <b>8-1</b>  | <b>TROUBLESHOOTING</b>                        | <b>12-1</b> |
| Installation                              | 8-1         | Troubleshooting Guide                         | 12-1        |
| Preparation Before Start-up               | 8-1         | <b>NOTES</b>                                  |             |
| Prior to Initial Start-up                 | 8-1         | <b>EXPLODED VIEWS &amp; PARTS LISTS</b>       |             |
| Initial Inspection for QT Genset Start-up | 8-1         | <b>WIRING DIAGRAMS &amp; SCHEMATICS</b>       |             |
| Start-up Inspection                       | 8-2         | <b>WARRANTY</b>                               |             |



## Standby Generator Sets Important Safety Instructions



**⚠ SAVE THESE INSTRUCTIONS** – The manufacturer suggests that these rules for safe operation be copied and posted in potential hazard areas. Safety should be stressed to all operators, potential operators, and service and repair technicians for this equipment. **⚠**



### WARNING:



**The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.**



### WARNING:



**This product contains or emits chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.**

Study these SAFETY RULES carefully before installing, operating or servicing this equipment. Become familiar with this Owner's Manual and with the unit. The generator can operate safely, efficiently and reliably only if it is properly installed, operated and maintained. Many accidents are caused by failing to follow simple and fundamental rules or precautions.

The manufacturer cannot anticipate every possible circumstance that might involve a hazard. The warnings in this manual, and on tags and decals affixed to the unit are, therefore, not all inclusive. If a procedure, work method or operating technique is used that the manufacturer does not specifically recommend, ensure that it is safe for others. Also make sure the procedure, work method or operating technique utilized does not render the generator unsafe.

### ⚠ DANGER ⚠

**⚠ Despite the safe design of this generator, operating this equipment imprudently, neglecting its maintenance or being careless can cause possible injury or death. Permit only responsible and capable persons to install, operate or maintain this equipment.**

**⚠ Potentially lethal voltages are generated by these machines. Ensure all steps are taken to render the machine safe before attempting to work on the generator.**

**⚠ Parts of the generator are rotating and/or hot during operation. Exercise care near running generators.**

### ⚠ GENERAL HAZARDS ⚠

- For safety reasons, the manufacturer recommends that this equipment be installed, serviced and repaired by an Authorized Service Dealer or other competent, qualified electrician or installation technician who is familiar with applicable codes, standards and regulations. The operator also must comply with all such codes, standards and regulations.
- Installation, operation, servicing and repair of this (and related) equipment must always comply with applicable codes, standards, laws and regulations. Adhere strictly to local, state and national electrical and building codes. Comply with regulations the Occupational Safety and Health Administration (OSHA) has established. Also, ensure that the generator is installed, operated and serviced in accordance with the manufacturer's instructions and recommendations. Following installation, do nothing that might render the unit unsafe or in noncompliance with the aforementioned codes, standards, laws and regulations.
- The engine exhaust fumes contain carbon monoxide gas, which can be DEADLY. This dangerous gas, if breathed in sufficient concentrations, can cause unconsciousness or even death. For that reason, adequate ventilation must be provided. This should be considered prior to installing the generator. The unit should be positioned to direct exhaust gasses safely away from any building where people, animals, etc., will not be harmed. Any exhaust stacks that ship loose with the unit must be installed properly per the manufacturer's instruction, and in strict compliance with applicable codes and standards.
- Keep hands, feet, clothing, etc., away from drive belts, fans, and other moving or hot parts. Never remove any drive belt or fan guard while the unit is operating.
- Adequate, unobstructed flow of cooling and ventilating air is critical in any room or building housing the generator to prevent buildup of explosive gases and to ensure correct generator operation. Do not alter the installation or permit even partial blockage of ventilation provisions, as this can seriously affect safe operation of the generator.
- Keep the area around the generator clean and uncluttered. Remove any materials that could become hazardous.
- When working on this equipment, remain alert at all times. Never work on the equipment when physically or mentally fatigued.
- Inspect the generator regularly, and promptly repair or replace all worn, damaged or defective parts using only factory-approved parts.



## Standby Generator Sets Important Safety Instructions



- Before performing any maintenance on the generator, disconnect its battery cables to prevent accidental start-up. Disconnect the cable from the battery post indicated by a **NEGATIVE**, **NEG** or **(-)** first. Reconnect that cable last.
- Never use the generator or any of its parts as a step. Stepping on the unit can stress and break parts, and may result in dangerous operating conditions from leaking exhaust gases, fuel leakage, oil leakage, etc.

### **ELECTRICAL HAZARDS**

- All generators covered by this manual produce dangerous electrical voltages and can cause fatal electrical shock. Utility power delivers extremely high and dangerous voltages to the transfer switch as well as the standby generator. Avoid contact with bare wires, terminals, connections, etc., on the generator as well as the transfer switch, if applicable. Ensure all appropriate covers, guards and barriers are in place before operating the generator. If work must be done around an operating unit, stand on an insulated, dry surface to reduce shock hazard.
- Do not handle any kind of electrical device while standing in water, while barefoot, or while hands or feet are wet. **DANGEROUS ELECTRICAL SHOCK MAY RESULT.**
- If personnel must stand on metal or concrete while installing, operating, servicing, adjusting or repairing this equipment, place insulative mats over a dry wooden platform. Work on the equipment only while standing on such insulative mats.
- The National Electrical Code (NEC) requires the frame and external electrically conductive parts of the generator to be connected to an approved earth ground. This grounding will help prevent dangerous electrical shock that might be caused by a ground fault condition in the generator set or by static electricity. Never disconnect the ground wire.
- Wire gauge sizes of electrical wiring, cables and cord sets must be adequate to handle the maximum electrical current (ampacity) to which they will be subjected.
- Before installing or servicing this (and related) equipment, make sure that all power voltage supplies are positively turned off at their source. Failure to do so will result in hazardous and possibly fatal electrical shock.
- Connecting this unit to an electrical system normally supplied by an electric utility shall be by means of a transfer switch so as to isolate the generator electric system from the electric utility distribution system when the generator is operating. Failure to isolate the two electric system power sources from each other by such means will result in damage to the generator and may also result in injury or death to utility power workers due to backfeed of electrical energy.
- Generators installed with an automatic transfer switch will crank and start automatically when normal (utility) source voltage is removed or is below an acceptable preset level. To prevent such automatic start-up and possible injury to personnel, disable the generator's automatic start circuit (battery cables, etc.) before working on or around the unit. Then, place a "Do Not Operate" tag on the generator control panel and on the transfer switch.
- In case of accident caused by electric shock, immediately shut down the source of electrical power. If this is not possible, attempt to free the victim from the live conductor. **AVOID DIRECT CONTACT WITH THE VICTIM.** Use a nonconducting implement, such as a dry rope or board, to free the victim from the live conductor. If the victim is unconscious, apply first aid and get immediate medical help.
- Never wear jewelry when working on this equipment. Jewelry can conduct electricity resulting in electric shock, or may get caught in moving components causing injury.

### **FIRE HAZARDS**

- Keep a fire extinguisher near the generator at all times. Do **NOT** use any carbon tetra-chloride type extinguisher. Its fumes are toxic, and the liquid can deteriorate wiring insulation. Keep the extinguisher properly charged and be familiar with its use. If there are any questions pertaining to fire extinguishers, consult the local fire department.

### **EXPLOSION HAZARDS**

- Properly ventilate any room or building housing the generator to prevent build-up of explosive gas.
- Do not smoke around the generator. Wipe up any fuel or oil spills immediately. Ensure that no combustible materials are left in the generator compartment, or on or near the generator, as **FIRE** or **EXPLOSION** may result. Keep the area surrounding the generator clean and free from debris.
- These generator sets may operate using one of several types of fuels. All fuel types are potentially **FLAMMABLE** and/or **EXPLOSIVE** and should be handled with care. Comply with all laws regulating the storage and handling of fuels. Inspect the unit's fuel system frequently and correct any leaks immediately. Fuel supply lines must be properly installed, purged and leak tested according to applicable fuel-gas codes before placing this equipment into service.
- Diesel fuels are highly **FLAMMABLE**. Gaseous fluids such as natural gas and liquid propane (LP) gas are extremely **EXPLOSIVE**. Natural gas is lighter than air, and LP gas is heavier than air; install leak detectors accordingly.



## Standby Generator Sets Important Safety Instructions



### INTRODUCTION

Thank you for purchasing this model of the standby generator set product line.

Every effort was expended to make sure that the information and instructions in this manual were both accurate and current at the time the manual was written. However, the manufacturer reserves the right to change, alter or otherwise improve this product(s) at any time without prior notice.

#### ◆ READ THIS MANUAL THOROUGHLY

If any portion of this manual is not understood, contact the nearest Authorized Service Dealer for starting, operating and servicing procedures.

Throughout this publication, and on tags and decals affixed to the generator, DANGER, WARNING, CAUTION and NOTE blocks are used to alert personnel to special instructions about a particular service or operation that may be hazardous if performed incorrectly or carelessly. Observe them carefully. Their definitions are as follows:



**After this heading, read instructions that, if not strictly complied with, will result in serious personal injury, including death, or property damage.**



**After this heading, read instructions that, if not strictly complied with, may result in personal injury or property damage.**



**After this heading, read instructions that, if not strictly complied with, could result in damage to equipment and/or property.**

#### NOTE:

**After this heading, read explanatory statements that require special emphasis.**

These safety warnings cannot eliminate the hazards that they indicate. Common sense and strict compliance with the special instructions while performing the service are essential to preventing accidents.

Four commonly used safety symbols accompany the DANGER, WARNING and CAUTION blocks. The type of information each indicates is as follows:

 This symbol points out important safety information that, if not followed, could endanger personal safety and/or property of others.

 This symbol points out potential explosion hazard.

 This symbol points out potential fire hazard.

 This symbol points out potential electrical shock hazard.

The operator is responsible for proper and safe use of the equipment. The manufacturer strongly recommends that the operator read this Owner's Manual and thoroughly understand all instructions before using this equipment. The manufacturer also strongly recommends instructing other users to properly start and operate the unit. This prepares them if they need to operate the equipment in an emergency.

#### ◆ OPERATION AND MAINTENANCE

It is the operator's responsibility to perform all safety checks, to make sure that all maintenance for safe operation is performed promptly, and to have the equipment checked periodically by an Authorized Service Dealer. Normal maintenance service and replacement of parts are the responsibility of the owner/operator and, as such, are not considered defects in materials or workmanship within the terms of the warranty. Individual operating habits and usage contribute to the need for maintenance service.

Proper maintenance and care of the generator ensure a minimum number of problems and keep operating expenses at a minimum. See an Authorized Service Dealer for service aids and accessories.

Operating instructions presented in this manual assume that the standby electric system has been installed by an Authorized Service Dealer or other competent, qualified contractor. Installation of this equipment is not a "do-it-yourself" project.

#### ◆ HOW TO OBTAIN SERVICE

When the generator requires servicing or repairs, simply contact an Authorized Service Dealer for assistance. Service technicians are factory-trained and are capable of handling all service needs.

When contacting an Authorized Service Dealer or the factory about parts and service, always supply the complete model number of the unit as given on the front cover of this manual or on the DATA LABEL affixed to the unit.


#### AUTHORIZED SERVICE DEALER LOCATION

To locate the nearest AUTHORIZED SERVICE DEALER, please call this number:


**1-800-333-1322**

or locate us on the web at:

**www.generac.com**



## Standby Generator Sets General Information



### IDENTIFICATION RECORD

#### ◆ DATA LABEL

Every generator set has a DATA LABEL that contains important information pertinent to the generator. The data label, which can be found attached to the generator's lower connection box, lists the unit's serial number and its rated voltage, amps, wattage capacity, phase, frequency, rpm, power factor, etc.

| GENERATOR SET DATA                                                                                      |                 | MADE IN USA |
|---------------------------------------------------------------------------------------------------------|-----------------|-------------|
| MODEL                                                                                                   | SERIAL          |             |
| RATED KW                                                                                                | RATED KVA       | PHASE       |
| RATED VOLTAGE                                                                                           | RATED AMPS      |             |
| POWER FACTOR                                                                                            | HERTZ           | ALT RPM     |
| ENGINE RPM                                                                                              | PRODUCTION DATE |             |
| ALTERNATOR SUBTRANSIENT REACTANCE                                                                       |                 |             |
| ALTERNATOR TRANSIENT REACTANCE                                                                          |                 |             |
| CLASS <input type="checkbox"/> ROTOR <input type="checkbox"/> STATOR WINDING INSULATION AT 25°C AMBIENT |                 |             |
| GENERAC POWER SYSTEMS, INC.<br>WAUKESHA, WI                                                             |                 |             |

#### NOTE:

For actual information related to this particular model, please refer to the Manual Drawing Listing located at the end of this manual, or to the data label affixed to the unit.

#### ✦ Generator Model and Serial Number

This number is the key to numerous engineering and manufacturing details pertaining to your unit. Always supply this number when requesting service, ordering parts or seeking information.

#### ✦ Identification Code

Use this code to obtain important information about the generator. For example, if the code is:

|   |   |   |   |   |   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| M | Q | T | 1 | 0 | 0 | 5 | 4 | A | N | S | N | A |
|---|---|---|---|---|---|---|---|---|---|---|---|---|

**M** — Designates generators capable of paralleling.  
NOTE: Only 100kW and 150kW, 6.8L units are currently available for this configuration.

**QT** — Quiet Test Generator Series

**100** — kw Rating

**5.4** — Engine Size in Liters

**A** — Voltage Code: A = 120/240, Single-phase;  
G = 120/208, Three-phase; K = 277/480, Three-phase; J = 120/240, Three-phase;  
L = 346/600, Three-phase

**N** — Fuel: N = Natural Gas; V = Vapor Propane

**S** — Enclosure Material: A = Aluminum; S = Steel (Corrosion Resistant Aluminum Enclosure Material, Steel is Standard)

**N** — Emission Equipment: N = No Equipment;  
Y = Catalytic Converter and Air/Fuel Ratio Controller


**A** — Industrial Dealer Product

#### ✦ Voltage Codes

The identification code letter following the unit's engine size is the generator's "voltage code."

#### ✦ Groups and Assembly Numbers

The manual drawing listing lists the groups and corresponding assembly numbers for each unit. The assembly numbers refer to exploded view drawing numbers that are applicable to the specific generator model. These drawings are located in the back half of this manual.



### EQUIPMENT DESCRIPTION

This equipment is a revolving field, alternating current generator set. It is powered by a gaseous fueled engine operating at 1800 rpm for 4-pole direct drive units, 3600 rpm for 2-pole direct drive units and 2300 - 3000 rpm for quiet drive gear units. See the Specifications section for exact numbers. The unit comes complete with a sound attenuated enclosure, internally mounted muffler, control console, main-line circuit breaker, battery charger, and protective alarms as explained in the following paragraph.

All AC connections, including the power leads from the alternator, 120 volt battery charger input and control connections to the transfer switch are available in the main connection box.

The generator incorporates the following generator features:

- Rotor and Stator insulation is Class H rated as defined by NEMA MG1-32.6, NEMA MG1-1.66. The generator is self ventilated and drip-proof constructed.
- The voltage waveform deviation, total harmonic content of the AC waveform and telephone influence factor have been evaluated and are acceptable according to NEMA MG1-32.

### ENGINE OIL RECOMMENDATIONS

The unit has been filled with 5W-20 engine oil at the factory. Use a high-quality detergent oil classified "For Service SJ or SH." Detergent oils keep the engine cleaner and reduce carbon deposits. When changing the engine oil, be sure to use 5W-30 engine oil (synthetic oil is recommended).



- ⚠ Any attempt to crank or start the engine before it has been properly serviced with the recommended oil may result in an engine failure.

#### NOTE:

For temperatures below 32° F, it is strongly recommended to use the optional Cold Weather Start Kit (part number listed in the Specification Section). The oil grade for temperatures below 32° F is 5W-30 synthetic oil.

### COOLANT RECOMMENDATIONS


Use a mixture of half low silicate ethylene glycol base anti-freeze and deionized water. Cooling system capacity is listed in the specifications. Use only deionized water and only low silicate anti-freeze. If desired, add a high quality rust inhibitor to the recommended coolant mixture. When adding coolant, always add the recommended 50-50 mixture.



- ⚠ Do not use any chromate base rust inhibitor with ethylene glycol base anti-freeze or chromium hydroxide ("green slime") forms and will cause overheating. Engines that have been operated with a chromate base rust inhibitor must be chemically cleaned before adding ethylene glycol base anti-freeze. Using any high silicate anti-freeze boosters or additives will also cause overheating. The manufacturer also recommends that any soluble oil inhibitor is NOT used for this equipment.



- ⚠ Do not remove the radiator pressure cap while the engine is hot or serious burns from boiling liquid or steam could result.
- ⚠ Ethylene glycol base antifreeze is poisonous. Do not use mouth to siphon coolant from the radiator, recovery bottle or any container. Wash hands thoroughly after handling. Never store used antifreeze in an open container because animals are attracted to the smell and taste of antifreeze even though it is poisonous to them.



### ENGINE PROTECTIVE DEVICES

The standby generator may be required to operate for long periods of time without an operator on hand to monitor such engine conditions as coolant temperature, oil pressure or rpm. For that reason, the engine has several devices designed to protect it against potentially damaging conditions by automatically shutting down the unit when the oil pressure is too low, the coolant temperature is too high, the coolant level is too low, or the engine is running too fast.

#### NOTE:

**Engine protective switches and sensors are mentioned here for the reader's convenience. Also refer to the applicable control panel manual for additional automatic engine shutdown information.**

#### ◆ HIGH COOLANT TEMPERATURE SWITCH

The switch will close if the temperature should exceed approximately 140° C (284° F), initiating an engine shutdown. The generator will automatically restart and the LED will reset once the temperature has returned to a safe operating level.

#### ◆ LOW COOLANT LEVEL SENSOR

To prevent overheating, the engine has a low coolant level sensor. If the level of engine coolant drops below the level of the low coolant level sensor, the engine automatically shuts down.

#### ◆ LOW OIL PRESSURE SWITCH

This switch has normally closed contacts that are held open by engine oil pressure during cranking and operating. Should oil pressure drop below the 8 psi range, switch contacts close, and the engine shuts down. The unit should not be restarted until oil is added, and the AUTO/OFF/MANUAL switch must be turned to OFF and then back to AUTO.

#### ◆ OVERCRANK SHUTDOWN

After a prespecified duration of cranking, this function ends the cranking if the engine has failed to start. The overcrank LED will turn ON. Turn OFF the AUTO/OFF/MANUAL switch, then turn switch back to AUTO to reset the generator control board.

#### NOTE:

**If the fault is not corrected, the overcrank feature will continue to activate.**

#### Approximate Crank Cycle Times

- 15 seconds ON
  - 7 seconds OFF
  - 7 seconds ON
  - 7 seconds OFF
  - Repeat for 45 seconds
- Approximately 90 seconds total.

#### ◆ OVERSPEED SHUTDOWN

A speed circuit controls engine cranking, start-up, operation and shutdown. Engine speed signals are delivered to the circuit board whenever the unit is running. Should the engine overspeed above a safe, preset value, the circuit board initiates an automatic engine shutdown. Contact the nearest Authorized Dealer if this failure occurs.



#### ◆ RPM SENSOR LOSS SHUTDOWN

If the speed signal to the control panel is lost, engine shutdown will occur.

#### ◆ DC FUSES

Fuse F1 (15 amp) is located inside of the control panel. It protects the panel wiring and components from damaging overload. **Always remove this fuse before commencing work on the generator.** The unit will not start or crank if the fuse is blown.

Fuse F2 (25 amp) is located in the engine wire harness adjacent to the DC alternator. It is used to prevent circuit failure due to DC alternator failure. If this fuse is blown, battery charging will not occur while the engine is running. Replace these fuses with the same size, type, and rating. (See the exploded views and parts lists at the end of this manual for replacement part number.)



## FUEL SYSTEM

### ◆ FUEL REQUIREMENTS

The standby generator may be equipped with one of the following fuel systems:

- Natural gas fuel system
- Propane vapor (PV) fuel system
- Liquid propane (LP) fuel system

The Manual Drawing Listing that is affixed to the unit includes the "Identification Code," which may be used to identify the type of fuel system installed on the unit.

Recommended fuels should have a Btu content of at least 1,000 Btu's per cubic foot for natural gas; or at least 2,520 Btu's per cubic foot for LP gas. Ask the fuel supplier for the Btu content of the fuel.

Required fuel pressure for **natural gas is 11 inches to 14 inches water column (0.4 to 0.5 psi); and for liquid propane, 11 inches to 14 inches of water column (0.4 to 0.5 psi).**

#### NOTE:

**Any piping used to connect the generator to the fuel supply should be of adequate size to ensure the fuel pressure NEVER drops below 11 inches water column for natural gas or 11 inches water column for liquid propane for all load ranges.**

#### NOTE:

**It is the responsibility of the installer to make sure that only the correct recommended fuel is supplied to the generator fuel system. Thereafter, the owner/operator must make certain that only the proper fuel is supplied.**

### ◆ NATURAL GAS FUEL SYSTEM

Natural gas is supplied in its vapor state. In most cases, the gas distribution company provides piping from the main gas distribution line to the standby generator site. The following information applies to natural gas fuel systems.

- Gas pressure in a building is usually regulated by national, state and local codes.
- To reduce gas pressure to a safe level before the gas enters a building, a primary regulator is needed. The natural gas supplier may or may not supply such a regulator.
- It is the responsibility of the gas supplier to make sure sufficient gas pressure is available to operate the primary regulator.
- Gas pressure at the inlet to the fuel shutoff solenoid should not exceed approximately 14 inches water column (0.5 psi). Optimum pressure at the fuel shutoff solenoid is 11 inches water column (0.4 psi).

### ◆ PROPANE VAPOR WITHDRAWAL FUEL SYSTEM


This type of system utilizes the vapors formed above the liquid fuel in the supply tank. Approximately 10 to 20 percent of the tank capacity is needed for fuel expansion from the liquid to the vapor state. The vapor withdrawal system is generally best suited for smaller engines that require less fuel. The installer should be aware of the following:

- The natural gas and LP gas systems are similar. However, the natural gas system delivers gas at a pressure of approximately five inches water column to the carburetor.
- When ambient temperatures are low and engine fuel consumption is high, the vapor withdrawal system may not function efficiently.
- Ambient temperatures around the supply tank must be high enough to sustain adequate vaporization, or the system will not deliver the needed fuel volume.
- In addition to the cooling effects of ambient air, the vaporization process itself provides an additional cooling effect.


### ◆ LP FUEL SYSTEM

LP is supplied as a liquid in pressure tanks. It is usually made up of propane, butane, or a mixture of the two gases. Propane tends to vaporize readily even at temperatures as low as -20° F (-29° C). However, butane reverts to its liquid state when temperatures drop below 32° F (0° C).

LP in a liquid withdrawal system must be converted to its gaseous state before it is introduced into the engine carburetor. A vaporizer-converter is generally used to accomplish this. In such a converter, heated engine coolant is ported through the converter to provide the necessary heat for conversion of the fuel from a liquid to a gaseous state.



# Standby Generator Sets Specifications



## SPECIFICATIONS

### ◆ GENERATOR

Type ..... Synchronous  
Rotor Insulation ..... Class H  
Stator Insulation ..... Class H  
Total Harmonic Distortion ..... < 3.5%  
Telephone Interference Factor (TIF) ..... < 50  
Alternator Output Leads 3-phase ..... 4-wire  
Bearings ..... Sealed Ball  
Coupling ..... Flexible Disc  
Load Capacity (Standby Rating) ..... 70kW\*

\* NOTE: Generator rating and performance in accordance with ISO8528-5, BS5514, SAE J1349, ISO3046 and DIN 6271 Standards. KW rating is based on LPG fuel and may derate with natural gas.

|                                     |                                     |
|-------------------------------------|-------------------------------------|
| Excitation System .....             | Direct                              |
| Generator Output Voltage/kW - 60 Hz | <u>kW</u> <u>Amp</u> <u>CB Size</u> |
| 120/240V, 1-phase, 1.0 pf           | 70    292    350                    |
| 120/208V, 3-phase, 0.8 pf           | 70    243    250                    |
| 277/480V, 3-phase, 0.8 pf           | 70    105    125                    |

Generator Locked Rotor KVA Available @ Voltage Dip of 35%  
Single-phase or 208 3-phase ..... 145 KVA  
480V, 3-phase ..... 160 KVA

### ◆ ENGINE

Make ..... Generac  
Model ..... V-type  
Cylinders and Arrangement ..... 6  
Displacement ..... 3.9 Liter  
Bore ..... 3.91 in.  
Stroke ..... 3.31 in.  
Compression Ratio ..... 9.1-to-1  
Air Intake System ..... Naturally Aspirated  
Valve Seats ..... Hardened  
Lifter Type ..... Hydraulic

### Engine Parameters

Rated Synchronous RPM ..... 60 Hz, 3600  
HP at rated kW ..... 60 Hz, 123.6

### Exhaust System

Exhaust Flow at Rated Output 60 Hz ..... 752 cfm  
Exhaust Temperature at Rated Output ..... 1174° F

### Combustion Air Requirements (Natural Gas)

Flow at rated power, 60 Hz ..... 235 cfm

### Governor

Type ..... Electronic  
Frequency Regulation ..... Isochronous  
Steady State Regulation .....  $\pm 1/2\%$   
Adjustments:  
Speed ..... Selectable

### Engine Lubrication System

Type of Oil Pump ..... Gear  
Oil Filter ..... Full Flow, Cartridge  
Crankcase Oil Capacity ..... 4 U.S. qts.

### ◆ COOLING SYSTEM

Type ..... Closed  
Water Pump ..... Belt Driven  
Fan Speed ..... 2170  
Fan Diameter ..... 22 inches  
Fan Mode ..... Puller  
Air Flow (inlet air including alternator and combustion air) ..... 4800 ft<sup>3</sup>/min.  
Coolant Capacity ..... 3.0 U.S. gal.  
Heat Rejection to Coolant ..... 309,000 Btu/h  
Maximum Operating Air Temp. on Radiator ..... 60° C (150° F)  
Maximum Ambient Temperature ..... 50° C (140° F)

### ◆ FUEL SYSTEM

Type of Fuel ..... Natural Gas, Propane Vapor\*  
Carburetor ..... Down Draft  
Secondary Fuel Regulator ..... Standard  
Fuel Shut-off Solenoid ..... Standard  
Operating Fuel Pressure ..... 11 in. - 14 in. Water Column

### Fuel Consumption - ft<sup>3</sup>/hr (Natural Gas/LPV)

|                 |             |             |             |             |
|-----------------|-------------|-------------|-------------|-------------|
| <i>Exercise</i> | <i>25%</i>  | <i>50%</i>  | <i>75%</i>  | <i>100%</i> |
| <u>Cycle</u>    | <u>Load</u> | <u>Load</u> | <u>Load</u> | <u>Load</u> |
| 130/52          | 280/111     | 530/210     | 750/298     | 1104/438    |

\* Engine is not field convertible between natural gas and propane. Jet size and ignition timing are factory set for the specific fuel.

### ◆ ELECTRICAL SYSTEM

Battery Charge Alternator ..... 12V, 30 Amp  
Static Battery Charger ..... 2 Amp  
Recommended Battery ..... 24F 525CCA  
System Voltage ..... 12 Volts

### Voltage Regulator


Type ..... Electronic  
Sensing ..... Single-phase  
Regulation .....  $\pm 1\%$   
Features ..... V/F Adjustable, Adjustable  
Voltage and Gain LED indicators

### Power Adjustment for Ambient Conditions

Temperature Deration  
3% for every 10° C above °C ..... 25  
1.65% for every 10° above °F ..... 77  
Altitude Deration  
1% for every 100 m above m ..... 183  
3% for every 1000 ft. above ft. .... 600

Controller ..... R-panel

**Figure 1 — Interconnections**



## ◆ COLD WEATHER KIT

For cold climates, optional cold weather kit (part number 0F6148) is recommended. The kit includes:

- Battery Warmer
- 4" Junction Box with hardware
- 6 qt. pack 5W-30 synthetic oil (engine)

## GENERATOR AC LEAD CONNECTIONS

See "Voltage Codes". This generator may be rated at any one of three voltages, either single-phase or three-phase. The electrical wires in the unit's AC connection (lower) panel should be installed according to the number of leads and the voltage/phase required for the application. If there are any questions regarding lead connection, refer to the wiring diagrams at the back of this manual.


Voltage codes apply to the type of stator assembly installed on a particular generator.

### ◆ FOUR-LEAD, SINGLE-PHASE STATOR

Four-lead generators (see Figure 7.1) are designed to supply electrical loads with voltage code "A" (240V, 1-phase, 60 Hz). Electrical power is produced in the stator power windings. These windings were connected at the factory to the main circuit breaker as shown in Figure 7.1.

The rated voltage between each circuit breaker terminal is 240V. The rated voltage between each circuit breaker terminal and the neutral point 00 is 120V.

**Figure 7.1 — Four-lead, Single-phase Stator**



## ALTERNATOR POWER WINDING CONNECTIONS


### ◆ 3-PHASE ALTERNATORS

The generator is designed to supply 3-phase electrical loads. Electric power is produced in the alternator power windings. These windings were connected at the factory to the main circuit breaker with a "Y" configuration as shown in Figures 7.2 and 7.3.


The rated voltage between circuit breaker terminals E1-E2, E1-E3 and E2-E3 is either 480V or 208V depending on the model.


The rated voltage between each circuit breaker terminal and the neutral point 00 is either 277V or 120V depending on the model.

**Figure 7.2 — Stator Power Winding Connections - 3-phase, 277/480V (6 Lead)**



**Figure 7.3 — Stator Power Winding Connections - 3-phase, 120/208V (6 Lead)**





## INSTALLATION

Refer to the separate "Installation Guide QT Product Line" supplied with the unit.

### PREPARATION BEFORE START-UP

The instructions in this section assume that the standby generator has been properly installed, serviced, tested, adjusted and otherwise prepared for use by a competent, qualified installation contractor. Be sure to read the "Safety Rules", as well as all other safety information in this manual, before attempting to operate this (and related) equipment.

Before starting the generator for the first time, the installer must complete the following procedures. For follow-up maintenance information and/or service intervals, please refer to the "Maintenance" section and the "Service Schedule".

#### ◆ TRANSFER SWITCH

If this generator is used to supply power to any electrical system normally powered by an electric utility, the National Electrical Code requires that a transfer switch be installed. The transfer switch prevents electrical backfeed between two different electrical systems. (For additional information, see the applicable transfer switch manual for this unit.) The transfer switch, as well as the generator and other standby components, must be properly located and mounted in strict compliance with applicable codes, standards and regulations.

#### ◆ FUEL SYSTEM

Make sure the fuel supply system to the generator (a) delivers the correct fuel at the correct pressure and (b) is properly purged and leak tested according to code. No fuel leakage is permitted. See "Specifications" for more information.

#### ◆ GENERATOR SET LUBRICATION

Check the engine crankcase oil level before operating and add oil to the proper level – the dipstick "FULL" mark. Never operate the engine with the oil level below the dipstick "ADD" mark. See "Specifications" and "Engine Oil Recommendations".

#### NOTE:

**This engine is shipped from the manufacturer with "break-in" oil. This oil should be changed after 30 hours of operation.**

Check the oil level in the generator gearbox (if so equipped) prior to initial use and at the intervals indicated by the "Service Schedule." The recommended oil is SAE 90 gear lubricant.

Also, if the engine is equipped with a mechanical governor, make sure the governor is properly lubricated with clean engine oil.

### ◆ PRIOR TO INITIAL START-UP



⚠ Prior to initially starting the generator, it must be properly prepared for use. Any attempt to crank or start the engine before it has been properly serviced with the recommended types and quantities of engine fluids (oil, coolant, fuel, etc.) may result in an engine failure.

#### ◆ ENGINE COOLANT

Have the engine cooling system properly filled with the recommended coolant mixture. Check the system for leaks and other problems. See "Specifications" and "Coolant" sections.

#### ◆ BELT TENSION

Check the engine-fan belt tension and condition prior to placing the unit into service and at recommended intervals. Belt tension is correct when a force of approximately 22 pounds (10 kg), applied midway between pulleys, deflects the belt about 3/8- to 5/8-inch (10 to 16 mm).

#### ◆ ELECTRICAL SYSTEM

Make sure the generator is properly connected to an approved earth ground.

Make sure the generator battery is fully charged, properly installed and interconnected, and ready for use.

#### NOTE:


**Battery charger must be connected to 120 VAC, 15 amp circuit to operate.**

Check to ensure that there are no loose electrical connections. Restrain any loose wires to keep them clear of any moving generator set components.

## INITIAL INSPECTION FOR QT GENSET STARTUP

**Inspect for the following.**

- Freight Damage.
- Manuals present.
- Fluid Levels (Oil, coolant, battery, Gear Drive).
- Correct fuel piping.
- Correct muffler installation for external application.
- Adequate air flow, clearances and ventilation per installation drawings and applicable codes.
- Correct AC and DC wire size, connections and grounding. Control and communication wiring to/from the transfer switch must be run in a separate conduit from the AC power leads.



- **Battery charger connection to 120 VAC.**
- Communication wires connected between transfer switch and generator (HTS only).
- Unit secured to pad.

## START-UP CHECKLIST



### WARNING

**Before working on the generator, ensure the following:**

- **The AUTO/OFF/MANUAL switch is in the OFF position.**
- **The 120VAC supply to the battery charger is switched OFF.**

## ◆ PREPARATION FOR START-UP

- Ensure that the 120VAC circuit breaker to the battery charger is open.
- Remove the fuse from the the control panel. For the H-100 and R-series: Open the front door of the control box and remove the 15 Amp ATO fuse in the lower left-hand corner of the control box.
- Connect the battery cables to the battery. Attach negative battery cable last.
- Close the 120VAC circuit breaker to the battery charger.
- Measure the voltage at the battery before and after the charger is turned on.
- Verify all AC electrical connections are tight at the circuit breaker and transfer switch.
- Visually inspect entire area looking for loose paper, plastic wrappings, leaves, etc.
- Check all hoses clamps fittings for leaks or damage.
- Check all electrical plugs throughout the generator. Ensure each plug is seated correctly and fully inserted into its receptacle.
- Verify the AUTO/OFF/MANUAL switch is in OFF position.
- Open the valve to the engine fuel line.
- Bleed the fuel system of air. (necessary for long fuel lines).
- Open the generator main line circuit breaker.
- Connect a manometer to the gas line and record the static pressure. It must be as listed in the Specifications.

- Insert the fuse into the control panel.
- Move the AUTO/OFF/MANUAL switch to the MANUAL position. The engine should now crank and start.
- Check voltage at the generator terminals.
- For 3-phase units, check phase rotation at the transfer switch terminals. The generator phase rotation must match the utility phase rotation.
- Check for coolant, fuel, oil, and exhaust leaks.
- Close the generators main line circuit breaker.
- Turn the generator set off.
- Connect the UTILITY supply to the transfer switch.
- Set the AUTO/OFF/MANUAL switch to AUTO.
- Disconnect utility power before the transfer switch.

Engine should start, transfer to load.



Run at least 15 minutes on generator power. Make certain all 3-phase loads are functioning correctly (correct phase rotation).

- **Reconnect Utility power**  
Transfer switch will transfer back to Utility and engine will shut down within the given time parameters set up for the specific transfer switch and controller.
- Install all covers, access plates and door panels.
- Put the Owners Manual in a safe and accessible place.
- Make certain the AUTO/OFF/MANUAL switch is in the AUTO position.

## ◆ START-UP INSPECTION

When a start-up is performed by an Authorized Service Dealer, a standard three-part form titled "Start-up Inspection for Standby Power Systems" (part no. 067377), should be completed by the installation technician or engineer. See page 1-3 for information on locating the nearest Authorized Service Dealer. The installer should complete the form and disseminate copies as follows:

- White copy: Mail to Generac Warranty Department, P.O. Box 340, 211 Murphy Dr., Eagle, WI 53119-2062.
- Pink Copy: For service file of installing dealer.
- Yellow Copy: For the customer's records.



## GENERATOR CONTROL AND OPERATION

Refer to the appropriate control panel operator's manual for this unit.

## OPERATING UNIT WITH MANUAL TRANSFER SWITCH

If the generator was installed in conjunction with a transfer switch capable of manual operation only, the following procedure applies. A manually operated transfer switch is one that will not provide automatic start-up and does not include an intelligence circuit.

### ◆ ENGINE START-UP AND TRANSFER

For additional information, refer to the applicable control panel manual for this unit, as well as any literature pertaining to the specific transfer switch.



⚠ The Maintenance Disconnect Switch and the AUTO/OFF/MANUAL switches (if so equipped) must be set properly, or the generator will crank and start as soon as the utility power to the transfer switch is turned off. Refer to applicable control panel and transfer switch manuals for more information.

⚠ Do not proceed until certain that utility source voltage is available to the transfer switch and the transfer switch main contacts are set to UTILITY.

⚠ Do not attempt manual operation until all power supplies to the transfer switch have been positively turned off, or extremely dangerous - possibly lethal - electrical shock will result.

⚠ Transfer switch enclosure doors should be kept closed and locked. Only authorized personnel should be allowed access to the transfer switch interior. Extremely high and dangerous voltages are present in the transfer switch.

In order to transfer load from the utility source to the generator, follow these directions:

- Turn OFF or disconnect the utility power circuit to the transfer switch, using the means provided (such as the utility source main line circuit breaker).
- Set the transfer handle to its UTILITY (NORMAL) position with load circuits connected to the utility power supply.
- Set the standby generator's main line circuit breaker to its OFF (or OPEN) position.
- Start the generator.



⚠ Do not crank the engine continuously for longer than 30 seconds, or the heat may damage the starter motor.

- Let engine stabilize and warm up.
- Check all applicable instrument and gauge readings. When certain that all readings are correct, move the transfer switch manual handle to its STANDBY (GENERATOR) position, i.e., load circuits supplied by the generator.
- Set the standby generator's main line circuit breaker to its ON (or CLOSED) position.
- Load circuits are now powered by the standby generator.

### ◆ RETRANSFER AND SHUTDOWN

For additional information, refer to the applicable control panel manual for this unit, as well as any literature pertaining to the specific transfer switch.

To transfer the load back to the utility power source and shut down the generator, follow these directions:


- Set the standby generator's main line circuit breaker to its OFF (or OPEN) position.
- Manually move the transfer switch handle to its UTILITY (NORMAL) position, i.e., load circuits connected to the utility.
- Turn ON the utility power supply to the transfer switch, using the means provided (such as the utility power source main line circuit breaker).
- Let the generator run at no-load for a few minutes to stabilize internal temperatures.
- Shut down the generator.

## OPERATING UNIT WITH AUTOMATIC TRANSFER SWITCH

If the generator has been installed with an automatic transfer switch, such as an RTS, HTS, or GTS-type transfer switch, the engine may be started and stopped automatically or manually.

### NOTE:

**Refer to the applicable manual for your transfer switch and to "Transfer Switch Start Signal Connections". In addition, please note the dangers under "Engine Start-up and Transfer."**



### MAINTENANCE PERFORMED BY AUTHORIZED SERVICE FACILITIES

#### — ⚠ WARNING ⚠ —

⚠ Before working on the generator, ensure the following:

- The AUTO/OFF/MANUAL switch is in the OFF position.
- The 15A fuse has been removed from the control box.
- The 120VAC supply to the battery charger is switched OFF.

#### ◆ EVERY THREE MONTHS

1. Check battery state of charge and condition.
2. Inspect and test fuel system.
3. Check transfer switch.
4. Inspect exhaust system.
5. Check engine ignition system.
6. Check fan belts.

#### ◆ ONCE EVERY SIX MONTHS

1. Test Engine Safety Devices (low oil pressure, low coolant level, high coolant temperature).

#### ◆ ONCE ANNUALLY

1. Test engine governor. Adjust or repair, if needed.
2. Clean, inspect generator.
3. Flush cooling system.

#### ◆ FIRST 100 OPERATING HOURS

1. Change engine oil and oil filter. (After initial change, service engine oil and filter at 150 operating hours or 6 months, whichever comes first.)

#### ◆ EVERY 500 OPERATING HOURS

1. Service air cleaner.
2. Check starter.
3. Check engine DC alternator.

### COOLING SYSTEM

Air intake and outlet openings in the generator compartment must be open and unobstructed for continued proper operation. This includes such obstructions as high grass, weeds, brush, leaves and snow.

Without sufficient cooling and ventilating air flow, the engine/generator quickly overheats, which causes it to shut down.

#### — ⚠ WARNING ⚠ —

⚠ The exhaust system parts from this product get extremely hot and remain hot after shutdown. High grass, weeds, brush, leaves, etc. must remain clear of the exhaust. Such materials may ignite and burn from the heat of the exhaust system.


### CHECKING FLUID LEVELS

#### ◆ CHECK ENGINE OIL

Check engine crankcase oil level (Figure 10.1) at least every 20 hours of operation, or prior to use.

- Remove oil dipstick and wipe dry with a clean, lint-free cloth.
- Install oil dipstick, then remove again.
- Oil should be between FULL and ADD marks.
- If oil level is below the dipstick ADD mark, remove oil fill cap. Add the recommended oil to bring oil level up to the FULL mark. DO NOT FILL ABOVE THE "FULL" MARK. See "Engine Oil Recommendations" for recommended oils.

*Figure 10.1 - Oil Dipstick and Oil Fill Cap*



#### ◆ BATTERY FLUID

Check battery electrolyte fluid at least once weekly. Fluid should cover separators in all battery cells. If fluid level is low, add distilled water to cover tops of separators. DO NOT USE TAP WATER IN BATTERY.



## Standby Generator Sets Maintenance



### ◆ ENGINE COOLANT

Check coolant level in coolant recovery bottle. See the “Specifications” section.

- Add recommended coolant mixture as necessary.
- Periodically remove radiator pressure cap to make sure the coolant recovery system is functioning properly. Coolant should be at bottom of radiator filler neck. If coolant level is low, inspect gasket in radiator pressure cap. Replace cap, if necessary. To have pressure cap tested, contact an Authorized Service Dealer. Inspect cooling system and coolant recovery system for leaks.

## MAINTENANCE OWNER/ OPERATOR CAN PERFORM

### ◆ CHECK ENGINE OIL LEVEL

Refer to the “Checking Fluid Levels” section.

### ◆ CHECK BATTERY

- Check battery fluid level each week as outlined under “Check Fluid Levels”.
- Check battery cables for condition, tightness, corrosion or damage. Clean, tighten or replace as necessary.

### ◆ EXERCISE SYSTEM

Start the generator engine at least once every seven days and let it run at least 20 minutes. See the “Weekly Exercise Cycle” section.

### ◆ INSPECT COOLING SYSTEM

- Inspect engine cooling system at least once each month.
- Check hoses for damage, deterioration, leaks, etc. Correct any discrepancies found.
- Check hose clamps for tightness.

### ◆ CHECK ENGINE COOLANT LEVEL

See the “Checking Fluid Levels” section.

### ◆ PERFORM VISUAL INSPECTION

Complete a thorough visual inspection of the entire engine-generator monthly. Look for obvious damage, loose, missing or corroded nuts, bolts and other fasteners. Look for fuel, oil or coolant leaks.

### ◆ INSPECT EXHAUST SYSTEM

Inspect the exhaust system at least once every three months. Check all exhaust system pipes, mufflers, clamps, etc. for condition, tightness, leaks, security, damage.

### ◆ CHECK FAN BELT

- Inspect fan belts every three months. Replace any damaged, deteriorated, worn or otherwise defective belt.
- Check fan belt tension. Thumb pressure, exerted midway between pulleys, should deflect about 3/8 to 5/8 inch. Adjust belt tension as required.

### ◆ INSPECT ENGINE GOVERNOR

Visually inspect electronic governor.



- ⚠ Do not attempt to adjust the governor. Only qualified service facilities should adjust the governor. Excessively high operating speeds are dangerous and increase the risk of personal injury. Low speeds impose a heavy load on the engine when adequate engine power is not available and may shorten engine life. Correct rated frequency and voltage are supplied only at the proper governed speed. Some connected electrical load devices may be damaged by incorrect frequency and/or voltage. Only qualified service technicians should adjust the governed speed.

### ◆ CHANGING ENGINE OIL


Refer to maintenance performed by authorized service facilities for engine oil and filter change frequencies.

Drain the oil while the engine is still warm from running. This means warm up the engine, shut it down and drain immediately as follows:

1. Remove OIL DRAIN HOSE from its retaining clip.
2. Loosen and remove OIL DRAIN HOSE CAP. Drain oil completely into suitable container.
3. When all oil has drained, install and tighten OIL DRAIN HOSE CAP, and re-install into its retaining clip.
4. Turn OIL FILTER (Figure 10.2) counterclockwise and remove. Dispose of old filter.
5. Apply light coating of new engine oil to seal of new oil filter. Install FILTER and tighten by hand only. DO NOT OVERTIGHTEN.
6. Remove OIL FILL CAP. Add recommended oil (see SPECIFICATIONS). DO NOT FILL ABOVE THE DIPSTICK “FULL” MARK. Crankcase oil capacity is 4.0 U.S. quarts (3.8 liters).




- ⚠ After refilling the crankcase with oil, always check oil level on dipstick. NEVER OPERATE ENGINE WITH OIL BELOW THE DIPSTICK “ADD” MARK.



7. Start engine and check for oil leaks.

**Figure 10.2 - Oil Filter**



### ◆ CHANGING THE ENGINE AIR CLEANER

To replace the engine air cleaner, (part number 0A4637), remove the air cleaner cover and replace the air filter making sure it is positioned properly before reattaching the cover.

See the “Service Schedule” section for air cleaner maintenance.


### ◆ SPARK PLUGS

Reset the spark plug gap or replace the spark plugs as necessary.

1. Clean the area around the base of the spark plugs to keep dirt and debris out of the engine. Clean by scraping or washing using a wire brush and commercial solvent. Do not blast the spark plugs to clean.
2. Remove the spark plugs and check the condition. Replace the spark plugs if worn or if reuse is questionable. See the “Service Schedule” section for recommended inspection.
3. Check the spark plug gap using a wire feeler gauge. Adjust the gap to 1.01 mm (0.040 inch) by carefully bending the ground electrode (Figure 10.3).

**Figure 10.3 – Setting the Spark Plug Gap**

SET PLUG GAP AT 1.01 mm  
(0.040 inch)



### ◆ COOLANT CHANGE

Every year, have an Authorized Service Facility drain, flush and refill the cooling system. See the “Specifications” section for cooling system recommendations.

## MISCELLANEOUS MAINTENANCE

### ◆ CLEANING THE GENERATOR

Keep the generator as clean and as dry as possible. Dirt and moisture that accumulates on internal generator windings have an adverse effect on insulation resistance.

Periodically clean generator exterior surfaces. A soft brush may be used to loosen caked on dirt. Use a vacuum system or dry, low pressure air to remove any accumulations of dirt. The generator is housed inside an all-weather enclosure, clean the enclosure with a soft, damp cloth or sponge and water.

Once each year, have the generator cleaned and inspected by an Authorized Service Dealer. That dealer will use dry, low pressure air to clean internal windings. Parts inside the control console should be cleaned and inspected at this time as well.

Finally, have the insulation resistance of stator and rotor windings checked. If insulation resistances are excessively low, the generator may require drying.


### ◆ BATTERY

All lead-acid storage batteries discharge when not in use. Refer to specific instructions and warnings that accompany the battery. If such information is not available, observe the following precautions when handling a battery:

- DO NOT use jumper cables and a booster battery to crank or start the generator engine.
- DO NOT recharge a weak battery while it is installed in the generator. Remove battery from generator and recharge in a well-ventilated area, away from fuel vapors, sparks, heat or flames.
- Battery electrolyte fluid is an extremely caustic sulfuric solution that can cause severe burns. DO NOT permit fluid to contact eyes, skin, clothing, painted surfaces, wiring insulation, etc. If any battery fluid is spilled, flush the affected area with clear water immediately.
- Always wear safety glasses, rubber apron and gloves when handling a battery.
- Batteries give off explosive hydrogen gas while charging. The gas can form an explosive mixture around the battery for several hours after charging. Any spark, heat or flames can ignite the gas and cause an explosion which can shatter the battery, causing blindness or other serious injury.



## Standby Generator Sets Maintenance



### ◆ BATTERY MAINTENANCE

The battery should be inspected per the “Service Schedule” section. The following procedure should be followed for inspection:

1. Inspect the battery posts and cables for tightness and corrosion. Tighten and clean as necessary.
2. Check the battery fluid level of unsealed batteries and, if necessary, fill with DISTILLED WATER ONLY. DO NOT USE TAP WATER IN BATTERIES.
3. Have the state of charge and condition checked. This should be done with an automotive-type battery hydrometer.



 Storage batteries give off explosive hydrogen gas. This gas can form an explosive mixture around the battery for several hours after charging. The slightest spark can ignite the gas and cause an explosion. Such an explosion can shatter the battery and cause blindness or other injury. Any area that houses a storage battery must be properly ventilated. Do not allow smoking, open flame, sparks or any spark producing tools or equipment near the battery.

 Battery electrolyte fluid is an extremely caustic sulfuric acid solution that can cause severe burns. Do not permit fluid to contact eyes, skin, clothing, painted surfaces, etc. Wear protective goggles, protective clothing and gloves when handling a battery. If the fluid is spilled, flush the affected area immediately with clear water.

 Do not use any jumper cables or booster battery to crank and start the generator engine. If the battery has completely discharged, remove it from the generator for recharging.



 Be sure the AUTO/OFF/MANUAL switch is set to the OFF position before connecting the battery cables. If the switch is set to AUTO or MANUAL, the generator can crank and start as soon as the battery cables are connected.

 Be sure the 120VAC power supply to the battery is turned OFF, or sparking may occur at the battery posts as the cables are attached and cause an explosion.

### ◆ BATTERY REPLACEMENT

When replacing batteries, use the same number and the type of battery that follows:

| BCI Group No. | CCA            |
|---------------|----------------|
| 24F-6         | 535 @ 0 deg. F |

#### NOTE:

The BCI number should be located directly on the battery.

### REPAIR PARTS

The latter portion of this manual consists of exploded views, parts lists and electrical data pertaining to this generator set. The parts lists consist of (a) an item number, (b) a part number, (c) the quantity required, and (d) a description of the part. The item number corresponds to an identical number on the exploded view drawing.

| Periodic Replacement Parts |                    |
|----------------------------|--------------------|
| Part Name                  | Part Number        |
| Oil Filter                 | # 0E7415           |
| Radiator Cap               | # 046627           |
| Air Cleaner                | # 0A4637           |
| Spark Plug                 | Champion # RC12LC4 |



## Standby Generator Sets Service Schedule



### SERVICE SCHEDULE

#### 30 KW - 150 KW STANDBY GAS ENGINE DRIVEN GENERATOR SETS

The following is a recommended maintenance schedule for standby gas engine driven generator sets from 30kW to 150 kW in size. The established intervals in the schedule are the maximum recommended when the unit is used in an average service application. They will need to be decreased (performed more frequently) if the unit is used in a severe application. Use calendar time, from the previous maintenance interval to determine the next required maintenance interval.

#### Service Maintenance Interval Information:

The various service maintenance intervals are designated by interval numbers as follows:

- 1 An early inspection of the generator set to insure it is ready to operate when required and to identify any potential problem areas.

*This inspection may be performed by the end user providing the following safety steps are taken to prevent the engine from starting automatically without warning:*

**To prevent injury, perform the following steps in the order indicated before starting any maintenance:**

- Disable the generator set from starting and/or connecting to the load by setting the control panel Auto/Off/Manual switch to the "OFF" position.
- Remove the 15 amp control panel fuse.
- Turn off the battery charger.
- Remove the negative battery cable.

**The battery charger must be turned off BEFORE removing the battery cable to prevent an over current condition from burning out sensitive control panel components and circuits.**

**Following all maintenance, reverse these steps to insure the unit is returned to standby setup for normal operation when required.**

- 2 A wear-in service inspection of the generator set to insure it is ready to operate and carry the load when required, and to identify any potential problem areas.

*Performed **ONLY ONCE** following the first three months or the first 30 hours of operation after purchase of the unit.*

*This inspection contains some maintenance tasks which require special tools, equipment, and/or knowledge to accomplish and should be performed only by a Service Dealer.*

- 3 An operational inspection of the generator set to insure it is ready to operate and carry the load when required, and to identify any potential problem areas.

*Performed semi-annually or following each 50 hours of operation of the unit.*

*This inspection contains some maintenance tasks which require special tools, equipment, and/or knowledge to accomplish and should be performed only by a Service Dealer.*

- 4 A mid-level inspection of the generator set to insure it is ready to operate and carry the load when required, and to identify any potential problem areas.


*Performed annually or following each 100 hours of operation of the unit.*

*This inspection contains some maintenance tasks which require special tools, equipment, and/or knowledge to accomplish and should be performed only by a Service Dealer.*


- 5 A comprehensive inspection of the generator set to insure it is properly serviced and ready to operate and carry the load when required, and to identify any potential problem areas.

*Performed annually or following each 250 hours of operation of the unit.*


*This inspection contains some maintenance tasks which require special tools, equipment, and/or knowledge to accomplish and should be performed only by a Service Dealer.*




## Standby Generator Sets Service Schedule



| Maintenance Tasks                                                                                                                     | Level 1                                               |                                      | Level 2                                                    |                                      | Level 3                                                 |                                      | Level 4                                         |                                      | Level5                                                 |                                      |
|---------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|--------------------------------------|------------------------------------------------------------|--------------------------------------|---------------------------------------------------------|--------------------------------------|-------------------------------------------------|--------------------------------------|--------------------------------------------------------|--------------------------------------|
|                                                                                                                                       | Recom-<br>mended<br>to be done<br>monthly/<br>10 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Required<br>to be done<br>3 months/<br>Break-in<br>30 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Required<br>to be done<br>Semi-<br>annually/<br>50 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Required<br>to be done<br>Annually/<br>100 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Required<br>to be done<br>Bi-<br>annually/<br>250 hrs. | Task<br>Comp.<br>(Date-<br>Initials) |
| 1. Disable the unit from operating per the first page warning.                                                                        |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 2. Check the engine oil level. Adjust as necessary.                                                                                   |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 3. Check the engine coolant level. Adjust as necessary.                                                                               |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 4. Check the engine coolant thermal protection level. Correct as necessary.                                                           |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 5. Check the natural gas delivery system for leaks and correct pressure on gas engine driven units. Tighten connections as necessary. |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 6. Check the air inlets and outlets for debris. Clean as necessary.                                                                   |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 7. Check the battery electrolyte level and specific gravity if accessible. Adjust as necessary.                                       |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 8. Check the battery posts, cables, and charger for loose connections, corrosion, and proper operation. Correct as necessary.         |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |
| 9. Check the unit wiring for loose connections, corrosion, and damage. Correct as necessary.                                          |                                                       |                                      |                                                            |                                      |                                                         |                                      |                                                 |                                      |                                                        |                                      |




## Standby Generator Sets Service Schedule




| Maintenance Tasks                                                                                                                                                                                                      | Level 1<br>Recom-<br>mended<br>to be done<br>monthly/<br>10 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 2<br>Required<br>to be done<br>3 months/<br>Break-in<br>30 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 3<br>Required<br>to be done<br>Semi-<br>annually/<br>50 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 4<br>Required<br>to be done<br>Annually/<br>100 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level5<br>Required<br>to be done<br>Bi-<br>annually/<br>250 hrs. | Task<br>Comp.<br>(Date-<br>Initials) |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|--------------------------------------|-----------------------------------------------------------------------|--------------------------------------|--------------------------------------------------------------------|--------------------------------------|------------------------------------------------------------|--------------------------------------|------------------------------------------------------------------|--------------------------------------|
| 10. Check the engine accessory drive belts and fan coupling device if equipped for correct tension, wear, weather cracking, and damage. Replace as necessary.                                                          |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 11. Check the engine valve clearance/lash. Adjust as necessary.**                                                                                                                                                      |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 12. Visually inspect the unit looking for leaks, wear or damage, loose connections or components, and corrosion. Correct as necessary.                                                                                 |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 13. Test the engine and transfer switch safety devices. Correct and/or adjust as necessary.                                                                                                                            |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 14. Initiate an automatic start and transfer of the unit to site load and exercise it for at least 1 hour looking for leaks, loose connections or components, and abnormal operating conditions. Correct as necessary. |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 15. Replace the engine accessory drive belts.                                                                                                                                                                          |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 16. Check gearbox oil level (if equipped).                                                                                                                                                                             |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 17. Change gearbox oil (if equipped).                                                                                                                                                                                  |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |

\*\* Not required for engines equipped with hydraulic lifters. See the "Specification" section for lifter type.



## Standby Generator Sets Service Schedule



| Maintenance Tasks                                                                                                                                                                                                                     | Level 1<br>Recom-<br>mended<br>to be done<br>monthly/<br>10 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 2<br>Required<br>to be done<br>3 months/<br>Break-in<br>30 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 3<br>Required<br>to be done<br>Semi-<br>annually/<br>50 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level 4<br>Required<br>to be done<br>Annually/<br>100 hrs. | Task<br>Comp.<br>(Date-<br>Initials) | Level5<br>Required<br>to be done<br>Bi-<br>annually/<br>250 hrs. | Task<br>Comp.<br>(Date-<br>Initials) |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|--------------------------------------|-----------------------------------------------------------------------|--------------------------------------|--------------------------------------------------------------------|--------------------------------------|------------------------------------------------------------|--------------------------------------|------------------------------------------------------------------|--------------------------------------|
| 18. Start and exercise the unit at full rated load (use a load bank if the site load is not enough) for at least 2 hours looking for leaks, loose connections or components, and abnormal operating conditions. Correct as necessary. |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 19. Perform an engine oil analysis (send a sample to a lab for results). Change the engine oil and filters if the analysis results indicate this is required.                                                                         |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 20. Change the engine oil.                                                                                                                                                                                                            |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 21. Replace the engine oil filter(s).                                                                                                                                                                                                 |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 22. Replace engine spark plugs. Clean and re-gap or replace as necessary.                                                                                                                                                             |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 23. Replace the engine air filter(s).                                                                                                                                                                                                 |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 24. Perform a 5 minute no-load operational run of the unit looking for any post service problems.                                                                                                                                     |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |
| 25. Return the unit to standby setup for operation when required.                                                                                                                                                                     |                                                                  |                                      |                                                                       |                                      |                                                                    |                                      |                                                            |                                      |                                                                  |                                      |



## TROUBLESHOOTING GUIDE

| PROBLEM                                                | CAUSE                                                                                                                                                                                                                                                                                                                          | CORRECTION                                                                                                                                                                                                                                                             |
|--------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine won't crank.                                    | <ol style="list-style-type: none"> <li>15 amp fuse blown.</li> <li>Loose or corroded or defective battery cables.</li> <li>Defective starter contactor.</li> <li>Defective starter motor.</li> <li>Dead or Defective Battery.</li> <li>5 amp fuse blown.</li> </ol>                                                            | <ol style="list-style-type: none"> <li>Replace fuse.</li> <li>Tighten, clean or replace battery cables as necessary.</li> <li>Replace contactor.*</li> <li>Replace starter motor.*</li> <li>Remove, change or replace battery.</li> <li>Replace fuse.*</li> </ol>      |
| Engine cranks but won't start                          | <ol style="list-style-type: none"> <li>Out of fuel.</li> <li>Fuel solenoid (FS) is defective</li> <li>Open Wire #14A from Engine Control circuit board.</li> <li>Spark plugs defective.</li> <li>Door on tank not closed.</li> </ol>                                                                                           | <ol style="list-style-type: none"> <li>Replenish fuel.</li> <li>Replace solenoid.*</li> <li>Reconnect wire.</li> <li>Clean, regap or replace plugs.</li> <li>Close door on tank.</li> </ol>                                                                            |
| Engine starts hard, runs rough.                        | <ol style="list-style-type: none"> <li>Flame arrestor (air cleaner) plugged or damaged.</li> <li>Plugged fuel line.</li> <li>Defective spark plugs.</li> <li>Fuel pressure incorrect.</li> </ol>                                                                                                                               | <ol style="list-style-type: none"> <li>Clean or replace as needed.</li> <li>Unclog fuel line.</li> <li>Clean, regap or replace plugs.</li> <li>Confirm fuel pressure to regulator is as recommended in SPECIFICATIONS.</li> </ol>                                      |
| Engine starts then shuts down.                         | <ol style="list-style-type: none"> <li>Engine oil level is low.</li> <li>Engine is overheated.</li> <li>Defective Low Oil Pressure Switch</li> <li>Defective Coolant Temperature Switch</li> <li>Defective Control Module circuit board.</li> <li>Coolant Level is Low.</li> <li>Defective Low Coolant Level Switch</li> </ol> | <ol style="list-style-type: none"> <li>Check oil and add oil as needed.</li> <li>Check cooling system for leaks.</li> <li>Replace switch.*</li> <li>Replace switch.*</li> <li>Replace board.*</li> <li>Repair leak - Add coolant.</li> <li>Replace Switch.*</li> </ol> |
| AUTO/OFF/MANUAL Switch at OFF, engine continues to run | <ol style="list-style-type: none"> <li>Defective AUTO/OFF/MANUAL switch</li> <li>Open/disconnected wire #15A between AUTO/OFF/MANUAL switch and Control Module circuit board.</li> <li>Defective Control Module circuit board</li> </ol>                                                                                       | <ol style="list-style-type: none"> <li>Replace switch.*</li> <li>Reconnect/close wire.</li> <li>Replace board.*</li> </ol>                                                                                                                                             |
| No AC output from generator.                           | <ol style="list-style-type: none"> <li>Check main line circuit breaker.</li> <li>Check circuit breaker &amp; fuses.</li> <li>Transfer switch set to NORMAL position</li> <li>Generator internal failure.</li> <li>Thermal circuit breaker open.</li> </ol>                                                                     | <ol style="list-style-type: none"> <li>Reset to ON or CLOSED.</li> <li>Reset and replace, if necessary.</li> <li>Set to GENERATOR position.</li> <li>*</li> <li>Auto-reset - Wait 5 min. and attempt restart.</li> </ol>                                               |

**\*Contact the nearest Authorized Dealer for assistance.**

## Standby Generator Sets

## Standby Generator Sets






## NOTES

NOTES

## Standby Generator Sets Notes

NOTES

# GROUP A



EXPLODED VIEW:  
CPL C2 & C4 FLEX HSB  
DRAWING #: 0F3391D

EXPLODED VIEW: CPL C2 & C4 FLEX HSB  
DRAWING #: 0F3391D

GROUP A


APPLICABLE TO:

| ITEM   | PART #  | QTY. | DESCRIPTION                                        |
|--------|---------|------|----------------------------------------------------|
| 1      | 0F3137  | 1    | PAN CB CONN BOX                                    |
| 2      | 0F3188  | 1    | STAND RH CONTROL                                   |
| 3      | 0F3189  | 1    | STAND LH CONTROL                                   |
| 4      | 023484N | 1    | BUSHING SNAP SB-2.5-31                             |
| 5      | 0F6366B | 1    | XFMR DUAL 120V/16V (FOR 120/240V & 277/480V UNITS) |
|        | 0F6366A | 1    | XFMR DUAL 104V/16V (FOR 120/208V UNITS)            |
| 6      | 043180  | 2    | WASHER FLAT M4                                     |
| 7      | 022264  | 2    | WASHER LOCK #8-M4                                  |
| 8      | 0C3990  | 2    | SCREW PHTT M4-0.7 X 10 ZYC                         |
| (1) 9  | 057701  | REF  | BLOCK TERM 20A 8 X 6 X 1100V                       |
| 10     | 022155  | 4    | WASHER LOCK #6                                     |
| 11     | 0C2428  | 4    | SCREW PHTT #6-32 X 1/2 ZYC                         |
| 12     | 0F3824  | 1    | DECAL UTIL SENSE/CUST CONN                         |
| 13     | 0A9457  | 1    | DECAL NEUTRAL                                      |
| 14     | 057073  | 2    | JUNCTION BLOCK 3/8-16                              |
| (2) 15 | 0D5466  | REF  | BUS BAR NEUTRAL BLOCK 390                          |
| (2) 16 | 0A7822  | REF  | LUG SLDLSS 600/250-1/0 X 1/4-28                    |
| 17     | 022237  | 2    | WASHER LOCK 3/8                                    |
| 18     | 022241  | 2    | NUT HEX 3/8-16 STEEL                               |
| 19     | 049226  | 6    | WASHER LOCK M5                                     |
| 20     | 0C2266  | 6    | SCREW PHTT M5-0.8 X 16 ZYC                         |
| 21     | 0C2454  | 8    | SCREW THF M6-1 X 16 N WA Z/JS                      |
| 23     | 022473  | 8    | WASHER FLAT 1/4-M6 ZINC                            |
| 24     | 022097  | 4    | WASHER LOCK M6-1/4                                 |
| (1) 26 | 0D4698  | REF  | BLOCK TERM 20A 6 X 3 X 1100V                       |
| 27     | 0F4464  | 1    | DECAL CUST CONN 120V UTILITY                       |
| 28     | 025433  | 1    | LUG SLDLSS #6-14 X 13/64 CU                        |
| 29     | 024469  | 1    | SCREW HHTT #10-32 X 3/8 CZ                         |
| 30     | 067210A | 1    | DECAL GROUND LUG                                   |
| 31     | 0D6029  | 4    | SCREW HHTT M6-1.0 X 16 ZYC                         |
| 32     | 081008  | 1    | GROMMET 1.25 X .25 X .75                           |
| 33     | 077043J | 1    | CONDUIT FLEX 2.0" ID (36" LG)                      |
| 34     | 051713  | 2    | WASHER FLAT M5                                     |
| 35     | 0F6156  | 1    | PLATE WIRE SNGL GALV                               |
| 36     | 029289  | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D)                      |
| 37     | 047411  | 4    | SCREW HHC M6-1.0 X 16 G8.8                         |
| (3) 39 | 0G0770  | 1    | HARNESS, TRANSFORMER ADAPTER                       |
| (4) 40 | 0G5952  | 1    | ASSY PCB IGN MOD 4.2L                              |
| (4) 41 | 036943  | 2    | SCREW PPHM #10/32 X 2                              |
| (4) 42 | 023897  | 4    | WASHER FLAT #10 ZINC                               |
| (4) 43 | 022152  | 2    | WASHER LOCK #10                                    |
| (4) 44 | 022158  | 2    | NUT HEX #10-32 STEEL                               |
| (4) 45 | 0C2454  | 1    | SCREW THF M6-1 X 16 N WA Z/JS                      |
| (4) 46 | 055934D | 1    | CLAMP VINYL 1.06 X .406 Z                          |
| 47     | 0F6145  | A/R  | SEAL WEATHER .45"DIA                               |
| 1)     |         |      | UL CIRCUIT BREAKER (ED)                            |
| A      | 0F3328  | 1    | COVER ED CB SHORT STND                             |
| C      | 0D5552  | 1    | CB 0050A 3P 480V S ED4 LL                          |
|        | 0D5553  | -    | CB 0060A 3P 480V S ED4 LL                          |
|        | 0D5554  | -    | CB 0070A 3P 480V S ED4 LL                          |
|        | 0D5556  | -    | CB 0090A 3P 480V S ED4 LL                          |
|        | 0D9693  | -    | CB 0125A 3P 480V S ED4 LL                          |
| D      | 0F0492  | 1    | INSULATOR CB S (ED-3P)                             |
| E      | 048927  | 4    | SCREW RHM #10-32 X 4-1/2                           |
| F      | 023897  | 4    | WASHER FLAT #10 ZINC                               |
| G      | 022152  | 4    | WASHER LOCK #10                                    |
| H      | 022158  | 4    | NUT HEX #10-32 STEEL                               |
| J      | 0C2454  | 9    | SCREW THF M6-1 X 16 N WA Z/JS                      |
| K      | 029289  | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D)                      |
| L      | 0F1733  | 1    | DECAL CUSTOMER CONNECT INSIDE                      |
| 2)     |         |      | UL CIRCUIT BREAKER (FD)                            |
| A      | 0F3138  | 1    | COVER CB CONN BOX                                  |
| C      | 0D5572  | 1    | CB 0150A 3P 600V S FD6 LL                          |
|        | 0D5573  | -    | CB 0175A 3P 600V S FD6 LL                          |
|        | 0D5574  | -    | CB 0200A 3P 600V S FD6 LL                          |
|        | 0D5575  | -    | CB 0225A 3P 600V S FD6 LL                          |
|        | 0D5576  | -    | CB 0250A 3P 600V S FD6 LL                          |
| D      | 0F0199  | 1    | INSULATOR CB FD FRAME 30MIL                        |
| E      | 081320  | 4    | SCREW SHC 1/4-20 X 4.5 G8.8 NZ                     |
| F      | 022473  | 4    | WASHER FLAT 1/4-M6 ZINC                            |
| G      | 022097  | 4    | WASHER LOCK M6-1/4                                 |


| ITEM | PART # | QTY. | DESCRIPTION                   |
|------|--------|------|-------------------------------|
| H    | 022127 | 4    | NUT HEX 1/4-20 STEEL          |
| J    | 0C2454 | 9    | SCREW THF M6-1 X 16 N WA Z/JS |
| K    | 029289 | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D) |
| L    | 0F1733 | 1    | DECAL CUSTOMER CONNECT INSIDE |
| 3)   |        |      | UL CIRCUIT BREAKER (JD+LD)    |
| A    | 0F3329 | 1    | COVER JD/LD CB SHRT STAND     |
| C    | 0D5577 | 1    | CB 0300A 3P 600V S JD6 LL     |
| D    | 0F2353 | 2    | INSULATOR CIRCUIT BR. JD/LD   |
| E    | 022770 | 4    | SCREW RHM 1/4-20 X 3          |
| F    | 022473 | 4    | WASHER FLAT 1/4-M6 ZINC       |
| G    | 022097 | 4    | WASHER LOCK M6-1/4            |
| H    | 022127 | 4    | NUT HEX 1/4-20 STEEL          |
| J    | 0C2454 | 9    | SCREW THF M6-1 X 16 N WA Z/JS |
| K    | 029289 | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D) |
| L    | 0F1733 | 1    | DECAL CUSTOMER CONNECT INSIDE |
| 4)   |        |      | UL CIRCUIT BREAKER (QN)       |
| A    | 0F8135 | 1    | COVER QN FRM CB               |
| C    | 0E7283 | -    | CB 0150A 2P 240V S QN2 LL     |
|      | 0E7284 | -    | CB 0175A 2P S QN2 LL 240V     |
| D    | 0E3664 | 1    | BASE, QN CIRCUIT BREAKER      |
| E    | 074908 | 2    | SCREW HHTT M5-0.8 X 10 BP     |
| F    | 0F8140 | 1    | COVER QN CB DISH              |
| G    | 036261 | 4    | RIVET POP .125 X .275 SS      |
| H    | 0C2454 | 11   | SCREW THF M6-1X16 N WA Z/JS   |
| J    | 029289 | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D) |
| K    | 0F1733 | 1    | DECAL CUSTOMER CONNECT INSIDE |

- (1) ITEM INCLUDED WITH HARNESS  
(2) ITEM INCLUDED WITH 0D5464B  
(3) ITEM USED WITH EARLY MODEL 208V UNITS ONLY  
(4) ITEMS USED ON 4.2L MODELS ONLY.


6.) 225AF




8.) OD5464B




9.) BQ



5.) QJ-2P



7.) 400AF



**EXPLODED VIEW: CPL C2 & C4 FLEX HSB**  
**DRAWING #: 0F3391D**

**GROUP A**

APPLICABLE TO:


| ITEM  | PART #      | QTY. | DESCRIPTION                          |
|-------|-------------|------|--------------------------------------|
| 5)    |             |      | UL CIRCUIT BREAKER (QJ-2P)           |
| A     | 0F8137      | 1    | COVER QJ 2P FRM CB                   |
| C     | 0E7994      | -    | CB 0225A 240V 2P S QJ22              |
| D     | 0F8136      | 1    | COVER QJ 2P CB DISH                  |
| E     | 036261      | 4    | RIVET POP .125 X .275 SS             |
| F     | 022473      | 2    | WASHER FLAT 1/4-M6 ZINC              |
| G     | 022097      | 2    | WASHER LOCK M6-1/4                   |
| H     | 022127      | 2    | NUT HEX 1/4-20 STEEL                 |
| J     | 0F8139      | 1    | INSUL CB 2P QJ                       |
| K     | 0C2454      | 9    | SCREW THF M6-1 X 16 N WA Z/JS        |
| L     | 022237      | 2    | WASHER LOCK 3/8                      |
| M     | 048527      | 2    | SCREW SHC 3/8-16 X 3/4 G8.8 NZ       |
| N     | 029289      | 1    | TAPE ELEC 1/2 FOAM (AS REQ'D)        |
| P     | 022770      | 2    | SCREW RHM 1/4-20 X 3                 |
| Q     | 0F1733      | 1    | DECAL CUSTOMER CONNECT INSIDE        |
| 6)    |             |      | UL CIRCUIT BREAKER (225AF) (2P & 3P) |
| A     | 0F4185      | 1    | COVER CB C2-C4 (225AF)               |
| B     | 058306      | 3    | SCREW SHC M8-1.25 X 25 G12.9         |
| C     | 0F4165\$    | REF  | CIRCUIT BREAKERS 200A FRAME (3P)     |
|       | 0F4143      | REF  | CB 0040A 3P 480V 225AF (3P)          |
|       | 0F4148      | REF  | CB 0125A 3P 480V G 225AF             |
|       | 0F4149      | REF  | CB 0150A 3P 480V G 225AF             |
|       | 0F4151      | REF  | CB 0200A 3P 480V G 225AF             |
|       | 0G5247\$    | REF  | CB 200A FRAME G 240V (2P)            |
|       | 0G5250      | REF  | CB 175A 2 POLE 240V 225AF (2P)       |
|       | 0G4478      | REF  | CB 200A 2 POLE 240V 225AF (2P)       |
| D     | 0F4186      | 1    | COVER CB DISH 225AF (3P)             |
|       | 0F4186AGS0R |      | COVER CB DISH 225AF (2P)             |
| E     | 036261      | 4    | RIVET POP .125 X .275 SS             |
| (2) F | 053640      | 2/4  | SCREW RHM #8-32 X 3-1/4              |
| (2) G | 038150      | 2/4  | WASHER FLAT #8 ZINC                  |
| (2) H | 022264      | 2/4  | WASHER LOCK #8-M4                    |
| (2) J | 022471      | 2/4  | NUT HEX #8-32 STEEL                  |
| K     | 029289      | 2    | TAPE ELEC 1/2 FOAM                   |
| L     | 0F1733      | 1    | DECAL CUSTOMER CONNECT INSIDE        |
| (2) M | 022129      | 6/9  | WASHER LOCK M8-5/16                  |
| N     | 0F8432      | 1    | INSULATOR CB 225AF (3P)              |
|       | 0F8432A     | 1    | INSULATOR CB 225AF (2P)              |
| P     | 0C2454      | 11   | SCREW THF M6-1 X 16 N WA Z/JS        |
| (2) R | 0F8451      | 2/3  | LUG SLDLSS 300 MCM-6 AL/CU           |
| (2) S | 049897      | 4/6  | SCREW SHC M8-1.25 X 20 G8            |
| (2) T | 022145      | 4/6  | WASHER FLAT 5/16-M8 ZINC             |
| (2) U | 045771      | 2/3  | NUT HEX M8-1.25 G8 CLEAR ZINC        |
| (2) V | 0F8843      | 2/3  | BUS BAR 200A LUG ADAPTOR             |
| (1) W | W/CB        | 2    | TERMINAL COVER CB                    |
| X     | 0G3259      | 1    | DECAL TERMINAL SHOCK HZD BI          |
| 7)    |             |      | UL CIRCUIT BREAKER (400AF)           |
| A     | 0F4187      | 1    | COVER CB C2-C4 400AF                 |
| C     | 0F4166\$    | REF  | CIRCUIT BREAKERS 400A FRAME          |
| D     | 0F1733      | 1    | DECAL CUSTOMER CONNECT INSIDE        |
| E     | 042419      | 4    | SCREW RHM 10-32 X 4                  |
| F     | 023897      | 4    | WASHER FLAT #10 ZINC                 |
| G     | 022152      | 4    | WASHER LOCK #10                      |
| H     | 022158      | 4    | NUT HEX #10-32 STEEL                 |
| J     | 0C2454      | 9    | SCREW THF M6-1 X 16 N WA Z/JS        |
| K     | 029289      | 1    | TAPE ELEC 1/2 FOAM                   |
| (2) L | 052647      | 2/3  | SCREW SHC M10-1.5 X 25 G12.9         |
| (2) M | 046526      | 2/3  | WASHER LOCK M10                      |
| N     | W/CB        | 3    | BUS BAR CB ADAPTER 225-400 A         |
| P     | 0A7822      | 3    | LUG SLDLSS 600/250-1/0 X 1/4-28      |
| (1) S | W/CB        | 2    | TERM COVER CB                        |
| T     | 023334      | 6    | SCREW HHC 1/4-28 X 1/2 G5            |
| U     | 022097      | 6    | WASHER LOCK M6-1/4                   |
| V     | 022473      | 6    | WASHER FLAT 1/4-M6 ZINC              |
| (2) W | W/CB        | 2/3  | SCREW SHC M10-1.5 X 25 G12.9         |
| (2) X | W/CB        | 2/3  | WASHER LOCK M10                      |
| Y     | 0G3259      | 1    | DECAL TERMINAL SHOCK HZD BI          |

| ITEM | PART # | QTY. | DESCRIPTION                     |
|------|--------|------|---------------------------------|
| 8)   |        |      | NEUTRAL BLOCK 390 / 200-400A    |
| A    | 0D5466 | 2    | BUS BAR NEUTRAL BLOCK 390       |
| B    | 039287 | 1    | SCREW HHC M8-1.25 X 45 G8.8 FT  |
| C    | 022145 | 1    | WASHER FLAT 5/16-M8 ZINC        |
| D    | 022129 | 1    | WASHER LOCK M8-5/16             |
| E    | 045771 | 1    | NUT HEX M8-1.25 G8 YEL CHR      |
| F    | 045335 | 2    | SCREW HHC 1/4-28 X 3/4 G5       |
| G    | 083896 | 2    | WASHER LOCK 1/4-M6 SS           |
| H    | 0A7822 | 1    | LUG SLDLSS 600/250-1/0 X 1/4-28 |
| 9)   |        |      | UL CIRCUIT BREAKER (BQ)         |
| A    | 0G1968 | 1    | COVER BQ CIR BREAKER CPL 3P     |
|      | 0G1970 | -    | COVER BQ CIR BREAKER CPL 2P     |
| C    | 0A2077 | 1    | CB 0125A 2P 240V S BQ2 LL       |
|      | 040532 | -    | CB 0100A 3P 240V S BQ3 LL       |
| D    | 0C3990 | 2    | SCREW PHTT M4-0.7 X 10 ZYC      |
| E    | 0E7890 | 1    | BRKT CB MTG BACK                |
|      | 0E6002 | -    | MTG TRACK BQ SIEMENS CB 3P      |
| F    | 022859 | 6    | SCREW RHM #10-32 X 3/4          |
| G    | 0G0008 | 1    | BRKT BQ CB STANDOFF             |
| H    | 023897 | 6    | WASHER FLAT #10 ZINC            |
| J    | 022152 | 6    | WASHER LOCK #10                 |
| K    | 022158 | 6    | NUT HEX #10-32 STEEL            |
| L    | 0F1733 | 1    | DECAL CUSTOMER CONNECT INSIDE   |
| M    | 029289 | 1    | TAPE ELEC 1/2 FOAM              |
| N    | 0C2454 | 11   | SCREW THF M6-1 X 16 N WA Z/JS   |

(1) HARDWARE FOR MTG. CB TERMINAL COVERS IS SUPPLIED WITH CIRCUIT BREAKERS.

(2) QTY. REQ'D FOR "2POLE / 3POLE" BREAKER

# GROUP A



EXPLODED VIEW:  
CPL ALTERNATOR DIRECT EXCITATION  
DRAWING #: 0F3425

**EXPLODED VIEW: CPL ALTERNATOR DIRECT EXCITATION**  
**DRAWING #: 0F3425**


**GROUP A**

APPLICABLE TO:

| ITEM | PART #        | QTY. | DESCRIPTION                       |
|------|---------------|------|-----------------------------------|
| 1    | 0F3380        | 1    | ASSY RTR 2390 50KD1 CPL           |
|      | 0F3377        | 1    | ASSY RTR 2390 70KD2 CPL           |
| 2    | 0F3381        | 1    | ASSY STR 2390 50AD1 CPL           |
|      | 0F3378        | 1    | ASSY STR 2390 70AD2 CPL           |
|      | 0F6185        | 1    | ASSY STR 390 50KW 2P 3PH 480V     |
|      | 0F6186        | 1    | ASSY STR 390 70KW 2P 3PH 480V     |
|      | 0F6181        | 1    | ASSY STR 390 50KW 2P 3PH 208V     |
|      | 0F6182        | 1    | ASSY STR 390 70KW 2P 3PH 208V     |
| 3    | 0C9708        | REF  | INSTR HYPOT TEST (NOT SHOWN)      |
| 4    | SEE ENGINE EV | REF  | ENGINE ADAPTER                    |
| 5    | SEE ENGINE EV | REF  | FLEXPLATE                         |
| 6    | 0F5767B       | 1    | ASSY FLYWHEEL CPL W/40MM FAN B    |
| 7    | 0E5706        | 1    | REAR BEARING CARRIER 390/DRCT     |
| 8    | 0F7874        | 1    | ASSY BRUSH HOLDER 390/HSB         |
| 9    | 0F6125        | 1    | GUARD REAR BEARING CARRIER CPL    |
| 10   | 0F2689        | 1    | RING PRESSURE 390 STATOR CAN      |
| 11   | 023454        | 1    | KEY WOODRUFF #E                   |
| 12   | 077043F       | 1    | CONDUIT FLEX 1-1/4" (30" LG)      |
| 13   | 04576100BU    | 4    | STUD M14-2.0 570 G5 ZINC (50KW)   |
|      | 04576100CH    | 4    | STUD M14-2.0 X 600 G5 ZINC (70KW) |
| 14   | 052646        | 4    | WASHER FLAT M14                   |
| 15   | 043123        | 4    | WASHER LOCK M14                   |
| 16   | 051779        | 4    | NUT HEX M14-2.0 G8 YEL CHR        |
| 17   | 0A2601        | 1    | SCREW HHC M16-2.0 X 45 G8.8       |
| 18   | 0A2602        | 1    | WASHER FLAT .688 ID X 3.25 OD     |
| 19   | 0F3398        | 4    | SCREW SHC M10-1.5 X 16 G10.9      |
| 20   | 046526        | 4    | WASHER LOCK M10                   |
| 21   | 0C3993        | 4    | SCREW HHTT M4-0.7 X 25 BP         |
| 22   | 022264        | 4    | WASHER LOCK #8-M4                 |
| 23   | 038150        | 4    | WASHER FLAT #8 ZINC               |
| 24 * | 047248        | 1    | BALL BEARING-45 MM                |
| 25 * | 070892        | 1    | SLIP RING MACHINED                |
| 26   | 0F7272        | 6    | SCREW 1/4-20 X 5/8" TAPTITE SS    |

\* ROTOR REPLACEMENT PARTS


GROUP B



EXPLODED VIEW:  
R-100 3600 RPM 3.0L/3.9L  
DRAWING #: 0F7377D

APPLICABLE TO:

| ITEM                                  | PART #  | QTY. | DESCRIPTION                                |
|---------------------------------------|---------|------|--------------------------------------------|
| <u>COMPONENTS INCLUDED IN 01827E</u>  |         |      |                                            |
| 1                                     | 0F1823A | 1    | ENCL HSB CONTROL PANEL                     |
| 2                                     | 0F3078  | 1    | COVER CONTROL PANEL                        |
| 3                                     | 0F2606  | 1    | HINGE CONTINUOUS H-PANEL                   |
| 4                                     | 036261  | 6    | RIVET POP .125 X .275 SS                   |
| 5                                     | 043181  | 4    | SCREW PHM M3-0.5 X 10MM                    |
| 6                                     | 052777  | 11   | WASHER FLAT M3                             |
| 7                                     | 0F4245F | 1    | ASSY PCB CPL CTRLR 3600 RPM                |
| 8                                     | 0F1262  | 4    | HOLDER, FUSE WICKMANN 178.6150             |
| 9                                     | 0F1263  | 1    | ADPTR,RH SIDE WICKMAN 178.6191             |
| 10                                    | 0F1264  | 1    | ADPTR,LH SIDE WICKMAN 178.6192             |
| 11                                    | 0F1725C | 1    | ASSY PCB 2AMP 12V UL BATT CHGR             |
| 12                                    | 067680  | 1    | ASSY VOLTAGE REGULATOR 60HZ                |
| 13                                    | 0E6875A | 2    | RELAY, 12VDC C FORM W/DIODE                |
| 14                                    | 055911  | 1    | BLOCK TERM 20A 12 X 6 X 1100V              |
| 15                                    | 0F5459  | 1    | DECAL CPL CONTROL PANEL FUSES              |
| 16                                    | 0E3161  | 1    | ASSY PCB BOSCH GOV DRIVER                  |
| 17                                    | 0F5090  | 1    | ASSY PCB SCR BRIDGE                        |
| 18                                    | 0F5462  | 1    | DECAL CPL 3.9L TB1                         |
| 19                                    | 0A5062J | 4    | SPACER 9.5H 3.2 ID                         |
| 20                                    | 029673  | 1    | DIO BRIDGE 25A 600V                        |
| 21                                    | 048467  | 1    | CIRCT BRK 7 X 1 ETA 46-500-P               |
| 22                                    | 0F1958  | 1    | PLATE,HARNESS CLAMP                        |
| 23                                    | 082573  | 1    | SWITCH RKR DPST 125V SPD                   |
| 24                                    | 0E4494  | 1    | SWITCH RKR DPDT ON-OFF-ON                  |
| 25                                    | 0F3215  | 1    | DECAL, CONTROL HSB                         |
| 26                                    | 0F6305  | 3    | SEAL COVER 3.18X12.7X382                   |
| 27                                    | 0F6305A | 1    | SEAL COVER 3.18X12.7X283                   |
| 28                                    | 0F5886  | 3    | SCREW HHPM M5-0.8 X 12                     |
| 29                                    | 051713  | 12   | WASHER FLAT M5                             |
| 30                                    | 049226  | 12   | WASHER LOCK M5                             |
| 31                                    | 0F5752F | 1    | RES WW 15R 5% 25W QK CONN                  |
| 32                                    | 0F5884  | 2    | SCREW PHTT M3.5-0.6 X 10                   |
| 33                                    | 0F5896  | 2    | SCREW PHTT M3.5-0.6 X 16                   |
| 34                                    | 0C2265  | 4    | SCREW PHTT M4-0.7 X 12 ZYC                 |
| 35                                    | 0C3990  | 2    | SCREW PHTT M4-0.7 X 10 ZYC                 |
| 36                                    | 091526  | 4    | SCREW PPHM M5-0.8 X 12 ZNC                 |
| 37                                    | 051716  | 9    | NUT HEX M5-0.8 G8 CLEAR ZINC               |
| 38                                    | 079224  | 2    | SCREW PPHM M5-0.8 X 30 SS                  |
| 39                                    | 075476  | 2    | SCREW PPHM M4-0.7 X 16                     |
| 40                                    | 043180  | 2    | WASHER FLAT M4                             |
| 41                                    | 043184  | 2    | WASHER LOCK M4                             |
| 42                                    | 051715  | 2    | NUT HEX M4-0.7 G8 YEL CHR                  |
| 43                                    | 043182  | 7    | WASHER LOCK M3                             |
| 44                                    | 051714  | 7    | NUT HEX M3-0.5 G8 YEL CHR                  |
| 45                                    | 0F3192  | 1    | SUPPORT ANGLE PCB                          |
| 46                                    | 0E7403C | 1    | FUSE ATO TYPE 15 AMP (BLUE)                |
| 47                                    | 0F4415  | 1    | HARN 3600RPM R-100 CONTROL PNL (NOT SHOWN) |
| <u>COMPONENTS INCLUDED IN 0F7376D</u> |         |      |                                            |
| A                                     | 056739  | 1    | RELAY SOLENOID 12VDC PNL MNT               |
| B                                     | 022287  | 2    | SCREW HHC 1/4-20 X 3/4 G5                  |
| C                                     | 022473  | 4    | WASHER FLAT 1/4-M6 ZINC                    |
| D                                     | 022097  | 2    | WASHER LOCK M6-1/4                         |
| E                                     | 022127  | 2    | NUT HEX 1/4-20 STEEL                       |
| F                                     | 0F6145  | A/R  | SEAL WEATHER .45"DIA                       |
| G                                     | 0F2627A | 1    | COVER CONTROL PANEL SIDE                   |
| H                                     | 091526  | 4    | SCREW PPHM M5-0.8 X 12 ZNC                 |
| J                                     | 049226  | 4    | WASHER LOCK M5                             |
| K                                     | 051713  | 4    | WASHER FLAT M5                             |



EXPLODED VIEW:  
MOUNTING BASE 3.0L/3.9L C4  
DRAWING #: 0F2745

## EXPLODED VIEW: MOUNTING BASE 3.0L/3.9L C4


DRAWING #: 0F2745

GROUP C

APPLICABLE TO:

| ITEM | PART #     | QTY. | DESCRIPTION                       |
|------|------------|------|-----------------------------------|
| 1    | 0F2601     | 1    | ASSY MTG BASE (3.9L C4)           |
|      | 0F2601A    | 1    | ASSY MTG BASE (3.0L C4)           |
| 2    | 052860     | 4    | NUT FLANGED HEX M12-1.75          |
| 3    | 052251     | 4    | DAMPENER VIBRATION 40 BLUE        |
| 4    | 052257     | 4    | SPACER .49 X .62 X 1.87 PWD/R/ZNC |
| 5    | 052252     | 4    | DAMPENER VIBRATION                |
| 6    | 052259     | 4    | WASHER FLAT M12                   |
| 7    | 052891     | 4    | SCREW HHC M12-1.75 X 80 G8.8      |
| 8    | 0536210410 | 1    | ASSY WIRE 14.00"                  |
| 9    | 042909     | 1    | SCREW HHC M8-1.25 X 30 G8.8       |
| 10   | 047411     | 1    | SCREW HHC M6-1.0 X 16 G8.8        |
| 11   | 055414     | 1    | LUG SLDLSS #2-#8 X 17/64 CU       |
| 12   | 022447     | 1    | WASHER SHAKEPROOF INT 1/4         |
| 13   | 022097     | 1    | WASHER LOCK M6-1/4                |
| 14   | 022473     | 1    | WASHER FLAT M6-1/4 ZINC           |
| 15   | 049813     | 1    | NUT HEX M6 -1.0 G8 YEL CHR        |
| 16   | 022261     | 1    | WASHER SHAKEPROOF INT 3/8         |
| 17   | 0F2230     | 2    | SUPPORT ENGINE 3.9L LH & RH SD    |
|      | 0E8824     | 2    | STAMPING, ENG FOOT 3.0L FORD      |
| 18   | 045771     | 1    | NUT HEX M8-1.25 G8 CLEAR ZINC     |
| 19   | 049814     | 4    | SCREW HHC M10-1.5 X 25 G8.8       |
| 20   | 022302     | 5    | WASHER LOCK 7/16                  |
| 21   | 022131     | 4    | WASHER FLAT 3/8-M10 ZINC          |
| 22   | 065852     | 1    | SPRING CLIP HOLDER .37-.62        |
| 23   | 045764     | 1    | SCREW HHTT M4-0.7 X 8 BP          |
| 24   | 051755     | 1    | SCREW HHC M10-1.5 X 16 G8.8       |
| 25   | 022129     | 1    | WASHER LOCK M8-5/16               |
| 26   | 026204     | 1    | WASHER SHAKEPROOF INT 5/16        |
| 27   | 022145     | 1    | WASHER FLAT 5/16-M8 ZINC          |
| 28   | 0C2454     | 4    | SCREW THF M6-1X16 N WA Z/JS       |
| 29   | 0F3656     | 1    | SUPPORT CONTROL PANEL CPL C4      |


GROUP C



**EXPLODED VIEW: BATTERY****DRAWING #: 0F3639****GROUP C****APPLICABLE TO:**

| <b>ITEM</b> | <b>PART #</b> | <b>QTY.</b> | <b>DESCRIPTION</b>             |
|-------------|---------------|-------------|--------------------------------|
| 1           | 0F3408        | 1           | TRAY BATTERY                   |
| 2           | 0F3411        | 1           | STRAP BATTERY RETAINMENT       |
| 3           | 058208        | 1           | BATT 12VDC 24F 625             |
| 4           | 036833        | 1           | SCREW HHC 3/8-16 X 1 G8        |
| 5           | 022237        | 1           | WASHER LOCK 3/8                |
| 6           | 022131        | 1           | WASHER FLAT 3/8-M10 ZINC       |
| 7           | 050331A       | 1           | BATT POST COVER RED +          |
| 8           | 050331        | 1           | BATT POST COVER BLK -          |
| 9           | 03880400AA    | 1           | CABLE BATT RED #1 X 44.00      |
| 10          | 038805T       | 1           | CABLE BATT BLK #1 X 40.00      |
| 11          | 045771        | 1           | NUT HEX M8-1.25 G8 YEL CHR     |
| 12          | 022129        | 1           | WASHER LOCK M8-5/16            |
| 13          | 027482        | 2           | WASHER SHAKEPROOF EXT 5/16 STL |
| 14          | 075763        | 1           | BOOT BATTERY CABLE             |
| 15          | 0C2454        | 8           | SCREW THF M6-1 X 16 N WA Z/JS  |
| 16          | 0F3409        | 1           | SUPPORT BATTERY TRAY           |

# GROUP D



USED ON 3600 RPM ONLY.

NOTE: REMOVE COOLANT BYPASS HOSE. INSERT I/N 66 BY-PASS ORIFICE FROM INTAKE MANIFOLD END OF HOSE. USE I/N 67 HOSE CLAMP TO HOLD I/N 66 IN PLACE.

EXPLODED VIEW:  
ENG. COMMON PARTS 3.9L CHRYSLER C2/C4  
DRAWING #: 0F2743

**EXPLODED VIEW: ENG. COMMON PARTS 3.9L CHRYSLER C2/C4**  
**DRAWING #: 0F2743**


**GROUP D**

APPLICABLE TO:

| ITEM | PART #  | QTY. | DESCRIPTION                           |
|------|---------|------|---------------------------------------|
| 1    | 0E5048A | 1    | FLEXPLATE HSB 3.9L CHRYSLER (1800RPM) |
|      | 0F3903A | 1    | FLEX PLATE 2 POLE 3.9L CHRY (3600RPM) |
| 2    | 0F2982  | 1    | ENG ADAPTER MACH 3.9L HSB NSPS        |
| 3    | 0E6703  | 1    | COVER FLYWHEEL ACCESS                 |
| 4    | 0F3795  | REF  | ENGINE INSERTED VALVE 3.9L (3600 RPM) |
|      | 0E8336  | REF  | MAKE 3.9L CHRYSLER ENGINE (1800 RPM)  |
| 5    | 0E7841  | 2    | GASKET THERMOSTAT ADAPTOR             |
| 6    | 0E7254  | 1    | MACH THERM ADAPTOR 3.9L CHRY          |
| 7    | 0E7956  | 1    | BRACKET IGNITION COIL                 |
| 8    | 0E7953  | 1    | COIL IGNITION 3.9L CHRYSLER           |
| 9    | 047411  | 4    | SCREW HHC M6-1.0 X 16 G8.8            |
| 10   | 0E8615  | 6    | BOLT 7/16-20 X 7/8                    |
| 11   | 0E9868A | 1    | D.C. ALTERNATOR W/OUT PULLEY          |
| 12   | 054455  | 1    | ADP OIL DRN 1/2-20                    |
| 13   | 022097  | 7    | WASHER LOCK M6-1/4                    |
| 14   | 022473  | 10   | WASHER FLAT 1/4-M6 ZINC               |
| 15   | 049721  | 2    | SCREW HHC M6-1.0 X 35 G8.8 BLK        |

| ITEM | PART #  | QTY. | DESCRIPTION                                           |
|------|---------|------|-------------------------------------------------------|
| 16   | 049813  | 3    | NUT HEX M6 X 1.0 G8 YEL CHR                           |
| 17   | 036833  | 11   | SCREW HHC 3/8-16 X 1 G8                               |
| 18   | 022131  | 15   | WASHER FLAT 3/8-M10 ZINC                              |
| 19   | 022237  | 19   | WASHER LOCK 3/8                                       |
| 20   | 0E6729  | 1    | STARTER 12V                                           |
| 21   | 022129  | 19   | WASHER LOCK M8-5/16                                   |
| 22   | 049821  | 3    | SCREW SHC M8-1.25 X 30 G12.9                          |
| 23   | 043790  | 1    | BARBED EL 90 3/8 NPT X 3/8                            |
| 24   | 052677  | 1    | WASHER NYLON .50 X .87 X .06                          |
| 25   | 0F1444A | 1    | HEAT SHEILD L/H SIDE                                  |
| 26   | 0E9975  | 1    | CAP VINYL 1/4" ID X 1" DP BLK                         |
| 27   | 0F5114  | 1    | DECAL REFER TO OWNERS MANUAL                          |
| 28   | 0D2244M | 1    | ASSY MAGPICKUP (3/8-24 MALE)                          |
| 29   | 0E0992B | REF  | PLUG EXPANSION 21/32" O.D. (WATER PUMP) (QTY 1)       |
| 30   | 0E0992A | REF  | PLUG EXPANSION 14.1 O.D. (INJECTOR HOLE) (QTY 6)      |
| 31   | 0F5806  | 1    | SPACER FLEX PLATE 3.9L C4 CPL (3600 RPM)              |
|      | 0E8731  | 1    | PLATE FLEX DISK SPACER (1800 RPM)                     |
| 32   | 052625  | 2    | SCREW SHC M10-1.5 X 35 G12.9                          |
| 33   | 0E7855  | 1    | TENSIONER W/BACKET                                    |
| 34   | 0F2694A | 1    | PULLEY CRANKSHAFT (3600 RPM)                          |
|      | 0E7952  | 1    | PULLEY CRANKSHAFT 3.9L CRYSLR (1800 RPM)              |
| 35   | 035606  | 1    | SENSOR HI COOLANT SHUTDOWN                            |
| 36   | 0A8584  | 1    | SWITCH OIL PRESSURE 10 PSI 2 POL                      |
| 37   | 061012  | REF  | PLUG STD PIPE 1/8 SOCKET HEAD                         |
| 38   | 0F1444  | 1    | HEAT SHIELD R/H SIDE                                  |
| 39   | 050873A | REF  | PLUG PIPE 1/4 CSK W/ VIBRA SL                         |
| 40   | 031919  | REF  | PLUG STD PIPE 3/8 COUNTERSUNK                         |
| 41   | 022145  | 15   | WASHER FLAT 5/16-M8 ZINC                              |
| 42   | 030231  | 6    | SCREW HHC 5/16-18 X 1-1/2 G5 (3600 RPM)               |
|      | 030795  | 6    | SCREW HHC 5/16-18 X 1 G5 (1800 RPM)                   |
| 43   | 048031J | REF  | HOSE CLAMP BAND 5/8"                                  |
| 44   | 069860E | 1    | HOSE DRAIN ASSY 28"                                   |
| 45   | 0E7954  | 1    | CABLE IGN COIL 3.9L CHRYSLER                          |
| 46   | 057824  | 1    | CLAMP HOSE #16 .87-1.50 (3600 RPM)                    |
| 47   | 023645  | 5    | SCREW SHC 3/8-16 X 1.25 G8.8 Z                        |
| 48   | 022403  | 2    | SCREW HHC 5/16-18 X 2 G5                              |
| 49   | 0E7950  | 1    | TUBE DIPSTICK 3.9L CHRYSLER                           |
| 50   | 0E7951  | 1    | DIPSTICK OIL LEVEL 3.9L CHRYSLER                      |
| 51   | 0E8445  | 1    | BRACKET DIPSTICK TUBE                                 |
| 52   | 0E7415  | 1    | OIL FILTER 3.9L CHRYSLER                              |
| 53   | 042568  | 1    | SCREW HHC M6-1.0 X 20 G8.8                            |
| 54   | 0F3447  | 1    | BRKT L/H SIDE D.C. ALTERNATOR                         |
| 55   | 0F3446  | 1    | BRKT R/H SIDE D.C. ALTERNATOR                         |
| 56   | 0F3216C | 1    | PULLEY 132 OD DC ALTERNATOR (3600 RPM)                |
|      | 0F3216  | 1    | PULLEY 80 OD DC ALTERNATOR (1800 RPM)                 |
| 57   | 039253  | 1    | SCREW HHC M8-1.25 X 20 G8.8                           |
| 58   | 022241  | 1    | NUT HEX 3/8-16 STEEL                                  |
| 59   | 022746  | 1    | SCREW HHC 3/8-16 X 1-3/4 G5                           |
| 60   | 0F3641  | 1    | HARN ENG 3.9L 3600 RPM FLEX PNL (NOT SHOWN)(3600 RPM) |
|      | 0F4272  | 1    | HARN ENG 3.9L 1800 RPM FLEX PNL (NOT SHOWN)(1800 RPM) |
| 61   | 0F3217  | 1    | SPACER DC ALTERNATOR PULLEY                           |
| 62   | 0D3488H | 1    | SERPENTINE BELT (60.5")                               |
| 63   | 022532  | 1    | SCREW HHC 5/16-18 X 2-1/2 G5                          |
| 64   | 0F3844  | 6    | WASHER FLAT .45 X 1.00                                |
| 65   | 026925  | 1    | PLUG STD PIPE 3/8 STEEL SQ HD                         |
| 66   | 0F4110  | 1    | BYPASS ORIFICE 3.9L CHRYSLER (3600 RPM)               |
| 67   | 0F5454  | 1    | PLATE MAG PICK-UP ADAPTOR                             |
| 68   | 0F6027  | 2    | SHIELD HT RR (C4 3600 RPM ONLY) (BOTH SIDES)          |
| 69   | 0F6029  | 2    | SHIELD HT FRT (C4 3600 RPM ONLY) (BOTH SIDES)         |
| 70   | 045771  | 5    | NUT HEX M8-1.25 G8 CLEAR ZINC (C4 3600 RPM ONLY)      |
| 71   | 0F5928  | 6    | REFLEX WRAP 13MM X 153.3MM (C4 3600 RPM ONLY)         |
| 72   | 087173  | 1    | SCREW HHC M8-1.25 X 45 G8.8                           |
| 73   | 0F6480  | 1    | BRKT L/H SIDE DC ALTERNATOR                           |
| 74   | 0F6715  | 2    | SPACER .41 X .75 X .18 AL                             |
| 75   | 0E0561  | 1    | ASSY WATER LEVEL SENSOR C/E PL                        |
| 76   | 059057  | 1    | HOSE 3/4 ID SAE-30R2 (17" LG)                         |
| 77   | 057822  | 1    | CLAMP HOSE #8 .53-1.00                                |
| 78   | 057795A | 1    | BARBED EL 90 3/4 PLASTIC                              |
| 79   | 057796  | 1    | GROMMET                                               |

# GROUP D



EXPLODED VIEW:  
C4 COOLING SYTEM & FAN DRIVE  
DRAWING #: 0F2744

# EXPLODED VIEW: C4 COOLING SYTEM & FAN DRIVE DRAWING #: 0F2744

## GROUP D


APPLICABLE TO:

| ITEM | PART #  | QTY.     | DESCRIPTION                           |
|------|---------|----------|---------------------------------------|
| 1    | 0F2688  | 1        | WELDMENT RADIATOR SUPPORT C4          |
| 2    | 0F2608  | 1        | RADIATOR 598 X 568 X 49,CPL RH (3.9L) |
|      | 0F2608A | 1        | RADIATOR 598 X 568 X 49,CPL LH (3.0L) |
| 3    | 0F5263  | 1        | V-BELT 31/64" X 57-3/8" (3.0L & 3.9L) |
| 4    | 046526  | 5        | WASHER LOCK M10                       |
| 5    | 059981  | 4        | SCREW HHC M10-1.5 X 30 G10.9          |
| 6    | 022145  | 6 (REF.) | WASHER FLAT 5/16-M8 ZINC (3.9L)       |
|      | 022131  | 4        | WASHER FLAT 3/8-M10 ZINC (3.0L)       |
| 7    | 0F5050A | 1        | SHIELD RADIATOR C4                    |
| 8    | 042568  | 8        | SCREW HHC M6-1.0 X 20 G8.8            |
| 9    | 0F2573  | 1        | PULLEY FAN V-GROOVE 9"                |

BEARING PRESS NOTE:  
APPLY LOCTITE 620 BEARING RETAINMENT  
COMPOUND TO BEARING SURFACE ON ITEM 37  
PRIOR TO PRESSING ITEM 28 ONTO ITEM 37.  
ALSO APPLY LOCTITE 620 BEARING RETAINMENT  
COMPOUND TO THE OUTSIDE OF 28 PRIOR TO  
INSTALLING ITEM 28 INTO ITEM 38.

| ITEM   | PART #      | QTY.     | DESCRIPTION                         |
|--------|-------------|----------|-------------------------------------|
| 10     | 0F4011      | 1        | FAN COOL 22" DIA 10 BLADE LH        |
| 11     | 0G56820ST03 | 1        | FLAT TENSIONER ARM                  |
| 12     | 0G2990      | 1        | SHOULDER BOLT 3/8 X 1/2"            |
| 13     | 0F2862      | 1        | SPRING TENSION CPL                  |
| 14     | 0F2560      | 1        | PULLEY V-BELT 4" FLANGED            |
| 15     | 022131      | 4        | WASHER FLAT 3/8-M10 ZINC            |
| 16     | 022129      | 6 (REF.) | WASHER LOCK M8-5/16 (3.9L)          |
|        | 046526      | 4        | WASHER LOCK M10 (3.0L)              |
| 17     | 030231      | 6 (REF)  | SCREW HHC 5/16-18 X 1-1/2 G5 (3.9L) |
|        | 052243      | 4        | SCREW HHC M10-1.5 X 60 G8.8 (3.0L)  |
| 18     | 0F2561      | 1        | HUB FLEX PLATE                      |
| 19     | 0C8145      | 8        | WASHER FLEX (THIN)                  |
| 21     | 0C7043      | 12       | DISK FLEX                           |
| 22     | 0F2694A     | 1 (REF.) | PULLEY CRANKSHAFT (3.9L)            |
|        | 0F2622      | 1        | ADAPTER CRANKSHAFT (3.0L)           |
| 23     | 022473      | 16       | WASHER FLAT 1/4-M6 ZINC             |
| 24     | 0C8146      | 4        | SCREW HHC 5/16-24 X 1.124           |
| 25     | 022097      | 16       | WASHER LOCK M6-1/4                  |
| 26     | 076749      | 1        | TANK COOLANT RECOVERY               |
| 27     | 048031C     | 1        | CLAMP HOSE BAND 1/4                 |
| 28     | 031971      | 1        | BEARING #6205 2NSE C3 E SRI2 S      |
| 29     | 0F4032      | 1        | PULLEY 5.5" DIA MACHINED            |
| 30     | 042911      | 1        | SCREW HHC M10-1.5 X 30 G8.8         |
| 31     | 0F2872      | 1        | SCREW HHC 1/2-13 X 2" G8            |
| 32     | 022304      | 2        | WASHER FLAT 1/2 ZINC                |
| 33     | 022195      | 1        | WASHER LOCK 1/2                     |
| 34     | 022196      | 1        | NUT HEX 1/2-13 STEEL                |
| 35     | 0F8651      | 9        | SCREW HHFC M8-1.25 X 20 W/M6        |
| 36     | 070015      | 1        | NUT HEX LOCK 5/16-18 NY INS SS      |
| 37     | 0F4026A     | 1        | SHAFT FAN DRIVE C4                  |
| 38     | 0F2461      | 1        | RETAINER BEARING                    |
| 39     | 022145      | 1        | WASHER FLAT 5/16-M8 ZINC            |
| 40     | 022129      | 10       | WASHER LOCK M8-5/16                 |
| 41     | 039414      | 1        | SCREW HHC M8-1.25 X 35 G8.8         |
| 42     | 082774      | 1        | KEY WOODRUFF 4 X 19D                |
| 43     | 0F2691      | 1        | HOSE LOWER RADIATOR, 3.9L C4        |
|        | 0F2812      | 1        | HOSE LOWER RADIATOR, 3.0L C4        |
| 44     | 0F2795      | 1        | HOSE UPPER RADIATOR, 3.9L C4        |
|        | 0F2813      | 1        | HOSE UPPER RADIATOR, 3.0L C4        |
| 45     | 049813      | 8        | NUT HEX M6 X 1.0 G8 YEL CHR         |
| 46     | 0F2835      | 1        | INNER DISCHARGE DUCT, C4            |
| 48     | 0C2454      | 6        | SCREW THF M6-1 X 16 N WA Z/JS       |
| 52     | 0F3072      | 8        | INSULATION RETAINMENT HANGER        |
| 54     | 0F3760B     | 1        | INSULATION FRONT INNER DUCT         |
| 55     | 078115      | 8        | WASHER SELF LOCKING DOME            |
| 56     | 0F3890      | 4        | RETAINER INSULATION (450)           |
| 57     | 0F4051D     | 2        | INSULATION INNER DUCT               |
| 58     | 035685      | 4        | CLAMP HOSE #28 1.32-2.25            |
| 59     | 052250      | 2        | TAPE FOAM 1 X 1 (26.75" LG)         |
| 60     | 055596      | 1        | BARBED STR 3/8 NPT X 3/8            |
| 61     | 0C7649      | 1        | CLAMP HOSE .38-.87                  |
| 62     | 069860E     | 1        | HOSE DRAIN ASSY 28"                 |
| (1) 63 | 069811      | REF.     | CAP HEX 1/4 NPT BRASS               |
| 64     | 065852      | 1        | SPRING CLIP HOLDER .37-.62          |
| 65     | 045764      | 1        | SCREW HHTT M4-0.7 X 8 BP            |
| 66     | 080713      | 1        | BRACKET COOLANT TANK                |
| 67     | 090283      | 1        | CAP RADIATOR 13 PSI                 |
| 68     | 0C8566      | 8        | SCREW HHFC M6-1.0 X 20 G8.8         |
| 69     | 052644      | 1        | SPACER .5 X 1.5 X .25 STL/ZINC      |
| 70     | 0E2507      | 1        | PROBE COOLANT LEVEL 3/8 NPTF        |
| 71     | 0F9483      | 1        | ASSY PCB WATERLEVEL SNSR INTFC      |
| 72     | 0F8657      | 1        | HARNESS WATER LEVEL EXTENSION       |
| 73     | 0G4376      | 1        | WASHER BELLEVILLE .75X.38X.028      |
| 74     | 0G56830ST03 | 1        | BENT 90 TENSIONER ARM SUPPORT       |
| 75     | 022145      | 2        | WASHER FLAT 5/16-M8 ZINC            |
| 76     | 051698      | 1        | SCREW HHC M8-1.25 X 75 C8.8         |
| 77     | 049820      | 1        | NUT HEX LOCK M8-1.25 NY INS         |
| 78     | 0G6151      | 1        | EYEBOLT 3/8-16 X 3.5" TURNED        |

(1) ITEM 63 IS INCLUDED WITH ITEM 62.




EXPLODED VIEW: AIR CLEANER 3.9L CHRYSLER C4  
DRAWING #: 0F2748

GROUP D

APPLICABLE TO:

| ITEM | PART #  | QTY. | DESCRIPTION                |
|------|---------|------|----------------------------|
| 1    | 0F4271  | 1    | BASE PLATE, AIR CLEANER    |
| 2    | 0F5418  | 1    | ELEMENT AIR FILTER         |
| 3    | 0F4268  | 1    | TOP PLATE, VENTURI         |
| 4    | 0F4270  | 1    | HOLD DOWN AIR CLEANER      |
| 5    | 0A4632A | 1    | PLATE AIR CLEANER TOP      |
| 6    | 037561  | 1    | NUT WING 1/4-20 NYLK       |
| 7    | 047411  | 4    | SCREW HHC M6-1.0 X 16 G8.8 |
| 8    | 022097  | 4    | WASHER LOCK M6-1/4         |
| 10   | 0F4269  | 1    | GASKET MIXER BODY          |

GROUP D



EXPLODED VIEW:  
MUFFLER 3.9L CPL EXHAUST C4  
DRAWING #: 0F2751

EXPLODED VIEW: MUFFLER 3.9L CPL EXHAUST C4  
DRAWING #: 0F2751


GROUP D

APPLICABLE TO:

| ITEM | PART #  | QTY. | DESCRIPTION                     |
|------|---------|------|---------------------------------|
| 1    | 0F6504A | 1    | PIPE R/H SIDE MUFFLER SS        |
| 2    | 0F3127A | 1    | PIPE L/H SIDE 3.9L CPL SS       |
| 3    | 0F4505  | REF  | GLASS PACK 23.5" LG 2.5" IN/OUT |
| 4    | 0F2981  | 1    | MFLR 7" X 9" (2) 2" IN/2.5" OUT |
| 5    | 0F2962  | 1    | MUFFLER STRAP                   |
| 6    | 0F2830  | 1    | MUFFLER BRACKET STIFFENER       |
| 7    | 047411  | 2    | SCREW HHC M6-1.0 X 16 G8.8      |
| 8    | 022097  | 2    | WASHER LOCK M6-1/4              |
| 9    | 022473  | 2    | WASHER FLAT 1/4-M6 ZINC         |
| 10   | 080762  | 1    | BOLT U 3/8-16 X 2.62            |
| 11   | 0D9832  | 4    | SCREW HHC M12-1.75 X 75 SS      |
| 12   | 087171  | 8    | WASHER FLAT 1/2 SS              |
| 13   | 083215  | 4    | WASHER LOCK 1/2 SS              |
| 14   | 051548  | 8    | NUT HEX M12-1.75 G8 SS          |
| 15   | 0F3794  | 1    | EXHAUST BLANKET LH 600MM LONG   |
| 16   | 0F3794B | 1    | EXHAUST BLANKET RH 700MM LONG   |
| 17   | 0E8816  | 1    | EXHAUST FLANGE 2" PIPE          |
| 18   | 0F4462  | REF  | RAIN CAP ALUM FOR 2-1/2" PIPE   |
| 19   | 0C2454  | REF  | SCREW THF M6-1 X 16 N WA Z/JS   |
| 20   | 0F4367  | REF  | HEAT SHIELD EXHAUST STACK       |
| 21   | 0F4368  | REF  | CAP HEAT SHIELD EXHAUST STACK   |
| 22   | 036797  | 4    | BOLT U 5/16-18 X 2.25           |
| 23   | 024114  | 8    | NUT HEX 5/16-24 STEEL           |
| 24   | 022129  | 8    | WASHER LOCK M8-5/16             |
| 25   | 0F5078A | 1    | PIPE, L/H SIDE MUFFLER ST/ST    |
| 26   | 0F2808A | 1    | EXHAUST OUTLET PIPE CPL         |
| 27   | 080762  | REF  | BOLT U 3/8-16 X 2.62            |
| 28   | 0F3133A | 1    | PIPE, R/H SIDE 3.9L CPL S.S.    |

\* PARTS INCLUDED IN 0F6332 KIT, GLASS PACK SHIP LOOSE.

# GROUP E



EXPLODED VIEW:  
FUEL NAT. GAS & LP VAPOR 3.9L 2 POLE  
DRAWING #: 0F2749

## EXPLODED VIEW: FUEL NAT. GAS &amp; LP VAPOR 3.9L 2 POLE


DRAWING #: 0F2749

GROUP E

APPLICABLE TO:

| ITEM | PART #  | QTY. | DESCRIPTION                                   |
|------|---------|------|-----------------------------------------------|
| 1    | 033212  | 4    | SCREW HHC 5/16-18 X 1-1/4 G5                  |
| 2    | 065908  | 1    | SUPPORT NAT GAS SOLENOID                      |
| 3    | 0F6261E | 1    | REGULATOR ASSEMBLY NATURAL GAS                |
|      | 0F6261F | 1    | REGULATOR ASSEMBLY LP VAPOR                   |
| 4    | 039253  | 2    | SCREW HHC M8-1.25 X 20 G8.8                   |
| 5    | 022145  | 2    | WASHER FLAT 5/16-M8 ZINC                      |
| 6    | 022129  | 6    | WASHER LOCK M8-5/16                           |
| 7    | 045771  | 2    | NUT HEX M8-1.25 G8 CLEAR ZINC                 |
| 8    | 064346  | 1    | PIPE TEE 1-1/4 NPT                            |
| 9    | 0A8064  | 2    | BSHG RDCR HEX 1-1/4-3/4                       |
| 10   | 030131  | 1    | ELBOW 90D 1-1/4 NPT                           |
| 11   | 088963  | 1    | NIPPLE PIPE 1.25 NPT X 5.5 BL IRN             |
| 12   | 026915  | 2    | NIPPLE CLOSE 3/4 X 1.375                      |
| 13   | 057823  | 4    | CLAMP HOSE #10 .56-1.06                       |
| 14   | 059057  | 2    | HOSE 3/4 ID SAE-30R2 (45" LG)                 |
| 15   | 064945  | 1    | GASKET CARB ADAPTOR                           |
| 16   | 0D1509  | 1    | DECAL INLET PRESSURE                          |
| 17   | 050279  | 1    | DECAL FUEL INLET NG (NATURAL GAS APPLICATION) |
|      | 050280  | 1    | DECAL FUEL INLET LPG (LP VAPOR APPLICATION)   |
| 18   | 0E7839  | 1    | MACHINING CARBURETOR ADAPTOR                  |
| 19   | 0E6586  | 1    | GASKET BOSCH 32 & 40                          |
| 20   | 0E4394  | 1    | ACTUATOR BOSCH 40 GOVERNOR                    |
| 21   | 0F3857  | 1    | REDUCER RUBBER 3.0"-2.00"                     |
| 22   | 0F3885  | 1    | MIXER 40/60MM ACTUATOR ASSY                   |
| 23   | 0G3167  | 2    | O-RING 2-3/4 X 3/32 X 2-15/16                 |
| 24   | 0F3691B | 1    | VENTURI THROTTLE 36MM                         |
| 25   | 042561  | 1    | CLAMP HOSE #36 1.88-2.75                      |
| 26   | 0A2038  | 2    | WASHER FLAT 3/8 ZINC                          |
| 27   | 061012  | 1    | PLUG STD PIPE 1/8 SOCKET HEAD                 |
| 28   | 046580  | 4    | SCREW SHC M6-1.0 X 45 G12.9                   |
| 29   | 039294  | 1    | CLAMP HOSE #44 2.31-3.25                      |
| 30   | 022097  | 4    | WASHER LOCK M6-1/4                            |
| 31   | 047290  | 1    | HOSE 3/8 ID SINGLE BRAID (42" LG)             |
| 32   | 040173  | 2    | CLAMP HOSE #5.5 .62-.62                       |
| 33   | 039130  | 1    | NIPPLE CLOSE 1.25 NPT X 1.625                 |
| 34   | 0F6279  | 1    | HARNESS FUEL JUMPER DUAL REG                  |

## GROUP F



**EXPLODED VIEW:  
ENCLOSURE C4  
DRAWING #: 0F2750**

**EXPLODED VIEW: ENCLOSURE C4**  
**DRAWING #: 0F2750**

**GROUP F**

APPLICABLE TO:

| ITEM   | PART #     | QTY.     | DESCRIPTION                       |
|--------|------------|----------|-----------------------------------|
| (2) 1  | 0F5859     | 1        | REAR WRAP C4                      |
| (2) 2  | 0F5855     | 2        | DOOR C4                           |
| (2) 3  | 0F5858     | 2        | DISCHARGE DUCT LH & RH SIDE C4    |
| (2) 4  | 0F5856     | 2        | FRONT CORNERS C4                  |
| (2) 5  | 0F5857     | 1        | DISCHARGE CENTER DUCT C4          |
| (2) 6  | 0F5854     | 1        | ROOF C4 ALUM                      |
| 11     | 0F8869D    | 1        | KEY VISE-ACTION LATCH SLOT CIR    |
| 12     | 0C2454     | 75       | SCREW THF M6-1 X 16 N WA Z/JS     |
| (1) 13 | 077992     | 21       | NUT HEX LOCK M6-1.0 SS NY INS     |
| 14     | 087233     | 2        | RIVET POP .1875 X .450 SS         |
| 15     | 0E3257     | 4        | SCREW HWHTF M6-1.0 X 16           |
| 16     | 049813     | 2        | NUT HEX M6 X 1.0 G8 YEL CHR       |
| 17     | 022447     | 2        | WASHER SHAKEPROOF INT 1/4         |
| 18     | 0912970094 | 2        | ASSY WIRE 14AWG 34.8" GRN/YEL     |
| 19     | 0F2835     | 1 (REF.) | INNER DISCHARGE DUCT, C4          |
| 20     | 042568     | 2        | SCREW HHC M6-1.0 X 20 G8.8        |
| 21     | 0F2786     | 3        | SPLITTER C4                       |
| 22     | 0F2785     | 1        | SPLITTER LOWER C4                 |
| 23     | 0F3185     | 1        | STRINGER SPLITTER C3              |
| 24     | 0F2787     | 2        | SUPPORT SLITTER C4                |
| 25     | 0F3890B    | 8        | RETAINER INSULATION (820)         |
| 26     | 0C2634A    | 1        | ASSEMBLY COVER ACCESS             |
| 27     | 022473     | 3        | WASHER FLAT 1/4-M6 ZINC           |
| 28     | 022097     | 1        | WASHER LOCK M6-1/4                |
| 29     | 022127     | 1        | NUT HEX 1/4-20 STEEL              |
| 30     | 0F3072     | 10       | INSULATION RETAINMENT HANGER      |
| 31     | 078115     | 46       | WASHER SELF LOCKING DOME #4-40    |
| 32     | 0F3760K    | 3        | INSULATION SPLITTER               |
| 33     | 0F3760E    | 3        | INSULATION LOWER SPLITTER         |
| 34     | 0F5048D    | 4        | WISE-ACTION LATCH SLOTTED CIR     |
| 35     | 0E5968     | 1        | GASKET EXTRUDED TRIM (374.64" LG) |
| 36     | 0F3760J    | 1        | INSULATION DISCHARGE FRONT        |
| 37     | 0F3890A    | 9        | RETAINER INSULATION (740)         |
| 38     | 0F3890     | 6        | RETAINER INSULATION (450)         |
| 39     | 0F3760H    | 1        | INSULATION DISCHARGE TOP          |
| 40     | 0F3760F    | 1        | INSULATION ROOF TOP               |
| 41     | 0F5049     | 4        | TAB PULL                          |
| 42     | 0F3760L    | 1        | INSULATION LOWER SPLITTER         |
| 43     | 0F3760C    | 2        | INSULATION DOOR                   |
| 44     | 0F3760A    | 1        | INSULATION REAR WRAP              |
| 45     | 0F3760     | 2        | INSULATION CORNER POST            |
| 46     | 0F3760D    | 2        | INSULATION DISCHARGE SIDE         |
| 47     | 078115A    | 10       | WASHER SELF LOCKING DOME #8-32    |

(1) ALUMINUM ENCLOSURE NOTE: ALL ENCLOSURE PANELS THAT FASTEN TO THE BASE FRAME MUST BE SECURED USING ITEM 12 & 15 THREAD FORMING FASTENER AND ITEM 13 LOCK NUT. LOCK NUT IS TO BE INSTALLED AFTER THREAD FORMING FASTENER HAS PENETRATED THROUGH EXTRUSIONS IN ENCLOSURE PANELS. ALL ROOF PANELS ARE TO BE SECURED IN THE SAME MANNER.

(2) I/N'S 1 THRU 6, REFER TO CHART BELOW FOR ENCLOSURE COLOR & MATERIAL TYPE.

| SUFFIX 1 (MATL.)                                                                                    | SUFFIX 2 (COLOR) |
|-----------------------------------------------------------------------------------------------------|------------------|
| AL (ALUMINUM)                                                                                       | 01 (TAN)         |
|                                                                                                     | 03 (BLACK)       |
|                                                                                                     | 05 (WHITE)       |
|                                                                                                     | 07 (G-FORCE)     |
|                                                                                                     | 08 (TELECOM)     |
| ST (STEEL)                                                                                          | 09 (CRAFTSMAN)   |
|                                                                                                     | OR (CUSTOM)      |
| GENERIC EXAMPLE: SUFFIX 1 <input type="text"/> SUFFIX 2 <input type="text"/><br><b>0F19870AL 01</b> |                  |




















## CONTROL PANEL LEGEND

AVR - AUTOMATIC VOLTAGE REGULATOR  
 BCH - BATTERY CHARGER  
 BR1 - DIODE (FIELD BOOST)  
 CB2 - CIRCUIT BREAKER (EXCITATION)  
 F1 - FUSE, BAT. POWER (15A ATO TYPE)  
 J2 - CONNECTOR 2 (ON PCB)  
 R4 - FIELD BOOST RESISTOR  
 RL1 - RELAY 1 (START RELAY)  
 RL2 - (RELAY 2 (ENGINE RUN)  
 SCR - SCR BRIDGE MODULE W/PCB  
 SW1 - AUTO/OFF/MANUAL SWITCH  
 SW2 - SET EXERCISER SWITCH  
 TB - TERMINAL BLOCK  
 TR1 - TRANSFORMER (6VA UTIL/16 VAC)

NOTE: ALL WIRES ARE  
 18 AWG UL LISTED UNLESS  
 OTHERWISE NOTED AS SHOWN:

SIZE  
 (AWG)  
 18

## CUSTOMER CONNECTIONS



SINGLE-PHASE STATOR SHOWN.  
 FOR 3-PHASE SEE DWG. OF6839.

## WIRING - DIAGRAM

3.9L 70kW 2P

DRAWING #: 0F3179


## CUSTOMER CONNECTION

### & ALTERNATOR LEGEND:

BA - BRUSH ASSEMBLY (GENERATOR)  
 ICT - INTERCONNECT TERMINAL BLOCK  
 MCB - MAINLINE CIRCUIT BREAKER  
 NB - NEUTRAL BLOCK  
 UCT - UTILITY CONNECT TERMINAL BLOCK

### ENGINE WIRING LEGEND

AFS - AIR/FUEL SOLENOID  
 ALT - D.C. CHARGE ALTERNATOR  
 BAT - 12VDC BATTERY  
 CC - STARTER CONTACTOR  
 DEG - DRIVER ELEC. GOVERNOR  
 DIST - DISTRIBUTOR  
 FS - FUEL SOLENOID  
 FS2 - AUX. FUEL SOLENOID  
 GND - GROUND  
 GOV - ELEC. GOVERNOR ACTUATOR  
 HCT - HIGH COOLANT TEMP SWITCH  
 IC - IGNITION COIL  
 J1 - CONNECTOR 1 (ON PCB)  
 LFP - LOW FUEL PRESSURE SWITCH  
 LOS - LOW OIL PRESSURE SWITCH  
 MP1 - MAGNETIC PICKUP  
 O2 - OXYGEN SENSOR  
 SM - STARTER MOTOR  
 WLS - COOLANT LEVEL SWITCH




WIRING - DIAGRAM

3.9L 70kW 2P


DRAWING #: 0F3179

## CONTROL PANEL LEGEND

AVR - AUTOMATIC VOLTAGE REGULATOR  
 BCH - BATTERY CHARGER  
 BR1 - BRIDGE RECTIFIER  
 CB2 - CIRCUIT BREAKER (EXCITATION)  
 F1 - FUSE, BAT POWER (15A ATO TYPE)  
 J2 - CONNECTOR 2 (ON PCB)  
 MOV - VARISTOR 680V  
 R1,2 - 820 OHM RES  
 R3 - 470 OHM RES  
 R4 - FIELD BOOST RESISTOR  
 RL1 - RELAY 1 (START RELAY)  
 RL2 - RELAY 2 (ENGINE RUN)  
 SCR - SCR BRIDGE  
 SW1 - AUTO/OFF/MANUAL SWITCH  
 SW2 - SET EXERCISER SWITCH  
 TR1 - TRANSFORMER (6VA UTIL/16 VAC)



**SCHEMATIC - DIAGRAM**



**SCHEMATIC - DIAGRAM**

# EXPLODED VIEW: INSTALL DWG 3.0L 50KW & 3.9L 70KW

DRAWING #: 0F6288


GROUP G

APPLICABLE TO:

| WEIGHT DATA                                                       |
|-------------------------------------------------------------------|
| 3.0L 50KW - 721KG (1590 LB)                                       |
| 3.9L 70KW - 800KG (1764 LB)                                       |
| WOODEN SHIPPING SKIDS INCREASE<br>OVERALL WEIGHT - 79 KG (175 LB) |

## NOTES:

- 1) MINIMUM RECOMMENDED CONCRETE PAD SIZE: 1460 (57.5') WIDE X 2860 (112.6') LONG. REFERENCE INSTALLATION GUIDE P/N OF5298 FOR CONCRETE PAD REINFORCEMENT AND PAD DEPTH GUIDELINES.
- 2) GENERATOR MUST BE LOCATED A MINIMUM DISTANCE OF 5 FEET FROM A WALL OR FENCE. ALLOW A 5 FOOT MINIMUM PERIMETER OF OPEN SPACE AROUND THE ENTIRE GENERATOR. REFERENCE INSTALLATION GUIDE P/N OF5298 FOR OUTDOOR ROOF MOUNTED APPLICATIONS.
- 3) CIRCUIT BREAKER INFORMATION:  
SEE SPECIFICATION SHEET WITHIN OWNERS MANUAL.
- 4) INSIDE STUB-UP AREA FOR AC LOAD LEAD CONDUIT CONNECTION, NEUTRAL CONNECTION, BATTERY CHARGER 120 VOLT AC ( .5 AMP MAX.) CONNECTION, AND ACCESS TO TRANSFER SWITCH CONTROL WIRES, REMOVE FRONT COVER FOR ACCESS.
- 4A) FIELD CUT HOLE IS ONLY REQUIRED FOR MOUNTING OF GENERATOR ON AN EXISTING PAD.
- 5) REFERENCE OWNERS MANUAL FOR LIFTING WARNINGS.
- 6) REMOVE EITHER LEFT OR RIGHT HAND SIDE PANEL TO ACCESS EXHAUST MUFFLER AND FAN BELT.




## EXPLODED VIEW: INSTALL DWG 3.0L 50KW &amp; 3.9L 70KW


DRAWING #: 0F6288

GROUP G


APPLICABLE TO:



|      |   |                      |
|------|---|----------------------|
| AR   | = | ALTERNATOR ROTOR     |
| AS   | = | ALTERNATOR STATOR    |
| MLCB | = | MAIN CIRCUIT BREAKER |
| NB   | = | NEUTRAL BLOCK        |



|      |   |                      |
|------|---|----------------------|
| AR   | = | ALTERNATOR ROTOR     |
| AS   | = | ALTERNATOR STATOR    |
| MLCB | = | MAIN CIRCUIT BREAKER |
| NB   | = | NEUTRAL BLOCK        |


$$\left. \begin{array}{l} E1 \text{ TO } E2 \\ E2 \text{ TO } E3 \\ E1 \text{ TO } E3 \end{array} \right\} *208\text{VAC}$$

E1, E2, OR E3 TO NB = \* 120VAC


\*NOTE: THE 8th DIGIT OF THE MODEL NUMBER SPECIFIES OUTPUT VOLTAGE

"G" = 120/208VAC

## OPTION 3 - THREE PHASE, R-SERIES CONTROL PANEL, 6-WIRE 277/480V

### LEGEND

AR = ALTERNATOR ROTOR  
 AS = ALTERNATOR STATOR  
 MLCB = MAIN CIRCUIT BREAKER  
 NB = NEUTRAL BLOCK



GENERATOR OUTPUT  
 CUSTOMER CONNECTION

E1 TO E2  
 E2 TO E3 } \*480VAC  
 E1 TO E3 }

E1, E2, OR E3 TO NB = \* 277VAC


\*NOTE: THE 8th DIGIT OF THE MODEL NUMBER SPECIFIES OUTPUT VOLTAGE

"K" = 227/480VAC

## OPTION 4 - THREE PHASE, R-SERIES CONTROL PANEL, 12-WIRE 120/208

### LEGEND

AR = ALTERNATOR ROTOR  
AS = ALTERNATOR STATOR  
MLCB = MAIN CIRCUIT BREAKER  
NB = NEUTRAL BLOCK



GENERATOR OUTPUT  
CUSTOMER CONNECTION


E1 TO E2 }  
E2 TO E3 } \*208VAC  
E1 TO E3 }

E1, E2, OR E3 TO NB = \* 120VAC

\*NOTE: THE 8th DIGIT OF THE MODEL NUMBER SPECIFIES OUTPUT VOLTAGE

"G" = 120/208VAC

|      |   |                      |
|------|---|----------------------|
| AR   | = | ALTERNATOR ROTOR     |
| AS   | = | ALTERNATOR STATOR    |
| MLCB | = | MAIN CIRCUIT BREAKER |
| NB   | = | NEUTRAL BLOCK        |



E1 TO E2  
E2 TO E3  
E1 TO E3 } \*240VAC

E1, OR E3 TO NB = \* 120VAC

\*NOTE: THE 8th DIGIT OF THE MODEL NUMBER SPECIFIES OUTPUT VOLTAGE  
"J" = 120/240VAC

THIS PAGE IS LEFT INTENTIONALLY BLANK



## Standby Generator Sets Warranty



### GENERAC POWER SYSTEMS STANDARD LIMITED WARRANTY FOR COMMERCIAL PRODUCT 50kW AND ABOVE

For a period of two (2) years from the date of sale, Generac Power Systems, Inc. will, at its option, repair or replace any part(s) which, upon examination, inspection, and testing by Generac Power Systems or an Authorized/Certified Generac Power Systems Dealer, or branch thereof, is found to be defective under normal use and service, in accordance with the warranty schedule set forth below. Any equipment that the purchaser/owner claims to be defective must be examined by the nearest Authorized/ Certified Generac Power Systems Dealer, or branch thereof. This warranty applies only to Generac Power Systems Generators used in "Standby" applications, as Generac Power Systems, Inc. has defined Standby, provided said generator has been properly installed and inspected on-site by appropriate personnel. Scheduled maintenance, as outlined by the generator owner's manual, is highly recommended. This should be performed by an Authorized/ Certified Generac Power Systems Dealer, or branch thereof. This will verify service has been performed on the unit throughout the warranty period.

#### WARRANTY SCHEDULE

**YEAR ONE** — Limited comprehensive coverage on mileage, labor, and parts listed.

- - ALL COMPONENTS

**YEAR TWO** — Limited comprehensive coverage on parts listed.

- - ALL COMPONENTS

\*Start-up and/or On-line Registration, or Registration Card, along with Proof of Purchase, must be performed and/or sent in.

#### Guidelines:

- Any and all warranty repairs and/or concerns, must be performed and/or addressed by an Authorized/Certified Generac Power Systems Dealer, or branch thereof.
- A Generac Power Systems, Inc. Transfer Switch is highly recommended to be used in conjunction with the genset. If a Non - Generac Power Systems, Inc. Transfer Switch is substituted for use and directly causes damage to the genset, no warranty coverage shall apply.
- All warranty expense allowances are subject to the conditions defined in Generac Power Systems Warranty, Policies, and Procedures Flat Rate Manual.
- Units that have been resold are not covered under the Generac Power Systems Warranty, as this Warranty is not transferable.
- Unit enclosure is only covered against rust or corrosion the first year of the warranty provision.
- Use of Non-Generac replacement part(s) will void the warranty in its entirety.
- Engine coolant heaters (block-heaters), heater controls and circulating pumps are only covered during the first year of the warranty provision (If applicable).

#### THIS WARRANTY SHALL NOT APPLY TO THE FOLLOWING:

1. Any unit built/manufactured prior to March 1, 2005.
2. Costs of normal maintenance (i.e. tune-ups, associated part(s), adjustments, loose/leaking clamps, installation and start-up).
3. Any failure caused by contaminated fuels, oils, coolants/antifreeze or lack of proper fuels, oils or coolants/antifreeze.
4. Units sold, rated or used for "Prime Power", "Trailer Mounted" or "Rental Unit" applications as Generac Power Systems have defined Prime Power, Trailer Mounted or Rental Unit. Contact a Generac Power Systems Distributor for Prime Power, Trailer Mounted or Rental Unit definition and warranty.
5. Units used for prime power in place of existing utility power where utility is present or in place of utility power where utility power service does not normally exist.
6. Failures caused by any external cause or act of God such as, but not limited to, collision, fire, theft, freezing, vandalism, riot or wars, lightning, earthquake, windstorm, hail, volcanic eruption, water or flood, tornado, hurricane, terrorist acts or nuclear holocaust.
7. Products that are modified or altered in a manner not authorized by Generac Power Systems in writing.
8. Failures due, but not limited to, normal wear and tear, accident, misuse, abuse, negligence, or improper installation or sizing.
9. Any incidental, consequential or indirect damages caused by defects in materials or workmanship, or any delay in repair or replacement of the defective part(s).
10. Failure due to misapplication, misrepresentation, or bi-fuel conversion.
11. Telephone, facsimile, cell phone, satellite, internet, or any other communication expenses.
12. Rental equipment used while warranty repairs are being performed (i.e. rental generators, cranes, etc.).
13. Overtime, holiday, or emergency labor.
14. Planes, ferries, railroad, busses, helicopters, snowmobiles, snow-cats, off-road vehicle or any other mode of transportation deemed abnormal.
15. Any and all expenses incurred investigating performance complaints unless defective Generac materials and/or workmanship were the direct cause of the problem.
16. Starting batteries, fuses, light bulbs, engine fluids, and overnight freight cost for replacement part(s).

THIS WARRANTY IS IN PLACE OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, SPECIFICALLY, GENERAC POWER SYSTEMS MAKES NO OTHER WARRANTIES AS TO THE MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to purchaser/owner.

GENERAC POWER SYSTEMS ONLY LIABILITY SHALL BE THE REPAIR OR REPLACEMENT OF PART(S) AS STATED ABOVE. IN NO EVENT SHALL GENERAC POWER SYSTEMS BE LIABLE FOR ANY INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF SUCH DAMAGES ARE A DIRECT RESULT OF GENERAC POWER SYSTEMS, INC. NEGLIGENCE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to purchaser/owner. Purchaser/owner agrees to make no claims against Generac Power Systems, Inc. based on negligence. This warranty gives purchaser/owner specific legal rights. Purchaser/owner also may have other rights that vary from state to state

**Generac Power Systems, Inc. • P.O. Box 8 • Waukesha, WI 53187**  
**Ph: (262) 544-4811 • Fax: (262) 544-4851**

Bulletin 0171370SVE / Rev. A 08.08 / Printed in U.S.A.

Printed in U.S.A.