

Owner's Manual

Stationary Emergency Generator

⚠ CAUTION!

⚠ NOT INTENDED FOR USE IN CRITICAL LIFE SUPPORT APPLICATIONS.

⚠ ONLY QUALIFIED ELECTRICIANS OR CONTRACTORS SHOULD ATTEMPT INSTALLATION! DEADLY EXHAUST FUMES! OUTDOOR INSTALLATION ONLY!

5.4L

45kW Models


EPA Certified

This manual should remain with the unit.

Table of Contents

SECTION	PAGE
INTRODUCTION	1-1
Read this Manual Thoroughly	1-1
Operation and Maintenance	1-1
How to Obtain Service	1-1
SAFETY RULES	1-2
GENERAL INFORMATION	2-1
Identification Record	2-1
Data Label	2-1
EQUIPMENT DESCRIPTION	3-1
Equipment Description	3-1
Engine Oil Recommendations	3-1
Coolant Recommendations	3-1
ENGINE PROTECTIVE DEVICES	4-1
Engine Protective Devices	4-1
High Coolant Temperature Sender	4-1
Low Coolant Level Sensor	4-1
Low Oil Pressure Switch	4-1
Overcrank Shutdown	4-1
Overspeed Shutdown	4-1
RPM Sensor Loss Shutdown	4-1
DC Fuses	4-1
FUEL SYSTEM	5-1
Fuel Requirements	5-1
Natural Gas Fuel System	5-1
Propane Vapor Withdrawal Fuel System	5-1
LP Liquid Fuel System	5-1
SPECIFICATIONS	6-1
Stationary Emergency Generator	6-1
Engine	6-1
Cooling System	6-1
Fuel System	6-1
Electrical System	6-1
Weather and Maintenance Kits	6-2
Reconfiguring the Fuel System	6-2
Fuel System	6-2
Control Panel	6-2
GENERAL INFORMATION	7-1
Alternator AC Lead Connections	7-1
Four-lead, Single-phase Stator	7-1
Alternator Power Winding Connections	7-1
3-phase Alternators ("Y" Configuration)	7-1
3-phase Alternators ("Delta" Configuration)	7-2
CONTROL PANEL	8-1
Control Panel Interface	8-1
Using the Auto/Off/Manual Switch	8-1
Activate the Generator	8-1
Display Interface Menus	8-1
Activation Chart	8-2
Setting the Exercise Timer	8-3
Low Speed Exercise	8-3
User Adjustable Settings	8-3
Fuel Conversion	8-3
Operation	8-3
Automatic Transfer Operation	8-3
Sequence of Automatic Operation	8-4
Crank Cycles and Overcrank Shutdown	8-4
Auto Start	8-4
Manual Start	8-4
Alarm and Warning Messages	8-4
Low Oil Pressure Shutdown Alarm	8-4
High Coolant Temperature Shutdown Alarm	8-4
Overcrank Shutdown Alarm	8-4
Overspeed Shutdown Alarm	8-4
RPM Sensor Failure Shutdown Alarm	8-4
Under-frequency Shutdown Alarm	8-5
Low Battery Alarm	8-5
Low Battery Warning	8-5
Low Coolant Level Alarm	8-5
Missing Cam Pulse Alarm	8-5
Missing Crank Pulse Alarm	8-5
Low Fuel Pressure Warning	8-5
Governor Sensor Fault Alarm	8-5
Wiring Error Alarm	8-5
Undervoltage Alarm	8-5
Overvoltage Alarm	8-6
Internal Failure Shutdown Alarm	8-6
Canbus Alarm	8-6
Ignition Alarm	8-6
Maintenance Warning	8-6
Alarm Cancel	8-6
Common Alarm Relay	8-6
Maintenance Alerts	8-6
Menu System	8-7
OPERATION	9-1
Stationary Emergency Generator Control and Operation	9-1
Operating Unit with Manual Transfer Switch	9-1
Engine Start-up and Transfer	9-1
Retransfer and Shutdown	9-1
Operating Unit with Automatic Transfer Switch	9-1
MAINTENANCE	10-1
General Maintenance	10-1
Check Engine Oil	10-1
Changing Engine Oil	10-1
Cooling Intake/Outlet	10-1
Inspect Cooling System	10-1
Engine Coolant	10-2
Coolant Change	10-2
Overload Protection for Engine DC Electrical System	10-2
Exercise System	10-2
Perform Visual Inspection	10-2
Inspect Exhaust System	10-2
Check Fan Belt	10-2
Inspect Engine Governor	10-2
Changing the Engine Air Filter	10-2
Spark Plugs	10-3
Battery Maintenance	10-3
Battery Replacement	10-3
Battery Fluid	10-3
Cleaning the Stationary Emergency Generator	10-3
SERVICE SCHEDULE	11-1
TROUBLESHOOTING	12-1
Troubleshooting Guide	12-1
EMISSIONS WARRANTY	13-1
NOTES	
EXPLODED VIEWS & PARTS LISTS	
WIRING DIAGRAMS & SCHEMATICS	

Safety Instructions

 **SAVE THESE INSTRUCTIONS** – The manufacturer suggests that these rules for safe operation be copied and posted in potential hazard areas. Safety should be stressed to all operators, potential operators, and service and repair technicians for this equipment.

INTRODUCTION

Thank you for purchasing this model of the stationary emergency generator product line.

Every effort was expended to make sure that the information and instructions in this manual were both accurate and current at the time the manual was written. However, the manufacturer reserves the right to change, alter or otherwise improve this product(s) at any time without prior notice.

READ THIS MANUAL THOROUGHLY

If any portion of this manual is not understood, contact the nearest Service Dealer for starting, operating and servicing procedures.

Throughout this publication, and on tags and decals affixed to the generator, DANGER, WARNING, CAUTION and NOTE blocks are used to alert personnel to special instructions about a particular service or operation that may be hazardous if performed incorrectly or carelessly. Observe them carefully. Their definitions are as follows:

DANGER!

INDICATES A HAZARDOUS SITUATION OR ACTION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.

WARNING!

Indicates a hazardous situation or action which, if not avoided, could result in death or serious injury.

CAUTION!

Indicates a hazardous situation or action which, if not avoided, could result in minor or moderate injury.

NOTE:

Notes contain additional information important to a procedure and will be found within the regular text body of this manual.

These safety warnings cannot eliminate the hazards that they indicate. Common sense and strict compliance with the special instructions while performing the service are essential to preventing accidents.

Four commonly used safety symbols accompany the DANGER, WARNING and CAUTION blocks. The type of information each indicates is as follows:

 **This symbol points out important safety information that, if not followed, could endanger personal safety and/or property of others.**

 **This symbol points out potential explosion hazard.**



This symbol points out potential fire hazard.



This symbol points out potential electrical shock hazard.

The operator is responsible for proper and safe use of the equipment. The manufacturer strongly recommends that the operator read this Owner's Manual and thoroughly understand all instructions before using this equipment. The manufacturer also strongly recommends instructing other users to properly start and operate the unit. This prepares them if they need to operate the equipment in an emergency.

For safety reasons, the manufacturer recommends that this equipment be installed, serviced and repaired by a Service Dealer or other competent, qualified electrician or installation technician who is familiar with applicable codes, standards and regulations. The operator also must comply with all such codes, standards and regulations.

OPERATION AND MAINTENANCE

It is the operator's responsibility to perform all safety checks, to make sure that all maintenance for safe operation is performed promptly, and to have the equipment checked periodically by a Service Dealer. Normal maintenance service and replacement of parts are the responsibility of the owner/operator and, as such, are not considered defects in materials or workmanship within the terms of the warranty. Individual operating habits and usage contribute to the need for maintenance service.

Proper maintenance and care of the generator ensure a minimum number of problems and keep operating expenses at a minimum. See a Service Dealer for service aids and accessories.

Operating instructions presented in this manual assume that the generator electric system has been installed by a Service Dealer or other competent, qualified contractor. Installation of this equipment is not a "do-it-yourself" project.

HOW TO OBTAIN SERVICE

When the generator requires servicing or repairs, simply contact a Service Dealer for assistance. Service technicians are factory-trained and are capable of handling all service needs.

When contacting a dealer about parts and service, always supply the complete Model Number, Serial Number and Type Code (where applicable) from the DATA LABEL that is affixed to the unit.

Safety Instructions

SAFETY RULES

Study these SAFETY RULES carefully before installing, operating or servicing this equipment. Become familiar with this Owner's Manual and with the unit. The generator can operate safely, efficiently and reliably only if it is properly installed, operated and maintained. Many accidents are caused by failing to follow simple and fundamental rules or precautions.

The manufacturer cannot anticipate every possible circumstance that might involve a hazard. The warnings in this manual, and on tags and decals affixed to the unit are, therefore, not all inclusive. If a procedure, work method or operating technique is used that the manufacturer does not specifically recommend, ensure that it is safe for others. Also make sure the procedure, work method or operating technique utilized does not render the generator unsafe.

⚠ DANGER!

⚠ Despite the safe design of this generator, operating this equipment imprudently, neglecting its maintenance or being careless can cause possible injury or death. Permit only responsible and capable persons to install, operate or maintain this equipment.

⚠ Potentially lethal voltages are generated by these machines. Ensure all steps are taken to render the machine safe before attempting to work on the generator.

⚠ Parts of the generator are rotating and/or hot during operation. Exercise care near running generators.

GENERAL HAZARDS

- For safety reasons, the manufacturer recommends that this equipment be installed, serviced and repaired by a Service Dealer or other competent, qualified electrician or installation technician who is familiar with applicable codes, standards and regulations. The operator also must comply with all such codes, standards and regulations.
- Installation, operation, servicing and repair of this (and related) equipment must always comply with applicable codes, standards, laws and regulations. Adhere strictly to local, state and national electrical and building codes. Comply with regulations the Occupational Safety and Health Administration (OSHA) has established. Also, ensure that the generator is installed, operated and serviced in accordance with the manufacturer's instructions and recommendations. Following installation, do nothing that might render the unit unsafe or in noncompliance with the aforementioned codes, standards, laws and regulations.

- The engine exhaust fumes contain carbon monoxide gas, which can be DEADLY. This dangerous gas, if breathed in sufficient concentrations, can cause unconsciousness or even death. For that reason, adequate ventilation must be provided. This should be considered prior to installing the generator. The unit should be positioned to direct exhaust gasses safely away from any building where people, animals, etc., will not be harmed. Any exhaust stacks that ship loose with the unit must be installed properly per the manufacturer's instruction, and in strict compliance with applicable codes and standards.
- Keep hands, feet, clothing, etc., away from drive belts, fans, and other moving or hot parts. Never remove any drive belt or fan guard while the unit is operating.
- Adequate, unobstructed flow of cooling and ventilating air is critical in any room or building housing the generator to prevent buildup of explosive gases and to ensure correct generator operation. Do not alter the installation or permit even partial blockage of ventilation provisions, as this can seriously affect safe operation of the generator.
- Keep the area around the generator clean and uncluttered. Remove any materials that could become hazardous.
- When working on this equipment, remain alert at all times. Never work on the equipment when physically or mentally fatigued.
- Inspect the generator regularly, and promptly repair or replace all worn, damaged or defective parts using only factory-approved parts.
- Before performing any maintenance on the generator, disconnect its battery cables to prevent accidental start-up. Disconnect the cable from the battery post indicated by a NEGATIVE, NEG or (–) first. Reconnect that cable last.
- Never use the generator or any of its parts as a step. Stepping on the unit can stress and break parts, and may result in dangerous operating conditions from leaking exhaust gases, fuel leakage, oil leakage, etc.

ELECTRICAL HAZARDS

- All stationary emergency generators covered by this manual produce dangerous electrical voltages and can cause fatal electrical shock. Utility power delivers extremely high and dangerous voltages to the transfer switch as well as the generator. Avoid contact with bare wires, terminals, connections, etc., on the generator as well as the transfer switch, if applicable. Ensure all appropriate covers, guards and barriers are in place before operating the generator. If work must be done around an operating unit, stand on an insulated, dry surface to reduce shock hazard.
- Do not handle any kind of electrical device while standing in water, while barefoot, or while hands or feet are wet. DANGEROUS ELECTRICAL SHOCK MAY RESULT.

Safety Instructions

- If personnel must stand on metal or concrete while installing, operating, servicing, adjusting or repairing this equipment, place insulative mats over a dry wooden platform. Work on the equipment only while standing on such insulative mats.
- The National Electrical Code (NEC) requires the frame and external electrically conductive parts of the generator to be connected to an approved earth ground. This grounding will help prevent dangerous electrical shock that might be caused by a ground fault condition in the generator or by static electricity. Never disconnect the ground wire.
- Wire gauge sizes of electrical wiring, cables and cord sets must be adequate to handle the maximum electrical current (ampacity) to which they will be subjected.
- Before installing or servicing this (and related) equipment, make sure that all power voltage supplies are positively turned off at their source. Failure to do so will result in hazardous and possibly fatal electrical shock.
- Connecting this unit to an electrical system normally supplied by an electric utility shall be by means of a transfer switch so as to isolate the generator electric system from the electric utility distribution system when the generator is operating. Failure to isolate the two electric system power sources from each other by such means will result in damage to the generator and may also result in injury or death to utility power workers due to backfeed of electrical energy.
- Stationary emergency generators installed with an automatic transfer switch will crank and start automatically when normal (utility) source voltage is removed or is below an acceptable preset level. To prevent such automatic start-up and possible injury to personnel, disable the generator's automatic start circuit (battery cables, etc.) before working on or around the unit. Then, place a "Do Not Operate" tag on the generator control panel and on the transfer switch.
- In case of accident caused by electric shock, immediately shut down the source of electrical power. If this is not possible, attempt to free the victim from the live conductor. **AVOID DIRECT CONTACT WITH THE VICTIM.** Use a nonconducting implement, such as a dry rope or board, to free the victim from the live conductor. If the victim is unconscious, apply first aid and get immediate medical help.
- Never wear jewelry when working on this equipment. Jewelry can conduct electricity resulting in electric shock, or may get caught in moving components causing injury.

FIRE HAZARDS

- Keep a fire extinguisher near the generator at all times. Do NOT use any carbon tetra-chloride type extinguisher. Its fumes are toxic, and the liquid can deteriorate wiring insulation. Keep the extinguisher properly charged and be familiar with its use. If there are any questions pertaining to fire extinguishers, consult the local fire department.

EXPLOSION HAZARDS

- Properly ventilate any room or building housing the generator to prevent build-up of explosive gas.
- Do not smoke around the generator. Wipe up any fuel or oil spills immediately. Ensure that no combustible materials are left in the generator compartment, or on or near the generator, as FIRE or EXPLOSION may result. Keep the area surrounding the generator clean and free from debris.
- These generators may operate using one of several types of fuels. All fuel types are potentially FLAMMABLE and/or EXPLOSIVE and should be handled with care. Comply with all laws regulating the storage and handling of fuels. Inspect the unit's fuel system frequently and correct any leaks immediately. Fuel supply lines must be properly installed, purged and leak tested according to applicable fuel-gas codes before placing this equipment into service.
- Diesel fuels are highly FLAMMABLE. Gaseous fluids such as natural gas and liquid propane (LP) gas are extremely EXPLOSIVE. Natural gas is lighter than air, and LP gas is heavier than air; install leak detectors accordingly.

CALIFORNIA PROPOSITION 65 WARNING

Engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

CALIFORNIA PROPOSITION 65 WARNING

This product contains or emits chemicals known to the State of California to cause cancer, birth defects and other reproductive harm.

General Information

IDENTIFICATION RECORD

DATA LABEL

Every generator set has a DATA LABEL that contains important information pertinent to the generator. The data label, which can be found attached to the generator's lower connection box, lists the unit's serial number and its rated voltage, amps, wattage capacity, phase, frequency, rpm, power factor, production date, etc.

NOTE:

For actual information related to this particular model, please refer to the Manual Drawing Listing located at the end of this manual, or to the data label affixed to the unit.

Stationary Emergency Generator Model and Serial Number

This number is the key to numerous engineering and manufacturing details pertaining to your unit. Always supply this number when requesting service, ordering parts or seeking information.

Data Label

MODEL	<input type="text"/>	<input type="text"/>	
PROD DATE	<input type="text"/>	SERIAL <input type="text"/>	
KW <input type="text"/>	KVA <input type="text"/>	PHASE <input type="text"/>	HERTZ <input type="text"/>
VOLT <input type="text"/>	AMP <input type="text"/>	PWR FACT <input type="text"/>	ALT RPM <input type="text"/>
ENG RPM <input type="text"/>	TYPE CODE <input type="text"/>		
ALT SUBTRANS REACTANCE <input type="text"/>		ALT TRANS REACTANCE <input type="text"/>	
CLASS <input type="checkbox"/> ROTOR <input type="checkbox"/> STATOR WINDING INS AT 25°C AMB			
<input type="text"/>		<input type="text"/>	
MODEL NO (CAT/CUST NO)		SERIAL NO	
<input type="text"/>		<input type="text"/>	
<input type="text"/>		<input type="text"/>	

0G2110 REV C

EQUIPMENT DESCRIPTION

This equipment is a revolving field, alternating current Stationary Emergency Generator. It is powered by a gaseous fueled engine operating at 1800 rpm for 4-pole direct drive units, 3600 rpm for 2-pole direct drive units and 2300 - 3000 rpm for quiet drive gear units. See the Specifications section for exact numbers. The unit comes complete with a sound attenuated enclosure, internally mounted muffler, control console, mainline circuit breaker, battery charger, and protective alarms as explained in the following paragraph.

All AC connections, including the power leads from the alternator, 120 volt battery charger input and control connections to the transfer switch are available in the main connection box.

The Stationary Emergency Generator incorporates the following alternator features:

- Rotor and Stator insulation class is rated as defined by NEMA MG1-32.6, NEMA MG1-1.66. The generator is self ventilated and drip-proof constructed. Refer to the Specifications section or the data label for the class ratings.
- The voltage waveform deviation, total harmonic content of the AC waveform and telephone influence factor have been evaluated and are acceptable according to NEMA MG1-32.

ENGINE OIL RECOMMENDATIONS

The unit has been filled with 5W-20 engine oil at the factory. Use a high-quality detergent oil classified "For Service SJ or SH." Detergent oils keep the engine cleaner and reduce carbon deposits. When changing the engine oil, be sure to use 5W-30 engine oil.

⚠ CAUTION!

- ⚠ Any attempt to crank or start the engine before it has been properly serviced with the recommended oil may result in an engine failure.

NOTE:

If not already equipped, it is strongly recommended to use the optional Cold Weather Start Kit for temperatures below 32° F. The part number for the Cold Weather Start Kit can be found in the Specifications section or by contacting an authorized dealer. The oil grade for temperatures below 32° F is 5W-30 synthetic oil.

COOLANT RECOMMENDATIONS

Use a mixture of half low silicate ethylene glycol base anti-freeze and deionized water. Cooling system capacity is listed in the specifications. Use only deionized water and only low silicate anti-freeze. If desired, add a high quality rust inhibitor to the recommended coolant mixture. When adding coolant, always add the recommended 50-50 mixture.

⚠ CAUTION!

- ⚠ Do not use any chromate base rust inhibitor with ethylene glycol base anti-freeze or chromium hydroxide ("green slime") forms and will cause overheating. Engines that have been operated with a chromate base rust inhibitor must be chemically cleaned before adding ethylene glycol base anti-freeze. Using any high silicate anti-freeze boosters or additives will also cause overheating. The manufacturer also recommends that any soluble oil inhibitor is NOT used for this equipment.

⚠ DANGER!

- ⚠ Do not remove the radiator pressure cap while the engine is hot or serious burns from boiling liquid or steam could result.
- ⚠ Ethylene glycol base antifreeze is poisonous. Do not use mouth to siphon coolant from the radiator, recovery bottle or any container. Wash hands thoroughly after handling. Never store used antifreeze in an open container because animals are attracted to the smell and taste of antifreeze even though it is poisonous to them.

ENGINE PROTECTIVE DEVICES

The Stationary Emergency Generator may be required to operate for long periods of time without an operator on hand to monitor such engine conditions as coolant temperature, oil pressure or rpm. For that reason, the engine has several devices designed to protect it against potentially damaging conditions by automatically shutting down the unit when the oil pressure is too low, the coolant temperature is too high, the coolant level is too low, or the engine is running too fast.

NOTE:

Engine protective switches and sensors are mentioned here for the reader's convenience. Also refer to the applicable control panel manual for additional automatic engine shutdown information.

HIGH COOLANT TEMPERATURE SENDER

An analog coolant temperature sender, located in the engine's cooling system will cause an engine shutdown if the temperature should exceed approximately 125° C (257° F). The generator will automatically restart once the temperature has returned to a safe operating level.

LOW COOLANT LEVEL SENSOR

To prevent overheating, the engine has a low coolant level sensor. If the level of engine coolant drops below the level of the low coolant level sensor, the engine automatically shuts down.

LOW OIL PRESSURE SWITCH

This switch has normally closed contacts that are held open by engine oil pressure during cranking and operating. Should oil pressure drop below the 8 psi range, switch contacts close, and the engine shuts down. The unit should not be restarted until oil is added, and the AUTO/OFF/MANUAL switch must be turned to OFF and then back to AUTO.

OVERCRANK SHUTDOWN

After a prespecified duration of cranking, this function ends the cranking if the engine has failed to start. The overcrank message will turn ON. Turn OFF the AUTO/OFF/MANUAL switch, then turn switch back to AUTO to reset the generator control board.

NOTE:

If the fault is not corrected, the overcrank feature will continue to activate.

Approximate Crank Cycle Times

- 15 seconds ON
- 7 seconds OFF
- 7 seconds ON
- 7 seconds OFF
- Repeat for 45 seconds
- Approximately 90 seconds total.

OVERSPEED SHUTDOWN

A speed circuit controls engine cranking, start-up, operation and shutdown. Engine speed signals are delivered to the circuit board whenever the unit is running. Should the engine overspeed above a safe, preset value, the circuit board initiates an automatic engine shutdown. Contact the nearest Authorized Dealer if this failure occurs.

RPM SENSOR LOSS SHUTDOWN

If the speed signal to the control panel is lost, engine shutdown will occur.

DC FUSES

A fuse (7.5 amp) is located on the control panel. It protects the panel components from damaging overload. **Always remove this fuse before commencing work on the generator.** The unit will not start or crank if the fuse is blown.

A fuse (25 amp) is located in the engine wire harness adjacent to the DC alternator. It is used to prevent circuit failure due to DC alternator failure. It will also protect the system in the event of a wiring short-circuit. If this fuse is blown, the generator will not operate. Replace these fuses with the same size, type, and rating.

FUEL SYSTEM

FUEL REQUIREMENTS

The Stationary Emergency Generator may be equipped with one of the following fuel systems:

- Natural gas fuel system
- Propane vapor (LPV) fuel system

Recommended fuels should have a Btu content of at least 1,000 Btu's per cubic foot for natural gas; or at least 2,520 Btu's per cubic foot for LP gas. Ask the fuel supplier for the Btu content of the fuel.

NOTE:

The fuel consumption requirements are identified in the Specifications section of the Owner's Manual. Refer to the Installation Manual if assistance is required for the sizing of the pipe diameter for the generator. Any piping used to connect the generator to the fuel supply should be of adequate size to achieve the 100% load fuel consumption requirements identified in the Specifications section regardless of actual load.

NOTE:

The recommended fuel pressure is identified in the Specifications section this manual.

NOTE:

It is the responsibility of the installer to make sure that only the correct recommended fuel is supplied to the generator fuel system. Thereafter, the owner/operator must make certain that only the proper fuel is supplied.

NATURAL GAS FUEL SYSTEM

Natural gas is supplied in its vapor state. In most cases, the gas distribution company provides piping from the main gas distribution line to the standby generator site. The following information applies to natural gas fuel systems.

- Gas pressure in a building is usually regulated by national, state and local codes.
- To reduce gas pressure to a safe level before the gas enters a building, a primary regulator is needed. The natural gas supplier may or may not supply such a regulator.
- It is the responsibility of the gas supplier to make sure sufficient gas pressure is available to operate the primary regulator.
- Gas pressure at the inlet to the fuel shutoff solenoid must never exceed approximately 14 inches water column (0.5 psi).

PROPANE VAPOR WITHDRAWAL FUEL SYSTEM

This type of system utilizes the vapors formed above the liquid fuel in the supply tank. Approximately 10 to 20 percent of the tank capacity is needed for fuel expansion from the liquid to the vapor state. The vapor withdrawal system is generally best suited for smaller engines that require less fuel. The installer should be aware of the following:

- When ambient temperatures are low and engine fuel consumption is high, the vapor withdrawal system may not function efficiently.
- Ambient temperatures around the supply tank must be high enough to sustain adequate vaporization, or the system will not deliver the needed fuel volume.
- In addition to the cooling effects of ambient air, the vaporization process itself provides an additional cooling effect.

Specifications

SPECIFICATIONS

STATIONARY EMERGENCY GENERATOR

Type.....	Synchronous
Rotor Insulation.....	Class F
Stator Insulation.....	Class H
Telephone Interference Factor (TIF)	< 50
Alternator Output Leads 1-phase	4-wire
Alternator Output Leads 3-phase	6-wire
Bearings	Sealed Ball
Coupling	Flexible Disc
Load Capacity (Standby Rating)	45kW*

* NOTE: Generator rating and performance in accordance with ISO8528-5, BS5514, SAE J1349, ISO3046 and DIN 6271 Standards. KW rating is based on LPG fuel and may derate with natural gas.

Excitation System	Direct		
Generator Output Voltage/kW - 60 Hz	<u>kW</u>	<u>Amp</u>	<u>CB Size</u>
120/240V, 1-phase, 1.0 pf	45	188	200
120/208V, 3-phase, 0.8 pf	45	156	175
120/240V, 3-phase, 0.8 pf	45	135	150
277/480V, 3-phase, 0.8 pf	45	68	80
Generator Locked Rotor KVA Available @ Voltage Dip of 35%			
Single-phase or 208, 3-phase	86 KVA		
480V, 3-phase	95 KVA		

ENGINE

Make	Generac
Cylinders and Arrangement	8, V-type
Displacement	5.4 Liter
Bore.....	3.55 in.
Stroke.....	4.17 in.
Compression Ratio.....	9-to-1
Air Intake System.....	Naturally Aspirated
Valve Seats	Precision Ground, Hardened
Lifter Type.....	Roller, Hydraulic
Spark Plug Gap	1.29-1.45mm (0.051-0.057 inch)

Engine Parameters

Rated Synchronous RPM	60 Hz, 1800
-----------------------------	-------------

Exhaust System

Exhaust Flow at Rated Output 60 Hz	414 cfm
Exhaust Temp. at Rated Output	1025° F

Combustion Air Requirements (Natural Gas)

Flow at rated power, 60 Hz	163 cfm
----------------------------------	---------

Governor

Type.....	Electronic
Frequency Regulation.....	Isochronous
Steady State Regulation	± 0.25%

Engine Lubrication System

Type of Oil Pump	Gear
Oil Filter	Full Flow Spin-on, Cartridge
Crankcase Oil Capacity	6.5 U.S. qts.

COOLING SYSTEM

Type.....	Pressurized Closed Recovery
Water Pump.....	Belt Driven
Fan Speed.....	1954 rpm
Fan Diameter.....	22 inches
Fan Mode.....	Puller
Air Flow (inlet air including alternator and combustion air)	4350 ft ³ /min.
Coolant Capacity.....	11.4 L (3.0 U.S. gal.)
Heat Rejection to Coolant	186,000 Btu/h
Maximum Operating Air Temp. on Radiator.....	60° C (150° F)
Maximum Ambient Temperature	50° C (140° F)

FUEL SYSTEM

Type of Fuel	Natural Gas, Propane Vapor
Carburetor.....	Down Draft
Secondary Fuel Regulator.....	Standard
Fuel Shut-off Solenoid	Standard
Operating Fuel Pressure	5 in. - 14 in. Water Column

Fuel Consumption - ft³/hr (Natural Gas/LPV)

<i>Exercise</i>	<i>25%</i>	<i>50%</i>	<i>75%</i>	<i>100%</i>
<i>Cycle</i>	<i>Load</i>	<i>Load</i>	<i>Load</i>	<i>Load</i>
95/38	204/82	392/157	547/220	756/302

ELECTRICAL SYSTEM

Battery Charge Alternator	12V, 30 Amp
Static Battery Charger	2.5 Amp
Recommended Battery.....	Group 24F, 525CCA
System Voltage	12 Volts

Voltage Regulator

Type.....	Electronic
Sensing	Single-phase
Regulation.....	± 1%
Features.....	Adjustable Voltage and Gain

Power Adjustment for Ambient Conditions

Temperature Deration	
3% for every 10° C above °C	25
1.65% for every 10° above °F	77
Altitude Deration	
1% for every 100 m above m	183
3% for every 1000 ft. above ft.	600

Controller	Nexus
------------------	-------

Specifications

WEATHER AND MAINTENANCE KITS

To keep the generator running at its peak, the following kits are offered:

- Cold Weather Kit
 - ~ Recommended for climates with temperatures below 32° F.
- Scheduled Maintenance Kit
 - ~ Kit includes the recommended parts to maintain the generator. Refer to the Service Schedule for regular maintenance intervals.

For additional information, or to order any of these kits, please contact an Authorized Service Dealer or Customer Service Representative.

RECONFIGURING THE FUEL SYSTEM

NOTE:

All models are configured to run on natural gas from the factory.

Before the generator can be operated using a LP fuel source, the fuel system and control panel (refer to the installation drawing for location) must be reconfigured. The steps to reconfigure the generator from a natural gas (NG) to a liquidified petroleum (LP) fuel source are as follows:

FUEL SYSTEM

1. Turn the main gas supply off and disconnect the battery.
2. Remove the carburetor fuel hose from the outlet port of the demand regulator (see Figure 6.1).
3. Disconnect the power wires from the fuel solenoid located on top of the regulator assembly by removing the screw on the front of the connector and pulling the connector forward, away from the solenoid body.
4. Loosen the spring clamp on the small fuel enrichment line and remove the hose from the hose barb.
5. Remove the black pipe assembly from the outlet port of the demand regulator. The solenoid assembly may need to be removed before performing this operation (Figure 6.1).
6. Remove the NG fuel jet (loosen counter clockwise) from the outlet port.
7. Remove the LP fuel jet (loosen counter clockwise) from the jet keeper port on the side of the regulator housing. Install this jet into the outlet port in the regulator casting.

NOTE:

The jet sizes are stamped on the individual jets. The larger jet size is used for running on NG.


8. Install the previously removed NG jet into the jet keeper port on the side of the regulator housing.

9. Install the previously removed black pipe onto the outlet port of the demand regulator. Use pipe sealant on the pipe threads.
10. Reverse steps 1-4 in this procedure to reactivate the demand regulator.
11. Follow the instructions in the Control Panel section.

⚠ DANGER!

⚠ Serious injury, including death, or damage may occur if not configured properly. Please consult an Authorized Dealer with any questions.

Figure 6.1 — Reconfigure the Fuel System



CONTROL PANEL

The FUEL TYPE must be reconfigured in the control panel to finalize the conversion process. This generator is configured at the factory to operate on natural gas. If conversion to LP is required, please complete the mechanical conversion process and then call 888-9ACTIVATE for the control panel password. This fuel selection conversion is required to be password protected by Environmental Protection Agency [EPA] regulations.

⚠ CAUTION!

⚠ Whenever the Generator's Fuel Regulator is converted from one Fuel type to the other, the Control Panel must be reconfigured for the correct fuel type. Failure to convert both the Regulator and Control Panel will result in decreased performance and an increase in emissions, and is a violation of EPA regulations.

ALTERNATOR AC LEAD CONNECTIONS


The electrical wires in the unit's AC connection (lower) panel should be installed according to the number of leads and the voltage/phase required for the application. The voltage and phase are described on the generator data label. The number of lead wires can be identified using the Specifications section and the power output rating on the generator data label. For example, if the generator produces 130kW, 277/480 Volt, 3-phase power, the generator has 12 alternator output leads. Figure 7.3 describes the stator power winding connection for the generator.

FOUR-LEAD, SINGLE-PHASE STATOR

Four-lead alternators (see Figure 7.1) are designed to supply electrical loads with voltage code "A" (240V, 1-phase, 60 Hz). Electrical power is produced in the stator power windings. These windings were connected at the factory to the main circuit breaker as shown in Figure 7.1.

The rated voltage between each circuit breaker terminal is 240V. The rated voltage between each circuit breaker terminal and the neutral point 00 is 120V.

Figure 7.1 — Four-lead, Single-phase Stator



ALTERNATOR POWER WINDING CONNECTIONS

3-PHASE ALTERNATORS ("Y" CONFIGURATION)

The Stationary Emergency Generator is designed to supply 3-phase electrical loads. Electric power is produced in the alternator power windings. These windings were connected at the factory to the main circuit breaker with a "Y" configuration as shown in Figures 7.2 through 7.6.

The rated voltage between circuit breaker terminals E1-E2, E1-E3 and E2-E3 is 480V, 208V or 600V depending on the model.

The rated voltage between each circuit breaker terminal and the neutral point 00 is 277V, 120V, or 346V depending on the model.

Figure 7.2 — Stator Power Winding Connections - 3-phase, 277/480V (6 Lead)





Figure 7.3 — Stator Power Winding Connections - 3-phase, 277/480V (12 Lead)



General Information

Figure 7.4 — Stator Power Winding Connections - 3-phase, 120/208V (6 Lead)




Figure 7.5 — Stator Power Winding Connections - 3-phase, 120/208V (12 Lead)





Figure 7.6 — Stator Power Winding Connections - 3-phase, 346/600V (6 Lead)



3-PHASE ALTERNATORS ("DELTA" CONFIGURATION)

The Stationary Emergency Generator is designed to supply 3-phase electrical loads. Electric power is produced in the alternator power windings. These windings were connected at the factory to the main circuit breaker with a "Delta" configuration as shown in Figures 7.7 and 7.8.

The rated voltage between circuit breaker terminals E1-E2, E1-E3 and E2-E3 is 240V.

The rated voltage between E1 or E3 and the neutral point 00 is 120V.

Figure 7.7 — Stator Power Winding Connections - 3-phase, 120/240V (6 Lead)





Figure 7.8 — Stator Power Winding Connections - 3-phase, 120/240V (12 Lead)



CONTROL PANEL INTERFACE

USING THE AUTO/OFF/MANUAL SWITCH

⚠ WARNING!

! With the switch set to AUTO, the engine may crank and start at any time without warning. Such automatic starting occurs when utility power source voltage drops below a preset level or during the normal exercise cycle. To prevent possible injury that might be caused by such sudden starts, always set the switch to OFF and remove the fuse before working on or around the generator or transfer switch. Then, place a “DO NOT OPERATE” tag on the generator panel and on the transfer switch.

1. “AUTO” Position – Selecting this switch activates fully automatic system operation. It also allows the unit to automatically start and exercise the engine every seven days with the setting of the exercise timer (see the Setting the Exercise Timer section).
2. “OFF” Position – This switch position shuts down the engine. This position also prevents automatic operation.
3. “MANUAL” Position – Set the switch to MANUAL to crank and start the engine. Transfer to standby power will not occur unless there is a utility failure.

ACTIVATE THE GENERATOR

When battery power is applied to the generator during the installation process, the controller will turn ON and the LCD screen will illuminate. However, the generator still needs to be activated before it will automatically run in the event of a power outage.

Activating the generator is a simple one time process that is guided by the controller screen prompts. Once the product is activated, the controller screen will not prompt you again, even if you disconnect the generator battery.

To obtain the activation code, record the generator serial number and log onto www.activategen.com or call 1-888-9ACTIVATE and follow the steps to retrieve the activation code.

After obtaining your activation code, please complete the following steps at the generator’s control panel in the Activation Chart on the following page.

NOTE:

The generator will only run in manual until the passcode has been entered.

Upon power up, this controller will go through a system self test which will check for the presence of utility voltage on the DC circuits. This is done to prevent damage if the installer mistakenly connects AC utility power sense wires into the DC terminal block. If utility voltage is detected, the controller will display a warning message and lock out the generator, preventing damage to the controller. Power to the controller must be removed to clear this warning.

Utility voltage must be turned on and present at the N1 and N2 terminals inside the generator control panel for this test to be performed and pass.

NOTE:

DAMAGE CAUSED BY MISWIRING OF THE INTERCONNECT WIRES IS NOT WARRANTABLE!

This test will be performed each time the controller is powered up.

Next, the user must enter the minimum settings to operate. These settings are current date and time and exercise day and time. The maintenance intervals will be initialized (i.e. started) the first time the clock is set. If the clock is never set at power up, the maintenance intervals will be reset every time power is applied.

If a subsequent power loss (loss of battery power) occurs the Installation assistant will operate upon power restoration. The self test routine will be run and then the customer will be required to re-enter the time and date, as this is not retained during a power loss. The unit will not require re-activation.






DISPLAY INTERFACE MENUS

The LCD display is organized as detailed below:

- The “Home” page, this page is the default page which will be displayed if no keys are pressed for 30 seconds. This page normally shows the current Status message and the current date and time. The highest priority active Alarm and/or Warning will be automatically posted on this page as well as flashing the backlight when such an event is detected. In the case of multiple Alarms or Warnings, only the first message will be displayed. To clear an Alarm or Warning, see the Protection Systems section - Clear Alarm.
- The display backlight is normally off. If the user presses any key, the backlight will come on automatically and remain on for 30 seconds after the last key was pressed.
- The “Main Menu” page will allow the user to navigate to all other pages or sub-menus by using the Left/Right and Enter keys. This page can be accessed at any time with several presses of the dedicated Escape key. Each press of the Escape key takes you back to the previous menu until the main menu is reached. This page displays the following options: HISTORY; STATUS; EDIT; AND DEBUG. (See the Appendix - “Menu System”).

Control Panel

ACTIVATION CHART

CHOOSE LANGUAGE		TROUBLESHOOTING
<p>Display Reads:</p> 	<p>Use ARROW keys to scroll to desired language. Press ENTER to select.</p>	<p>If the wrong language is chosen, it can be changed later using the “edit” menu.</p>
<p>Display Reads:</p> 	<p>Press ENTER to begin the activation process.</p>	<p>If ESCAPE is pressed instead of ENTER, your generator will only run in manual mode (for test purposes) and NOT ACTIVATED will be displayed. You will need to remove the generator control panel fuse AND disconnect the T1, N1 and N2 connector in the external connection box (if equipped); or disconnect utility input (main breaker) to the transfer switch for 3-5 seconds and reconnect, then begin with Step 1.</p>
<p>Display Reads:</p> 	<p>If you do not have your activation code, go to www.activategen.com or call 1-888-9ACTIVATE (922-8482). If you already have your activation code, wait 3-5 seconds for the next display.</p>	
ENTER ACTIVATION CODE (Passcode)		TROUBLESHOOTING
<p>Display Reads:</p> 	<p>Use ARROW keys to scroll and find the first number of your Activation Code. Press ENTER to select. Repeat this step until all digits have been entered. Use ESCAPE to correct previous digits.</p>	
<p>Display Reads:</p> 	<p>Activation is complete when all digits are entered above and your screen shows this display. Follow the controller prompts to continue setting the time function. Refer to your Owner's Manual with questions.</p>	<p>What happens if “Wrong Passcode Try Again” appears? Re-enter the activation code. If a second attempt is unsuccessful, check the number against the code given on activategen.com. If it is correct and the generator will not accept it, contact 1-888-9ACTIVATE (922-8482).</p>

INSTALLATION ASSISTANT

Interconnect System Self Test Feature (follow the on-screen prompts).

Upon power up, this controller will go through a system self test which will check for the presence of utility voltage on the DC circuits. This is done to prevent damage if the installer mistakenly connects AC utility power sense wires into the DC terminal block. If utility voltage is detected, the controller will display a warning message and lock out the generator, preventing damage to the controller. Power to the controller must be removed to clear this warning.

Utility voltage must be turned on and present at the N1 and N2 terminals inside the generator control panel for this test to be performed and pass.

NOTE:

DAMAGE CAUSED BY MISWIRING OF THE INTERCONNECT WIRES IS NOT WARRANTABLE!

This test will be performed each time the controller is powered up.

Upon first power up of the generator, the display interface will begin an installation assistant. The assistant will prompt the user to set the minimum settings to operate. These settings are simply: Current Date/Time and Exercise Day/Time. The maintenance intervals will be initialized when the exercise time is entered.

The exercise settings can be changed at any time via the "EDIT" menu (see Appendix, "Menu System").

If the 12 volt battery is disconnected or the fuse removed, the Installation Assistant will operate upon power restoration. The only difference is the display will only prompt the customer for the current Time and Date.

IF THE INSTALLER TESTS THE GENERATOR PRIOR TO INSTALLATION, PRESS THE "ENTER" KEY TO AVOID SETTING UP THE EXERCISE TIME. THIS WILL ENSURE THAT WHEN THE CUSTOMER POWERS UP THE UNIT, HE WILL STILL BE PROMPTED TO ENTER AN EXERCISE TIME.

SETTING THE EXERCISE TIMER

This generator is equipped with an exercise timer. Once it is set, the generator will start and exercise every seven days, on the day of the week and at the time of day specified. During this exercise period, the unit runs for approximately 12 minutes and then shuts down. Transfer of loads to the generator output does not occur during the exercise cycle unless utility power is lost.

LOW SPEED EXERCISE

The standard start sequence will be initiated.

- All 1800 rpm units will exercise at 1400 RPM
- All 3600 rpm units will exercise at 1800 RPM

If utility is lost during exercise the controller will do the following:

- Wait for the "line interrupt period" for utility to return. If utility returns within the "line interrupt period", continue to exercise at low RPM.

- If utility is still lost after the "line interrupt period", run the engine up to normal RPM and transfer the load. At this time the controller will exit the exercise routine and assume full automatic operation.

USER ADJUSTABLE SETTINGS

Setting	Factory Default	Minimum Setting	Maximum Setting	Increment
Exercise time	2 pm	00:00 (12 am)	23:59 (11:59 pm)	1 min
Exercise day	Wed	Sun	Sat	1 day
Current Time	12 am	00:00 (12 am)	23:59 (11:59 pm)	1 min
Current Day	Sun	Sun	Sat	1 day
Current Month	Jan	Jan	Dec	1 month
Current Year	2008	2008	2100	1 year
Language	English	French	Spanish	N/A
Contrast	80%	0%	100%	1%

FUEL CONVERSION

For fuel conversion steps, refer to the GenSpec section, RECONFIGURING THE FUEL SYSTEM.

OPERATION

This system is intended to supply standby power in the event of a utility failure. The control system will monitor the utility voltage to determine if stand-by power is required. Should the utility voltage fail, the generator will start and run normally, detaching from the utility and supplying the customer load from the generator. When utility power returns, the controller will re-transfer the customer load back to utility and shut down the generator.

AUTOMATIC TRANSFER OPERATION

To select automatic operation, do the following:

1. Make sure the transfer switch main contacts are set to their UTILITY position, i.e., loads connected to the utility power source.
2. Be sure that normal UTILITY power source voltage is available to transfer switch terminal lugs N1 and N2 (Refer to the Electrical Data section).
3. Set the generator's AUTO/OFF/MANUAL switch to AUTO.
4. Set the generator's main circuit breaker to its ON (or CLOSED) position.

With the preceding steps complete, the generator will start automatically when utility source voltage drops below a preset level. After the unit starts, loads are transferred to the standby power source. Refer to the Sequence of Automatic Operation section.

SEQUENCE OF AUTOMATIC OPERATION

Initial Conditions: Generator in Auto ready to run, load being supplied by the Utility Source through the transfer switch.

1. When the utility voltage fails (falls below 60% of nominal), a 10-30 second (programmable) "line interrupt" delay timer is started. The factory set time delay is 10 seconds. If at the end of the line interrupt time the utility voltage is above 60% the engine will not crank. If the utility voltage is still below the 60% of nominal at the end of the line interrupt time, the unit will crank and start. If the unit cranks for more than 10 seconds and the utility voltage rises above 80% of nominal (programmed pickup voltage) and the unit has not started, the crank cycle will abort.
2. As soon as the unit starts a 5 second "warm-up" timer is initiated. When the warm-up timer expires the control will transfer the load to the generator (through the RTS switch) if the utility voltage is less than 80% of nominal. If the utility voltage is greater than the 80% of nominal at the end of the warm-up time the load will not be transferred to the generator and a one minute low-speed cool down period will start. At the end of the one minute cool down period the generator will stop.
3. Once the unit is running and the switch has transferred the load to the generator the unit will monitor utility voltage. When utility voltage returns (above the programmable pickup voltage, normally 80% of nominal), a 15 second "Return to Utility" timer will start. At the end of the return to utility time, if the utility voltage is still above the pickup voltage, the unit will transfer the load back to the utility source and run the unit through a one minute cool down period. When the cool down period is over the unit will shut down and be ready for the next outage.
4. If during the cool down period utility voltage should fall below 60% of nominal the 5 second warm-up timer is initiated and the unit will transfer the load back to the generator and continue to monitor the utility.

CRANK CYCLES AND OVERCRANK SHUTDOWN

If the unit fails to start during a cranking period it will display the Overcrank Shutdown Alarm. The system will control the cranking cycles as follows:

The first crank cycle is a 16 second crank time followed by a 7 second rest. The next 5 cycles will be 7 seconds of cranking time each followed by a 7 second rest time.

If the unit fails to start by the end of the 6 crank/rest cycles the Overcrank Shutdown Alarm will display and the unit will not attempt to crank until the alarm is reset.

AUTO START

This unit is designed to automatically start in the event of a utility failure or brown out condition. Brown out is defined as utility voltage less than 60% nominal, while utility is considered good when it is restored to at least the pickup value, 80% of nominal. These levels are fixed. The "Line Interrupt period" is an adjustable parameter by the dealer. If 2-wire start mode is activated, the unit will start when 2-wire start is active.

MANUAL START

Allows the user to start and run the generator manually.

Transfer of the load to the generator will occur if utility is lost while the unit is running in the manual mode (only if activated).

ALARM AND WARNING MESSAGES

Alarms are defined as "Latching" which means they must be cleared before the alarm message on the screen will clear. They can be of type "Shutdown" or not and are logged in the alarm log. Alarms are all annunciated on the display).

Warnings are "Non Latching" meaning the message automatically clears when the warning condition goes away. Warnings can not be of type "Shutdown" but they are logged in the alarm log. Warnings are all annunciated on the display.

LOW OIL PRESSURE SHUTDOWN ALARM

There is a 10 second delay before oil pressure is monitored.

HIGH COOLANT TEMPERATURE SHUTDOWN ALARM

There is a 10 second delay before engine temperature is monitored.

Once running there is a 1/4 second delay before shut down. The limit is set at 125° C or 257° F.

OVERCRANK SHUTDOWN ALARM

Occurs if the engine has not started within the specified crank cycle.

OVERSPEED SHUTDOWN ALARM

Warning indicator is measured and calculated by the microprocessor. Overspeed is defined as +20% of nominal engine speed for 3 seconds, or +25% immediate.

Nominal engine speed = 60.0 Hz

RPM SENSOR FAILURE SHUTDOWN ALARM

During cranking: If the board does not see a valid RPM signal within four (4) seconds of cranking it will shut down and lock out on RPM sensor loss.


During running: If the RPM signal is lost for one full second the board will shut the engine down, wait 15 seconds, then re-crank the engine if in AUTO, it will not re-crank in MANUAL.

If no RPM signal is detected within the first four (4) seconds of cranking, the control board will shut the engine down and latch out on RPM sensor loss.

If the RPM signal is detected the engine will start and run normally. If the RPM signal is subsequently lost the control board will try two more re-cranks before latching out and flashing the RPM Sensor Failure message (if it is in AUTO).

Control Panel

Figure 1 – Generator Control Panel



CHECK ENGINE MESSAGE

The control system has detected an emissions related fault. This fault cannot be cleared using the control panel interface. The unit will continue to operate in automatic mode. Contact your local servicing dealer.

UNDER-FREQUENCY SHUTDOWN ALARM

After starting, if the generator stays under frequency for more than 30 seconds, it will shutdown.

LOW BATTERY ALARM

While running, if the average battery voltage falls below 11.9 volts for one (1) minute, the low battery alarm will be displayed.

LOW BATTERY WARNING

The microprocessor will continually monitor the battery voltage and display the Low Battery Voltage message if the battery voltage falls below 12.2 Volts for one (1) minute.

No other action is taken on a low battery warning condition. The warning will automatically clear if the battery voltage rises above 12.2 volts.

NOTE:

The battery sentinel is a separate feature that monitors battery condition.

LOW COOLANT LEVEL ALARM

This is a shutdown alarm. The sensor will be continuously monitored. If an error condition is seen for five (5) consecutive seconds, the alarm will be displayed.

MISSING CAM PULSE ALARM

This is a shutdown alarm. The alarm will activate after five (5) seconds of continuously missing cam pulses.

MISSING CRANK PULSE ALARM

This is a shutdown alarm. The alarm will activate after 12 consecutive revs where crank pulses are missing.

LOW FUEL PRESSURE WARNING

Fuel pressure is monitored by a digital sensor with a fixed setpoint of below five (5) inches water column.

GOVERNOR SENSOR FAULT ALARM

The governor position is monitored by an analog feedback signal. If the throttle position is seen outside of the normal operating range, a shutdown alarm is displayed. If the throttle is commanded to move, and no movement is seen, a shutdown alarm is displayed.

WIRING ERROR ALARM

When power is first applied to the controller, the software will perform a check on the wiring of the transfer output, and ensure it does not have high voltage on the wire. If this is the case, it will signal a miswire alarm and will not run. The test can be skipped by use of the escape key.

UNDERVOLTAGE ALARM

If the generator voltage falls below 60% for >5 seconds, an alarm will be issued.

Control Panel

OVERVOLTAGE ALARM

If the generator voltage rises above 110% for >3 seconds, an alarm will be issued.

If the generator voltage rises above 130% for >0.2 seconds, an alarm will be issued.

INTERNAL FAILURE SHUTDOWN ALARM

Any internal failure that can be detected such as corrupted firmware will cause this shutdown alarm. This alarm cannot be cleared.

CANBUS ALARM

Where applicable, if the Canbus communications link fails to communicate, a "Canbus Alarm" will be generated. This only applies to systems with external ignition modules. The alarm may be generated if:

1. The physical link is broken.
2. The Ignition Module fails or resets.
3. The Nexus Controller fails or resets.
4. Having the Battery Chargers 120 VAC connected without a battery installed.
5. A blown 10 amp Ignition Module fuse (approximately 12 inches away from the starter).
6. A blown 25 amp system fuse (located approximately 12 inches away from the DC alternator).

NOTE:

The "Canbus Alarm" will not clear on its own. To clear the alarm, press the "enter" key to acknowledge the alarm. The alarm will clear and if the fault is still present, the alarm will reoccur.

IGNITION ALARM

When an ignition alarm occurs, a generic message "Ignition Fault" will be displayed as the fault code.

MAINTENANCE WARNING

When a maintenance period expires, a warning message will be posted. The warning can be reset by hitting the Enter key. Resetting will clear the warning and reset the maintenance counters for the condition annunciated. The history log will reflect the maintenance warning.

ALARM CANCEL

When the generator is shut down due to a latching alarm, the Auto /Off/ Manual switch must be set to the off position and the ENTER key pressed to unlatch any active fault and clear the corresponding fault alarm message.

COMMON ALARM RELAY

The common alarm relay will be activated if there is a shutdown alarm. It will not activate on warnings or indicate that the Auto/Off/ Manual switch is in the OFF position. The OFF position will clear the alarms and the relay. The relay will not be used to indicate a generator is not activated.

The common alarm connections are wired to a set of potential-free (dry) contacts on the Nexus controller board. These Normally Open (N.O.) contacts close when an alarm condition occurs and are used to activate a remote signaling device. The circuit is rated for a maximum of 130mA at 24 VDC. The connections are a short set of free hanging wires that exit the engine harness loom directly behind the Nexus Control Panel and are labeled numbers 209 and 210.

MAINTENANCE ALERTS

Maintenance alerts will be provided for these conditions.


SERVICE SCHEDULE 'A'

Inspect Accessory Drive Alert	1yr / 100hrs*
Coolant Change & Flush	1yr / 100hrs
Inspect Spark Plugs Alert	1yr / 100hrs
Change Oil & Filter Alert	1yr / 100hrs*
Inspect Battery Alert	1yr / 100hrs
Change / Inspect Air Filter Alert	1yr / 100hrs
Clean/Inspect Air Inlet & Exhaust	6mo / 50hrs*
* Items require a 3 month / 30 hour break-in change or check.	

SERVICE SCHEDULE 'B'

Change / Inspect spark plugs alert	2yr/ 250hr
------------------------------------	------------

MENU SYSTEM



ESC Press the "ESCAPE" key to jump back up through the menu levels.

+ / - Use the "+/-" key to navigate through the menu.

ENTER Use the "ENTER" key to select items or enter data.

STATIONARY EMERGENCY GENERATOR CONTROL AND OPERATION

Refer to the appropriate control panel operator's manual for this unit.

OPERATING UNIT WITH MANUAL TRANSFER SWITCH

If the Stationary Emergency Generator was installed in conjunction with a transfer switch capable of manual operation only, the following procedure applies. A manually operated transfer switch is one that will not provide automatic start-up and does not include an intelligence circuit.

ENGINE START-UP AND TRANSFER

For additional information, refer to the applicable control panel manual for this unit, as well as any literature pertaining to the specific transfer switch.

⚠ DANGER!

⚠ The Maintenance Disconnect Switch and the AUTO/OFF/MANUAL switches (if so equipped) must be set properly, or the generator will crank and start as soon as the utility power to the transfer switch is turned off. Refer to applicable control panel and transfer switch manuals for more information.

⚠ Do not proceed until certain that utility source voltage is available to the transfer switch and the transfer switch main contacts are set to UTILITY.

⚠ Do not attempt manual operation until all power supplies to the transfer switch have been positively turned off, or extremely dangerous - possibly lethal - electrical shock will result.

⚠ Transfer switch enclosure doors should be kept closed and locked. Only authorized personnel should be allowed access to the transfer switch interior. Extremely high and dangerous voltages are present in the transfer switch.

In order to transfer load from the utility source to the generator, follow these directions:

- Turn OFF or disconnect the utility power circuit to the transfer switch, using the means provided (such as the utility source main line circuit breaker).
- Set the transfer handle to its UTILITY (NORMAL) position with load circuits connected to the utility power supply.
- Set the generator's main line circuit breaker to its OFF (or OPEN) position.
- Start the generator.

⚠ CAUTION!

⚠ Do not crank the engine continuously for longer than 30 seconds, or the heat may damage the starter motor.

- Let engine stabilize and warm up.
- Check all applicable instrument and gauge readings. When certain that all readings are correct, move the transfer switch manual handle to the STANDBY (or EMERGENCY STANDBY) position, i.e., load circuits supplied by the generator.
- Set the generator's main line circuit breaker to its ON (or CLOSED) position.
- Load circuits are now powered by the generator.

RETRANSFER AND SHUTDOWN

For additional information, refer to the applicable control panel manual for this unit, as well as any literature pertaining to the specific transfer switch.

To transfer the load back to the utility power source and shut down the generator, follow these directions:

- Set the generator's main line circuit breaker to its OFF (or OPEN) position.
- Manually move the transfer switch handle to its UTILITY (NORMAL) position, i.e., load circuits connected to the utility.
- Turn ON the utility power supply to the transfer switch, using the means provided (such as the utility power source main line circuit breaker).
- Let the generator run at no-load for a few minutes to stabilize internal temperatures.
- Shut down the generator.

OPERATING UNIT WITH AUTOMATIC TRANSFER SWITCH

If the Stationary Emergency Generator has been installed with an automatic transfer switch, the engine may be started and stopped automatically or manually.

NOTE:

Refer to the applicable manual for your transfer switch and to "Transfer Switch Start Signal Connections". In addition, please note the dangers under "Engine Start-up and Transfer."

GENERAL MAINTENANCE

⚠ WARNING!

⚡ Before working on the Stationary Emergency Generator, ensure the following:


- The AUTO/OFF/MANUAL switch is in the OFF position.
- The control panel fuse has been removed from the control box.
- The 120VAC supply to the battery charger is switched OFF.
- The negative battery cable has been removed.

CHECK ENGINE OIL

Check engine crankcase oil level (Figure 10.1) according to the Service Schedule.

- Remove oil dipstick and wipe dry with a clean, lint-free cloth.
- Install oil dipstick, wait approximately 10 seconds, then remove again.
- Oil should be between FULL and ADD marks.
- If oil level is below the dipstick ADD mark, remove oil fill cap-. Add the recommended oil to bring oil level up to the FULL mark. DO NOT FILL ABOVE THE "FULL" MARK. See "Engine Oil Recommendations" for recommended oils.

Figure 10.1 - Oil Dipstick and Oil Fill Cap



CHANGING ENGINE OIL

⚠ CAUTION!

⚡ Hot oil may cause burns. Allow engine to cool before draining oil. Avoid prolonged or repeated skin exposure with used oil. Thoroughly wash exposed areas with soap.

Refer to the Service Schedule for engine oil and filter change frequencies.

Drain the oil while the engine is still warm from running. This means warm up the engine, shut it down and drain immediately as follows:

1. Remove the drain hose from its retaining clip or cut the zip-tie securing the oil drain hose.
2. Loosen and remove OIL DRAIN HOSE CAP. Drain oil completely into suitable container.
3. When all oil has drained, install and tighten OIL DRAIN HOSE CAP and secure drain hose with a new zip-tie, or place the hose in its retaining clip.
4. Turn OIL FILTER (Figure 10.1) counterclockwise and remove. Properly dispose of old filter.
5. Apply light coating of new engine oil to seal of new oil filter. Install FILTER and tighten by hand only. DO NOT OVER TIGHTEN.
6. Remove OIL FILL CAP and add recommended oil. Crankcase oil capacity is listed in the "Specifications" section.

⚠ CAUTION!

⚡ After refilling the crankcase with oil, always check oil level on dipstick. NEVER OPERATE ENGINE WITH OIL BELOW THE DIPSTICK "ADD" MARK.

7. Start engine and check for oil leaks.
8. Shut OFF engine and wait 10 minutes for the oil to settle down into the oil pan. Recheck oil level on dipstick. DO NOT fill above the dipstick "FULL" mark.
9. Dispose of used oil at a proper collection center.

COOLING INTAKE/OUTLET

Air intake and outlet openings in the generator compartment must be open and unobstructed for continued proper operation. This includes such obstructions as high grass, weeds, brush, leaves and snow.

Without sufficient cooling and ventilating air flow, the engine/generator quickly overheats, which causes it to shut down. (See the installation diagram.)

⚠ WARNING!

⚡ The exhaust system parts from this product get extremely hot and remains hot after shutdown. High grass, weeds, brush, leaves, etc. must remain clear of the exhaust. Such materials may ignite and burn from the heat of the exhaust system.

INSPECT COOLING SYSTEM

- Inspect engine cooling system. See the Service Schedule.
- Check hoses for damage, deterioration, leaks, etc. Correct any discrepancies found.
- Check hose clamps for tightness.

ENGINE COOLANT

Check coolant level in coolant recovery bottle. See the Specifications and Service Schedule sections.

- Add recommended coolant mixture as necessary.
- Periodically remove radiator pressure cap (only when engine has cooled down) to make sure the coolant recovery system is functioning properly. Coolant should be at bottom of radiator filler neck. If coolant level is low, inspect gasket in radiator pressure cap. Replace cap, if necessary. To have pressure cap tested, contact a Service Facility. Inspect cooling system and coolant recovery system for leaks.

COOLANT CHANGE

Every year, have a service dealer drain, flush and refill the cooling system. See the Specifications and Service Schedule for cooling system recommendations.

OVERLOAD PROTECTION FOR ENGINE DC ELECTRICAL SYSTEM

Engine cranking, start up and running are controlled by a solid state Engine Controller circuit board. Battery voltage is delivered to that circuit board via the control panel fuse. This overcurrent protection device will open if the circuit is overloaded.

▲ CAUTION!

- ▲** If a circuit breaker opens or a fuse element melts, find the cause of the overload before resetting the circuit breaker or replacing the fuse.

PERFORM VISUAL INSPECTION

Complete a thorough visual inspection of the entire engine-generator monthly. Look for obvious damage, loose, missing or corroded nuts, bolts and other fasteners. Look for fuel, oil or coolant leaks.


INSPECT EXHAUST SYSTEM

Inspect the exhaust system at least once every year. Check all exhaust system pipes, mufflers, clamps, etc. for condition, tightness, leaks, security, damage.

CHECK FAN BELT

- Inspect fan belts every year. Replace any damaged, deteriorated, worn or otherwise defective belt.
- Check fan belt tension. Thumb pressure, exerted midway between pulleys, should deflect about 3/8 to 5/8 of an inch. This system uses an automatic belt tensioner and cannot be adjusted.

Figure 10.2 – Fan Belts




CHANGING THE ENGINE AIR FILTER

To replace the engine air filter, remove the air filter cover and replace the air filter making sure it is positioned properly before reattaching the cover (Figure 10.3).

See the Service Schedule for air filter maintenance.

Figure 10.3 – Engine Air Filter



SPARK PLUGS

Reset the spark plug gap or replace the spark plugs as necessary.


1. Clean the area around the base of the spark plugs to keep dirt and debris out of the engine. Clean by scraping or washing using a wire brush and commercial solvent. Do not blast the spark plugs to clean.
2. Remove the spark plugs and check the condition. Replace the spark plugs if worn or if reuse is questionable. See the "Service Schedule" section for recommended inspection.
3. Check the spark plug gap using a wire feeler gauge. See the Specifications section for the required spark plug gap.


BATTERY MAINTENANCE

The battery should be inspected per the Service Schedule section. The following procedure should be followed for inspection:

1. Inspect the battery posts and cables for tightness and corrosion. Tighten and clean as necessary.
2. Check the battery fluid level of unsealed batteries and, if necessary, fill with DISTILLED WATER ONLY. DO NOT USE TAP WATER IN BATTERIES.
3. Have the state of charge and condition checked. This should be done with an automotive-type battery hydrometer.


⚠ DANGER!

 Storage batteries give off explosive hydrogen gas. This gas can form an explosive mixture around the battery for several hours after charging. The slightest spark can ignite the gas and cause an explosion. Such an explosion can shatter the battery and cause blindness or other injury. Any area that houses a storage battery must be properly ventilated. Do not allow smoking, open flame, sparks or any spark producing tools or equipment near the battery.

 Battery electrolyte fluid is an extremely corrosive sulfuric acid solution that can cause severe burns. Do not permit fluid to contact eyes, skin, clothing, painted surfaces, etc. Wear protective goggles, protective clothing and gloves when handling a battery. If fluid is spilled, flush the affected area immediately with clear water.

 Do not use any jumper cables or booster battery to crank and start the generator engine. If the battery has completely discharged, remove it from the generator for recharging.

⚠ WARNING!

 Be sure the AUTO/OFF/MANUAL switch is set to the OFF position, before connecting the battery cables. If the switch is set to AUTO or MANUAL, the generator can crank and start as soon as the battery cables are connected.

 Be sure the 120VAC power supply to the battery is turned OFF, or sparking may occur at the battery posts as the cables are attached and cause an explosion.

BATTERY REPLACEMENT

NOTE:

Unit DOES NOT include battery.

When supplying or replacing the battery, the recommended number and type of battery is listed in the Specifications Section.

NOTE:

The BCI number should be located directly on the battery.

CLEANING THE STATIONARY EMERGENCY GENERATOR

Keep the generator as clean and as dry as possible. Dirt and moisture that accumulates on internal generator windings have an adverse effect on insulation resistance.

Periodically clean generator exterior surfaces. A soft brush may be used to loosen caked on dirt. Use a vacuum system or dry, low pressure air to remove any accumulations of dirt. The generator is housed inside an all-weather enclosure, clean the enclosure with a soft, damp cloth or sponge and water.

Once each year have the generator cleaned and inspected by a Service Dealer. That dealer will use dry, low pressure air to clean internal windings.

Finally, have the insulation resistance of stator and rotor windings checked. If insulation resistances are excessively low, the generator may require drying.

Service Schedule

SERVICE SCHEDULE

System / Component	Frequency	Procedure		
	Weekly - W Monthly - M Yearly - Y	Inspect	Change	Clean
Fuel				
Fuel Lines & Connections	M	X		
Lubrication				
Oil Level	M	X*		
Oil	Y		X**	
Oil Filter	Y		X**	
Cooling				
Engine Coolant Lines & Connections	M	X		
Engine Coolant Level	M	X		
Engine Coolant	Y		X	
Enclosure Louvers	W	X		X
Engine				
Air Cleaner	Y	X	X***	
Spark Plugs	Y	X	X***	
Battery				
Remove Corrosion, Ensure Dryness	M	X		X
Clean & Tighten Battery Terminals	M	X		X
Check Charge State	M	X	X***	
Check Electrolyte Level	M	X	X***	
General Condition				
Vibration, Noise, Leakage, Temperature	M	X		
Generator System				
Complete Tune-up and System Inspection	Y	To be completed by an Authorized Service Dealer.		
Footnotes				
* Inspect the oil level monthly or every 12 hours during continuous operation.				
** Change oil and oil filter after the first 30 hours of operation and then every 100 hours or annually thereafter, whichever occurs first. Change sooner when operating under heavy load or in a dusty or dirty environment or in high ambient temperatures.				
*** Replace as necessary.				

Troubleshooting

TROUBLESHOOTING GUIDE

PROBLEM	CAUSE	CORRECTION
Engine won't crank.	<ol style="list-style-type: none"> 1. Control panel 7.5 amp fuse blown. 2. Loose or corroded or defective battery cables. 3. Defective starter contactor. 4. Defective starter motor. 5. Dead or Defective Battery. 	<ol style="list-style-type: none"> 1. Replace fuse.* 2. Tighten, clean or replace battery cables as necessary.* 3. Replace contactor.* 4. Replace starter motor.* 5. Remove, change or replace battery.*
Engine cranks but won't start.	<ol style="list-style-type: none"> 1. Out of fuel. 2. Fuel solenoid (FS) is defective 3. Spark plugs defective. 	<ol style="list-style-type: none"> 1. Replenish fuel/turn on fuel valve. 2. Replace solenoid.* 3. Clean, regap or replace plugs.
Engine starts hard, runs rough.	<ol style="list-style-type: none"> 1. Air cleaner plugged or damaged. 2. Defective spark plugs. 3. Fuel pressure incorrect. 4. Insufficient fuel supply. 5. Fuel system set to wrong fuel type. 	<ol style="list-style-type: none"> 1. Clean or replace as needed. 2. Clean, regap or replace plugs. 3. Confirm fuel pressure to regulator is as recommended in SPECIFICATIONS.* 4. Confirm fuel pressure to regulator is as recommended in SPECIFICATIONS.* 5. Reconfigure the fuel system. (See RECONFIGURING THE FUEL SYSTEM in manual.*
Engine starts then shuts down.	<ol style="list-style-type: none"> 1. Engine oil level is low. 2. Engine is overheated. 3. Defective Low Oil Pressure Switch 4. Defective Coolant Temperature Switch 5. Defective Control Module circuit board. 6. Coolant Level is Low. 7. Defective Low Coolant Level Switch 	<ol style="list-style-type: none"> 1. Check oil and add oil as needed. 2. Check cooling system for leaks. 3. Replace switch.* 4. Replace switch.* 5. Replace board.* 6. Repair leak - Add coolant. 7. Replace Switch.*
AUTO/OFF/MANUAL Switch at OFF, engine continues to run.	<ol style="list-style-type: none"> 1. Defective AUTO/OFF/MANUAL switch 2. Defective Control Module circuit board 	<ol style="list-style-type: none"> 1. Replace board.* 2. Replace board.*
No AC output from generator.	<ol style="list-style-type: none"> 1. Main line circuit breaker is tripped/open. 2. Generator internal failure. 3. Thermal circuit breaker open. 	<ol style="list-style-type: none"> 1. Reset to ON/CLOSED. 2. * 3. Auto-reset - Wait 5 min. and attempt restart.

***Contact the nearest Dealer for assistance.**

United States Environmental Protection Agency Warranty Statement (Stationary Emergency Spark-Ignited Generators)

Warranty Rights, Obligations and Coverage

The United States Environmental Protection Agency (EPA) and Generac Power Systems, Inc. (Generac) are pleased to explain the Emission Control System Warranty on your new stationary emergency engine. If during the warranty period, any emission control system or component on your engine is found defective in materials or workmanship, Generac will repair your engine at no cost to you for diagnosis, replacement parts and labor provided it be done by a Generac Authorized Warranty Service Facility. Your emission control system may include parts such as the fuel metering, ignition, and exhaust systems and other related emission related components listed below. Generac will warrant the emissions control systems on your 2009 and later model year engines provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your engine. For engines less than 130 HP the warranty period is two years from the date of sale to the ultimate purchaser. For engines greater than or equal to 130 HP the warranty period is three years or 2500 hours of operation, whichever comes first, from the date of the engine being placed into service. For high-cost warranted components, the Emission Control System warranty is valid for 5 years or 3500 hours of operation, whichever comes first.

Purchaser's/Owner's Warranty Responsibilities

As the engine purchaser/owner you are responsible for the following: 1) The engine must be installed and configured in accordance to Generac's installation specifications. 2) The completion of all maintenance requirements listed in your Owner's Manual. 3) Any engine setting adjustment must be done in accordance and consistent with the instructions in the Owner's Manual. 4) Any emission control system or component must be maintained and operated appropriately in order to ensure proper operation of the engine and control system to minimize emissions at all times.

Generac may deny any/or all Emission Control System Warranty coverage or responsibility of the engine, or an emission control system or component on your engine thereof, if it has failed due to abuse, neglect, unapproved modification or improper maintenance, or the use of counterfeit and/or "gray market" parts not made, supplied or approved by Generac. Warranty service can be arranged by contacting either your selling dealer or a Generac Authorized Warranty Service dealer, 1-800-333-1322 for the dealer nearest you. The purchaser/owner shall be responsible for any expenses or other charges incurred for service calls and/or transportation of the product to/from the inspection or repair facilities. The purchaser/owner shall be responsible for any and/or all damages or losses incurred while the engine is being transported/shipped for inspection or warranty repairs. Contact Generac Power Systems Inc. for additional Emission Control System Warranty related information, Generac Power Systems, Inc., PO. Box 8, Waukesha, WI 53187, or call 1-800-333-1322 or www.generac.com.

Important Note

This warranty statement explains your rights and obligations under the Emission Control System Warranty, which is provided to you by Generac pursuant to federal law. Note that this warranty shall not apply to any incidental, consequential, or indirect damages caused by defects in materials or workmanship or any delay in repair or replacement of the defective part(s). This warranty is in place of all other warranties, expressed or implied. Specifically, Generac makes no other warranties as to the merchantability or fitness for a particular purpose. Any implied warranties which are allowed by law, shall be limited in duration to the terms of the express warranty provided herein. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Emission Related Parts Include the Following (if so equipped)

- | | |
|--|---|
| 1) Fuel Metering System | 3) Ignition System Including A) Spark Plug, B) Ignition Module, C) Ignition Coil, D) Spark Plug Wires |
| 1.1) Gasoline Carburetor Assembly and Internal Components
A) Fuel Filter, B) Carburetor, C) Fuel Pump | 4) Exhaust System
A) Catalyst Assembly*, B) Exhaust Manifold, C) Muffler, D) Exhaust Pipe, E) Muffler Gasket |
| 1.2) Carburetion Assembly and Its Components
A) Fuel Controller, B) Carburetor and Its Gaskets, C) Mixer and Its Gaskets, D) Primary Gas Regulator, E) Liquid Vaporizer | 5) Crankcase Breather Assembly Including
A) Breather Connection Tube, B) PCV Valve |
| 1.3) Fuel Regulator | 6) Oxygen Sensor |
| 2) Air Induction System Including A) Intake Pipe/Manifold, B) Air Cleaner | 7) Diagnostic Emission-Control System |

*High-Cost Warranted Component

United States Environmental Protection Agency Compliance Requirements (Stationary Emergency Spark-Ignited Generators)

Purchaser's/Owner's Record Keeping Responsibilities

The United States Environmental Protection Agency (EPA) and Generac Power Systems, Inc. (Generac) are pleased to explain your record keeping requirements for compliance with Subpart JJJJ- Standards of Performance for Stationary Spark Ignition Internal Combustion Engines as listed in the Electronic Code of Federal Regulations Title 40 Part 60. As the engine purchaser/owner who operates and maintains their certified emergency stationary engine and emission control system according to applicable emission related guidelines as specified in this Owner's Manual, you are required to meet the following notification and record keeping requirements to demonstrate compliance: 1) Maintain documentation that the engine is certified to meet emission standards. 2) Record keeping of maintenance conducted. 3) Record keeping of the provision allowing natural gas engines to operate using propane for a maximum of 100 hours per year as an alternate fuel solely during emergency operations provided the engine is not certified to operate on propane. 4) Meet all compliance notifications submitted to the purchaser/owner and maintain all supporting documentation. 5) Record keeping of hours of operation, including what classified the operation as emergency and how many hours are spent for non-emergency operation. For emergency engines greater than or equal to 130 HP, record keeping of hours of operation begins January 1, 2009; engines are equipped with non-resettable hour meters to facilitate record keeping.

Specific Air Quality Management or Air Pollution Control Districts may have different and additional record keeping/reporting requirements. Your permit to construct and/or operate the engine may be contingent upon compliance with those requirements. Check with your local Air Quality Management or Air Pollution Control District for specific requirements.

Emergency stationary internal combustion engines (ICE) may be operated for the purpose of maintenance checks and readiness testing, provided that the tests are recommended by Federal, State or local government, Generac, or the insurance company associated with the engine. Maintenance checks and readiness testing of such units is limited to 100 hours per year. There is no time limit on the use of emergency stationary ICE in emergency situations. The purchaser/owner may petition the Administrator for approval of additional hours to be used for maintenance checks and readiness testing, but a petition is not required if the owner maintains records indicating that Federal, State, or local standards require maintenance and testing of emergency ICE beyond 100 hours per year. Emergency stationary ICE may operate up to 50 hours per year in non emergency situations, but those 50 hours are counted towards the 100 hours per year provided for maintenance and testing.

The 50 hours per year for non-emergency situations cannot be used for peak shaving or to generate income for a facility to supply power to an electric grid or otherwise supply power as part of a financial arrangement with another entity. For purchaser/owner of emergency engines, any operation other than emergency operation, maintenance and testing, and operation in non-emergency situations for 50 hours per year, as permitted in this section is prohibited.

If you operate and maintain your certified emergency stationary SI internal combustion engine and emissions control systems in accordance to the specifications and guidelines in this Owner's Manual, EPA will not require engine performance testing. If not, your engine will be considered non-certified and you must demonstrate compliance according to Subpart JJJJ - Standards of Performance for Stationary Spark Ignition Internal Combustion Engines as listed in the Electronic Code of Federal Regulations Title 40 Part 60.


Emission-Related Installation Instructions

Your certified emergency stationary engine has pre-set emission control systems or components that require no adjustment. Inspection and replacement of an emissions related component is required to be done so in accordance with the requirements cited in the United States Environmental Protection Agency Warranty Statement or can be arranged by contacting either your selling dealer or a Generac Authorized Warranty Service dealer, 1-800-333-1322 for the dealer nearest you. Failing to follow these instructions when installing a certified engine in a piece of non-road equipment violates federal law 40 CFR 1068.105 (b), subject to fines or penalties as described in the Clean Air Act.

Notes

[illegible]

GROUP A



EXPLODED VIEW: EV ALTCOMPRT DIRECT B-CAN

DRAWING #: 0J5599A

GROUP A

ITEM	PART#	QTY.	DESCRIPTION
1	0G1931	1	ROTOR 25KW 3PH DIRECT 390 1800
	0G2101	1	ROTOR 25KW 1PH DIRECT 390 1800
	0G6568	1	RTR 390 45AD1 CPL
	0G6570	1	RTR 390 45KD1 CPL
2	0G1932	1	ASSY STR 390 25 GD1 CPL
	0G2098	1	ASSY STR 390 25AD1 CPL
	0G2099	1	ASSY STR 390 25KD1 CPL
	0G2100	1	ASSY STR 390 25JD1 CPL
	0G6365	1	STR 390 45JD1 CPL
	0G6569	1	STR 390 45AD1 CPL
	0G6571	1	STR 390 45GD1 CPL
	0G6572	1	STR 390 45KD1 CPL
	0H1299	1	ASSY STR 390 36AD1 CPL
	0H1300	1	ASSY STR 390 36JD1 CPL
	0H1301	1	ASSY STR 390 36 GD1 CPL
	0J5243	1	STR 390 48GD1 CPL
	0J5427	1	STR 390 48AD1 CPL
	0J6268	1	STR 390 48JD1 CPL
	0J6269	1	STR 390 48KD1 CPL
3	0C9708	REF	INSTR HYPOT TEST (NOT SHOWN)
4	SEE ENGINE EV	REF	ENGINE ADAPTER
5	SEE ENGINE EV	REF	FLEXPLATE
6	0F5767B	1	ASSY FLYWHEEL CPL W/40MM FAN B
7	0E5706	1	REAR BEARING CARRIER 390/DRCT
8	0F7874	1	ASSY BRUSH HOLDER 390/HSB
	0F7874A	1	ASSY BRUSH HOLDER 390/HSB
	(6) 0J7347	1	ASSY BRUSH HOLDER 390/HSB
	(6) 0J7347A	1	ASSY BRUSH HOLDER 390/HSB
9	077043A	1	CONDUIT FLEX .38" ID (60")
10	038150	4	WASHER FLAT #8 ZINC
11	023454	1	KEY WOODRUFF #E
12	077043F	1	CONDUIT FLEX 1.25"ID (35" LG)
13	04576100BU	4	STUD M14-2.0 X 570 G5 ZINC
	(5) 04576100BF	4	STUD M14-2.0 X 540 G5 ZINC
14	052646	4	WASHER FLAT M14
15	043123	4	WASHER LOCK M14
16	051779	4	NUT HEX M14-2.0 G8 YEL CHR
(2) 17	0A2601	1	SCREW HHC M16-2.0 X 45 G8.8
18	072879	1	SPACER .69 X 2.75 X .37 ST/ZNC
(2) 19	059980	4	SCREW HHC M10-1.5 X 25 C10.9
20	046526	4	WASHER LOCK M10
21	0C3993	4	SCREW HHTT M4-0.7 X 25 BP
22	022264	4	WASHER LOCK #8-M4
(1) 23	047248	1	BALL BEARING-45 MM
(1) 24	070892	1	SLIP RING MACHINED
(3) 25	0J7077	1	BLOCK OFF, ALTERNATOR AIR
	(6)(7) 0J7348	1	BLOCK OFF, ALTERNATOR AIR QTA
(3) 26	0J7077A	2	BLOCK OFF, ALT AIR LH/RH
(3) 27	0J7007	1	BAFFLE-ALT INLET
(3) 28	0J7086	1	PLATE LEAD CLAMP
(3) 29	0C2454	19	SCREW HWHT M6-1 X 16 N WA Z/JS
(3) 30	052250	1	TAPE FOAM 1X1 (166" LG)

EXPLODED VIEW: EV ALTCOMPRT DIRECT B-CAN**DRAWING #: 0J5599A****GROUP A**

ITEM	PART#	QTY.	DESCRIPTION
(8)31	0J81840ST0R	1	SCROLL TOP 390 ALT CPL
(8)32	0J8184AST0R	2	SCROLL FT/RR 390 ALT CPL
(8)33	0J8184BST0R	2	SCROLL LH/RH 390 ALT CPL
34	089685	4	GROMMET .75 X .12 X .50
35	089961A	1	FOAM STRIP 3/4"WIDE X 1/4"THK (120"LG)
36	0C2266	6	SCREW PHTT M5-0.8 X 16 ZP
(7)37	056326	1	TRIM VINYL BLACK 1/8GP (10" LG)

NOTES (UNLESS OTHERWISE SPECIFIED :

(1) ROTOR REPLACEMENT PARTS.

(2) APPLY MEDIUM STRENGTH BLUE THREAD LOCKING FLUID TO THREADS.

(3) NOT USED IN OPEN SETS.

(4) TORQUE VALUES: (FOR REFERENCE ONLY)

ITEM #16 - 45 ft-lbs.

ITEM #17 - 144 ft-lbs.

ITEM #19 - 56 ft-lbs.

(5) 5.4L ONLY

(6) QTA ONLY

(7) 60KW ONLY

(8) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.
- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

EXPLODED VIEW: EV ALTCOMPRT DIRECT B-CAN


DRAWING #: 0J5599A

GROUP A



ITEM	PART#	QTY.	DESCRIPTION
------	-------	------	-------------

This page left blank intentionally

225 AF




400 AF




C2 DPE BREAKER SELECTION		
MODEL RATING	ITEM 42 RATING	ITEM 42 P/N
4.2L 48KW - 3Ø	7A	048467
45KW - 1Ø	5A	048512
45KW - 3Ø	5.5A	054450
3ØKW / 4.2L 48KW / 60KW - 1Ø	6A	048505
36KW 3Ø	8A	048468
5.4L 48KW 1Ø	9A	048470
5.4L 48KW 3Ø		
60KW 3Ø		

FG




NOTE:
NUT KEEPER PROVIDED
WITH CB FOR LINE SIDE
LUG CONNECTION.

CC (2P & 3P)




KG



NOTE:
NUT KEEPER PROVIDED
WITH CB FOR LINE SIDE
LUG CONNECTION.

JG



NOTE:
NUT KEEPER PROVIDED
WITH CB FOR LINE SIDE
LUG CONNECTION.



ED

Diagram illustrating the assembly components and sequence for the ED series display:

- A:** Main display unit.
- B:** Bezel/frame.
- C:** Mounting bracket.
- D:** Mounting plate.
- E:** Mounting plate.
- F:** Mounting bracket.
- G:** Mounting bracket.
- H:** Mounting bracket.
- I:** Mounting bracket.
- J:** Mounting bracket.
- K:** Mounting bracket.
- L:** Mounting bracket.
- M:** Mounting bracket.
- CONNECTION BOX:** External connection box.

Assembly sequence indicated by arrows:

- TO "A"
- TO "B"
- TO "C"
- TO "D"
- TO "E"
- TO "F"
- TO "G"
- TO "H"
- TO "I"
- TO "J"
- TO "K"
- TO "L"
- TO "M"
- TO "CONNECTION BOX"

[illegible]

EXPLODED VIEW: EV CONBOX C2 CPL

DRAWING #: 0J8319

GROUP A

APPLICABLE TO:

ITEM	PART#	QTY.	DESCRIPTION
PAGE 1			
1	0J8300	1	BACK PANEL CONBOX SUPPORT C2
2	0H6265	1	TOP PANEL CONBOX SUPPORT C2
3	0H6160	1	COVER WIRE ENTRY CONBOX
4	057073	2	JUNCTION BLOCK 3/8-16
5	056739	1	RELAY SOLENOID 12VDC PNL MNT
(6)6	0H67330STOR	1	BRACKET GIMBAL CONTROL PNL RAW
7	REF	1	ASSY CTRL PROGRAMMED
8	0A2115	2	WASHER FLAT NYLON 0.257 X 0.625
9	022097	3	WASHER LOCK M6-1/4
10	022473	8	WASHER FLAT 1/4-M6 ZINC
11	0H7115	2	KNOB M6-1.0 CONTROL PANEL
12	0C2454	13	SCREW HWHT M6-1 X 16 N WA Z/JS
13	0F5458	12	SCREW HHSP #10 X 3/8 HI-LOW
14	042568	2	SCREW HHC M6-1.0 X 20 C8.8
(6)15	0H88390STOR	1	SHIELD HIGH/LOW C2 RAW
16	0C2265	4	SCREW PHTT M4-0.7 X 12 ZP
17	(3)0H6169B	1	ASSY PROG 2010 IGN MOD 6 CYL
	(7)0H6169C	1	ASSY PROG 2010 IGN MOD 8 CYL
(3)18	023897	4	WASHER FLAT #10 ZINC
(3)19	036943	2	SCREW PPHM #10-32 X 2
(3)20	022152	2	WASHER LOCK #10
(3)21	022158	2	NUT HEX #10-32 STEEL
(3)22	055934D	1	CLAMP STL/VNL 1.06 X .406 Z
(2)23	0D5464B	1	NEUTRAL BLOCK 390/200-400A
24	022237	2	WASHER LOCK 3/8
25	022241	2	NUT HEX 3/8-16 STEEL
26	0D3700	6	NUT FLANGE M6-1.0 NYLOK
27	0H6267	1	COVER VOLTAGE SHIELD
28	0F5752F	1	RES WW 15R 5% 25W QK CONN
29	052777	3	WASHER FLAT M3
30	043182	3	WASHER LOCK M3
31	051714	3	NUT HEX M3-0.5 G8 CLEAR ZINC
32	0D7177V	2	DIODE BRIDGE 1P 35A 1000V
33	051713	2	WASHER FLAT M5
34	049226	2	WASHER LOCK M5
35	051716	2	NUT HEX M5-0.8 G8 CLEAR ZINC
36	056326	1	TRIM VINYL BLACK 1/8GP (3"LG)
37	0J0489	1	DECAL CUSTOMER POWER CONNECT
38	0H7292	1	DECAL CUSTOMER CONTROL CONNECT
39	0H7293	1	DECAL CONBOX TB1 CONNECTIONS
40	026850	1	WASHER LOCK EXT 1/4 STL
41	055414	1	LUG SLDLSS #2-#8 X 17/64 CU
(4)42	SEE CHART	1	CIRCUIT BREAKER
(6)43	0H81040AS0R	1	COVER DPE BREAKER NEXUS RAW
44	0A9457	1	DECAL NEUTRAL
45	022264	4	WASHER LOCK #8-M4
46	045764	2	SCREW HHTT M4-0.7 X 8 ZP
47	067210A	1	DECAL GROUND LUG
(1)48	0D7393T	REF	TERM BLOCK 3P UL 12-20AWG
(1)49	0D7393U	REF	TERM BLOCK 4P UL 12-20AWG
(1)50	0F5376S0AR	REF	MX150L SLRRMNT 22-18 8P W/O GA
(1)51	0F5396S0AR	REF	MX150L SLRRMNT 22-18 12P W/OGA
(2)52	0A7822	REF	LUG SLDLSS 600/250-1/0X1/4-28
(2)53	083896	REF	WASHER LOCK 1/4-M6 SS
(2)54	045335	REF	SCREW HHC 1/4-28 X 3/4 G5
55	029289	1	TAPE ELEC 1/2 FOAM (69"LG)
56	0F6146	1	HANG TAG 2 WIRE START (NOT SHOWN)
57	0H6692	1	HARN CONBOX NEXUS (NOT SHOWN)
58	0D6029	5	SCREW HHTT M6-1.0 X 16 ZYC
59	0D7178T	REF	FUSE ATO TYPE 7.5AMP (BROWN)
60	0J3060	1	GASKET WIRE ENTRY COVER
61	0H8006	1	DECAL CAUTION ELEC SHOCK SM

EXPLODED VIEW: EV CONBOX C2 CPL**DRAWING #: 0J8319****GROUP A****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
UL CIRCUIT BREAKER (225AF)			
A	0G5250	1	CB 175A 2 POLE 240V 225AF
B	0H7356	1	COVER CB C2 CPL
C	0F4186AGS0R	1	COVER CB DISH 2P G 225AF
D	0F8432A	1	INSULATOR CB 2P 225AF
E	0H7311	1	STANDOFF CB BOX CONBOX
F	045771	2	NUT HEX M8-1.25 G8 CLEAR ZINC
G	036261	4	RIVET POP .125 X .275 SS
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	053640	2	SCREW RHM #8-32 X 3-1/4
K	038150	2	WASHER FLAT #8 ZINC
L	022264	2	WASHER LOCK #8-M4
M	022471	2	NUT HEX #8-32 STEEL
N	049897	4	SCREW SHC M8-1.25 X 20 G8
P	022129	6	WASHER LOCK M8-5/16
R	022145	4	WASHER FLAT 5/16-M8 ZINC
S	058306	2	SCREW SHC M8-1.25 X 25 C12.9
T	0F8843	2	BUS BAR 200A LUG ADAPTOR
U	0F8451	2	LUG SLDLSS 300 MCM-6 AL/CU
V	0G3259	1	DECAL TERMINAL SHOCK HZD BI
(6)W	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
X	0J7872	1	GASKET-CB SHIELD C2
Y	0E3257	2	SCREW HWHTF M6-1.0 X 16
UL CIRCUIT BREAKER (400AF)			
A	0F4153	1	CB 0250A 3P 480V G 400AF
B	0H6735	1	COVER CB 400AF C2 CONBOX
C	0A7822	3	LUG SLDLSS 600/250-1/0X1/4-28
D	0H6734	1	STANDOFF CB MOUNT CONBOX
E	042419	4	SCREW RHM 10-32 X 4
F	022097	6	WASHER LOCK M6-1/4
G	052647	6	SCREW SHC M10-1.5 X 25 C12.9
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	046526	6	WASHER LOCK M10
K	023897	4	WASHER FLAT #10 ZINC
L	022152	4	WASHER LOCK #10
M	022158	4	NUT HEX #10-32 STEEL
N	023334	6	SCREW HHC 1/4-28 X 1/2 G5
P	022473	6	WASHER FLAT 1/4-M6 ZINC
Q	0G3259	1	DECAL TERMINAL SHOCK HZD BI
(6)R	0J7874AST0R	1	SHIELD-LGE CIRCUIT BREAKER
S	0J7872	1	GASKET-CB SHIELD C2
T	0E3257	2	SCREW HWHTF M6-1.0 X 16

(1) ITEMS INCLUDED WITH HARNESS P/N 0H6692.

(2) ITEMS INCLUDED WITH NEUTRAL BLOCK P/N 0D5464B.

(3) ITEMS INCLUDED WITH 4.2L MODELS ONLY.

(4) SEE "C2 DPE BREAKER SELECTION" TABLE.

(5) QTY. REQ. FOR 2 POLE BREAKER / QTY. REQ. FOR 3 POLE BREAKER.

(6) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.
- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

(7) ITEMS INCLUDED WITH 5.4L MODELS ONLY.

EXPLODED VIEW: EV CONBOX C2 CPL

DRAWING #: 0J8319

GROUP A

APPLICABLE TO:

ITEM	PART#	QTY.	DESCRIPTION
------	-------	------	-------------

PAGE 2

UL CIRCUIT BREAKER (KG)

A	0H5582	1	CB 0300 3P 600V E KG LL
B	0H6740	1	COVER CB E KG C2 CONBOX
C	0D3700	4	NUT FLANGE M6-1.0 NYLOK
D	0H5581A	1	INSULATOR CB E 3P KG
E	0H6734	1	STANDOFF CB MOUNT CONBOX
G	022129	3	WASHER LOCK M8-5/16
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	0D2157	4	SCREW SHC M6-1.0 X 50 C8.8
K	049821	3	SCREW SHC M8-1.25 X 30 C12.9
L	022145	3	WASHER FLAT 5/16-M8 ZINC
(6)M	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
N	0J7872	1	GASKET-CB SHIELD C2
P	0E3257	2	SCREW HWHTF M6-1.0 X 16

UL CIRCUIT BREAKER (FG)

A	0H5486	1	CB 0060 3P 480V E FG LL
B	0H7356	1	COVER CB C2 CPL
C	0H7434	1	COVER CB DISH 3P E FG
D	0H4698A	1	INSULATOR CB 3P E TYPE CC/FG
E	0H7311	1	STANDOFF CB BOX CONBOX
F	022471	4	NUT HEX #8-32 STEEL
G	036261	4	RIVET POP .125 X .275 SS
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	0H5721	4	SCREW PPHM #8-32 X 1-3/4 ZINC
K	022264	4	WASHER LOCK #8-M4
L	038150	4	WASHER FLAT #8 ZINC
M	052619	3	SCREW HHC M5-0.8 X 20 G8.8
N	023897	3	WASHER FLAT #10 ZINC
P	049226	3	WASHER LOCK M5
(6)R	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
S	0J7872	1	GASKET-CB SHIELD C2
T	0E3257	2	SCREW HWHTF M6-1.0 X 16

UL CIRCUIT BREAKER (JG)

A	0H5580	1	CB 0250 3P 600V E JG LL
B	0H6739	1	COVER CB E JG C2 CONBOX
D	0H5576A	1	INSULATOR CB E 3P JG
E	0H6734	1	STANDOFF CB MOUNT CONBOX
F	022127	4	NUT HEX 1/4-20 STEEL
G	022097	4	WASHER LOCK M6-1/4
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	022770	4	SCREW RHM 1/4-20 X 3
K	022473	4	WASHER FLAT 1/4-M6 ZINC
L	049897	3	SCREW SHC M8-1.25 X 20 G8
M	022145	3	WASHER FLAT 5/16-M8 ZINC
N	022129	3	WASHER LOCK M8-5/16
(6)P	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
R	0J7872	1	GASKET-CB SHIELD C2
S	0E3257	2	SCREW HWHTF M6-1.0 X 16

EXPLODED VIEW: EV CONBOX C2 CPL**DRAWING #: 0J8319****GROUP A****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
UL CIRCUIT BREAKER (CC(2P & 3P))			
A	0H4748	1	CB 0175A 2P 240V E CC LL
	0H4915	1	CB 0150 3P 240V E CC LL
B	0H7356	1	COVER CB C2 CPL
C	0H7432	1	COVER CB DISH 2P E CC
	0H7433	1	COVER CB DISH 3P E CC
(5)D	051716	2/3	NUT HEX M5-0.8 G8 CLEAR ZINC
E	0H7311	1	STANDOFF CB BOX CONBOX
(5)F	022471	2/4	NUT HEX #8-32 STEEL
G	036261	4	RIVET POP .125 X .275 SS
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
(5)J	053640	2/4	SCREW RHM #8-32 X 3-1/4
(5)K	022264	2/4	WASHER LOCK #8-M4
(5)L	038150	2/4	WASHER FLAT #8 ZINC
(5)M	052619	2/3	SCREW HHC M5-0.8 X 20 G8.8
(5)N	023897	4/6	WASHER FLAT #10 ZINC
(5)P	049226	2/3	WASHER LOCK M5
(6)R	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
S	0J7872	1	GASKET-CB SHIELD C2
T	0E3257	2	SCREW HWHTF M6-1.0 X 16

(5) QTY. REQ. FOR 2 POLE BREAKER / QTY. REQ. FOR 3 POLE BREAKER.

(6) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

• MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.

• CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

PAGE 3

UL CIRCUIT BREAKER (QN)

A	0E7284	1	CB 0175A 2P 240V S QN2 LL
B	0H7356	1	COVER CB C2 CPL
C	0H7429	1	COVER CB DISH 2P S QN
D	0E3664	1	BASE, QN CIRCUIT BREAKER
E	0H7311	1	STANDOFF CB BOX CONBOX
F	074908	2	SCREW HHTT M5-0.8 X 10 BP
G	036261	4	RIVET POP .125 X .275 SS
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
(6)J	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
K	0J7872	1	GASKET-CB SHIELD C2
L	0E3257	2	SCREW HWHTF M6-1.0 X 16

UL CIRCUIT BREAKER (ED)

A	0D9693	1	CB 0125A 3P 480V S ED4 LL
B	0H6736	1	COVER CB S ED C2 CONBOX
C	022158	4	NUT HEX #10-32 STEEL
D	0F0492	1	INSULATOR CB S(ED-3P)
E	0H6734	1	STANDOFF CB MOUNT CONBOX
F	022152	4	WASHER LOCK #10
G	023897	4	WASHER FLAT #10 ZINC
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	048927	4	SCREW RHM #10-32 X 4-1/2
(6)K	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
L	0J7872	1	GASKET-CB SHIELD C2
M	0E3257	2	SCREW HWHTF M6-1.0 X 16

EXPLODED VIEW: EV CONBOX C2 CPL**DRAWING #: 0J8319****GROUP A****APPLICABLE TO:**


ITEM	PART#	QTY.	DESCRIPTION
UL CIRCUIT BREAKER (VL)			
A	0H7519	1	CB 0300A 3P 600V S JG-VL LL
B	0H6738	1	COVER CB S JG VL C2 CONBOX
C	040976	3	SCREW SHC M8-1.25 X 20 C12.9
D	022129	3	WASHER LOCK M8-5/16
E	0H6734	1	STANDOFF CB MOUNT CONBOX
F	022145	3	WASHER FLAT 5/16-M8 ZINC
G	023897	4	WASHER FLAT #10 ZINC
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	042419	4	SCREW RHM 10-32 X 4
K	022152	4	WASHER LOCK #10
L	022158	4	NUT HEX #10-32 STEEL
(6)M	0J7874AST0R	1	SHIELD-LGE CIRCUIT BREAKER
N	0J7872	1	GASKET-CB SHIELD C2
P	0E3257	2	SCREW HWHTF M6-1.0 X 16
UL CIRCUIT BREAKER (FD)			
A	0D5572	1	CB 0150A 3P 600V S FD6 LL
B	0H6737	1	COVER CB S FD6 C2 CONBOX
C	081320	4	SCREW SHC 1/4-20 X 4.5 G8.8 NZ
D	0F0199	1	INSULATOR CB FD FRAME 30MIL
E	0H6734	1	STANDOFF CB MOUNT CONBOX
F	022473	4	WASHER FLAT 1/4-M6 ZINC
G	022097	4	WASHER LOCK M6-1/4
H	0C2454	12	SCREW HWHT M6-1 X 16 N WA Z/JS
J	022127	4	NUT HEX 1/4-20 STEEL
(6)K	0J78740ST0R	1	SHIELD-SM CIRCUIT BREAKER
L	0J7872	1	GASKET-CB SHIELD C2
M	0E3257	2	SCREW HWHTF M6-1.0 X 16

(6) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

• MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.

• CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

GROUP A



EXPLODED VIEW: EV MTG BASE 5.4L G3**DRAWING #: 0J5600A****GROUP C**


ITEM	PART#	QTY.	DESCRIPTION
(1)1	0L06870ST0R	1	WELDMENT BASEFRAME 5.4L G3
2	065852	1	SPRING CLIP HOLDER .37-.62
3	052252	4	DAMPENER VIBRATION
4	052257	4	SPACER .49 X .62 X 1.87 PWDR/ZINC
5	052259	4	WASHER FLAT M12
6	055597	4	SCREW HHC M12-1.75 X 85 G8.8
7	052251A	4	DAMPENER VIBRATION 50 WHITE
8	052860	4	NUT LOCKING M12-1.75
(1)9	0L01140ST0R	1	ENGINE MOUNT 5.4L LH SIDE
10	045764	1	SCREW HHTT M4-0.7 X 8 BP
11	051735	2	SCREW HHC M10-1.5 X 70 C8.8
12	055414	1	LUG SLDLSS #2-#8 X 17/64 CU
13	047411	1	SCREW HHC M6-1.0 X 16 C8.8
16	052243	4	SCREW HHC M10-1.5 X 60 C8.8
17	022131	6	WASHER FLAT 3/8-M10 ZINC
18	046526	6	WASHER LOCK M10
19	0536210410	1	ASSY WIRE 14.00"
20	042909	1	SCREW HHC M8-1.25 X 30 G8.8
21	0C3168	1	WASHER LOCK SPECIAL 5/16
22	022129	1	WASHER LOCK M8-5/16
23	022097	1	WASHER LOCK M6-1/4
24	045771	2	NUT HEX M8-1.25 G8 YEL CHR
(1)25	0L01150ST0R	1	ENGINE MOUNT 5.4L RH SIDE
26	022473	2	WASHER FLAT 1/4-M6 ZINC
27	0A1658	1	WASHER LOCK SPECIAL 1/4"
28	0C2454	2	SCREW HWHT M6-1 X 16 N WA Z/JS
29	0J6549	1	BLOCK OFF, ALTERNATOR
30	0A4456	1	WASHER LOCK SPECIAL 3/8
31	057644	1	SCREW HHC M10-1.5 X 100 C8.8
32	0L0123	1	SPACER .41 X .75 X 1.68 ST/ZNC
(1) 33	0L01390ST0R	1	5.4L RH ENGINE MOUNT SPACER

NOTES (UNLESS OTHERWISE SPECIFIED):

(1) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO XA BOM.
- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).


GROUP C



EXPLODED VIEW: EV BATT ACSRY 5.4L G3 W/O BATT**DRAWING #: 0J7828****GROUP C**

ITEM	PART#	QTY.	DESCRIPTION
1	0F3408	1	TRAY BATTERY
2	0F3411	1	STRAP BATTERY RETAINMENT
3	051768	1	SCREW HHC M12-1.75 X 25 G8.8
4	022145	1	WASHER FLAT 5/16-M8 ZINC
5	022195	1	WASHER LOCK 1/2
6	022304	1	WASHER FLAT 1/2 ZINC
7	050331A	1	BATTERY POST COVER RED +
8	050331	1	BATTERY POST COVER BLACK -
9	038804U	1	CABLE BATT RED #1 X 28.00
10	038805Y	1	CABLE BATT BLK #1 X 16.00 NEG
11	045771	1	NUT HEX M8-1.25 G8 YEL CHR
12	022129	1	WASHER LOCK M8-5/16
13	025507	1	WASHER SHAKEPROOF EXT 7/16 STL
14	0F3976	1	BOOT CONTACTOR CABLES
15	0C2454	2	SCREW THF M6-1 X 16 N WA Z/JS
16	042568	2	SCREW HHC M6-1.0 X 20 G8.8
17	022097	2	WASHER LOCK M6-1/4
18	049813	2	NUT HEX M6 X 1.0 G8 YEL CHR
19	058208	REF	BATT 12VDC 24F 525 CCA (SOLD AS AN OPTION)

GROUP D




EXPLODED VIEW: EV AIR CLEANER**DRAWING #: 0F9809****GROUP D**

ITEM	PART#	QTY.	DESCRIPTION
1	0E6586	1	GASKET BOSCH 32 & 40
2	0E0519A	1	ADAPTER CARBURETOR W/PVC CONN
3	0C8127	1	ELEMENT AIR CLEANER
4	049815	4	SCREW HHC M5-0.8 X 16 G8.8
5	022127	1	NUT HEX 1/4-20 STEEL
(1) 6	062974	1	STUD TH 1/4-20 X 4-1/2 G2 ZNC
7	0G0190	1	PLATE, AIR CLEANER TOP 2.4L
8	025870	1	NUT WING 1/4-20
9	022097	1	WASHER LOCK M6-1/4
10	022473	1	WASHER FLAT 1/4-M6 ZINC

(1) APPLY MEDIUM STRENGTH BLUE THREAD LOCKING FLUID TO THREADS.

GROUP D



BEARING PRESS NOTE:
 APPLY LOCTITE 620 BEARING RETAINMENT COMPOUND TO BEARING SURFACE ON ITEM 37 PRIOR
 TO PRESSING ITEM 28 ONTO ITEM 37. ALSO APPLY LOCTITE 620 BEARING RETAINMENT COMPOUND
 TO THE OUTSIDE OF 28 PRIOR TO INSTALLING ITEM 28 INTO ITEM 38.

REFER TO BEARING
 PRESS NOTE

EXPLODED VIEW: EV COOLING SYSTEM 5.4L C2**DRAWING #: 0J5601A****GROUP D**

ITEM	PART#	QTY.	DESCRIPTION
(5)1	0J57770ST0R	1	WELDMENT RADIATOR SUPPORT C2
2	0F2608D	1	RADIATOR 598 X 568 X 19,CPL LH
3	0J6435	1	V-BELT A51 (53IN O.C)
4	046526	5	WASHER LOCK M10
(1) 5	059981	4	SCREW HHC M10-1.5 X 30 G10.9
(5)7	0J89380ST0R	1	SHIELD RADIATOR C2
9	0J6178	1	PULLEY FAN, V-GROOVE
10	0F4011	1	FAN COOL 22" DIA 10 BLADE LH
11	0H20620ST03	1	ARM BELT TENSIONER
(1) 12	0H2051	1	SHOULDER BOLT 1/2 X 2-1/4"
13	0F2862	1	SPRING TENSION CPL
14	0F2560	1	PULLEY V-BELT 4" FLANGED
15	022131	4	WASHER FLAT 3/8-M10 ZINC
16	0H1827	1	PROBE COOLANT LEVEL 3/8-18NPTF
17	035685	2	CLAMP HOSE #28 1.32-2.25
18	0F2561	1	HUB FLEX PLATE
19	0C8145	8	WASHER FLEX (THIN)
20	052250	2	TAPE FOAM 1 X 1 (26.75" LG)
21	0C7043	12	DISK FLEX
23	022473	8	WASHER FLAT 1/4-M6 ZINC
(1) 24	0C8146	4	SCREW HHC 5/16-24 X 1.124
25	022097	16	WASHER LOCK M6-1/4
26	076749	1	TANK COOLANT RECOVERY
(2) 27	048031C	2(REF)	CLAMP HOSE BAND 1/4
28	031971	1	BEARING #6205 2NSE C3 E SRI2 S
29	0F4030	1	PULLEY 6" DIA MACHINED
(1) 30	042911	1	SCREW HHC M10-1.5 X 30 G8.8
31	0F2872	1	SCREW HHC 1/2-13 X 2" G8
32	022304	1	WASHER FLAT 1/2 ZINC
33	022195	1	WASHER LOCK 1/2
34	022196	1	NUT HEX 1/2-13 STEEL
35	0F8651	8	SCREW HHFC M8-1.25 X 20 W/M6
36	052677	1	WASHER NYLON .50 X .87 X .06
37	0F9867B	1	SHAFT FAN DRIVE
38	0F2461	1	RETAINER BEARING
39	022145	13	WASHER FLAT 5/16-M8 ZINC
40	022129	9	WASHER LOCK M8-5/16
(1) 41	039287	1	SCREW HHC M8-1.25 X 45 C8.8
42	082774	1	KEY WOODRUFF 4 X 19D
43	0J5742	1	HOSE LOWER RAD CPL C2 5.4L
44	0J5751	1	HOSE RADIATOR UPPER C2 CPL
45	049813	8	NUT HEX M6 X 1.0 G8 YEL CHR
46	052644	1	SPACER .5 X 1.5 X .25 STL/ZINC
47	0C8566	16	SCREW HHFC M6-1.0 X 20 G8.8
48	0C2454	5	SCREW THF M6-1 X 16 N WA Z/JS
49	090283	1	CAP RADIATOR 13 PSI
(5)50	0L01050ST0R	1	BRACKET COOLANT TANK
51	029032	1	HOSE 9/32 ID (60"LG)
52	0H5380	1	COUPLING FLEX HUB MACHINED
(1) 53	0F2012	1 (REF)	SCREW HHC M12-1.5 X 70 C10.9
54	099502	2	CLAMP HOSE #24 B1.06-2.00
55	049820	2	NUT HEX LOCK M8-1.25 NY INS
56	0H30880ST03	1	BRACKET TENSIONER SPRING
(3) 57	0H2844	2 (REF)	BEARING SLEEVE 1/2/ X 3/4 X 1
(5)58	0G53150AL0R	1	SPACER CPL COOLING FAN 1/8"
59	039253	2	SCREW HHC M8-1.25 X 20 C8.8

EXPLODED VIEW: EV COOLING SYSTEM 5.4L C2**DRAWING #: 0J5601A****GROUP D**

ITEM	PART#	QTY.	DESCRIPTION
61	0C8165	2	NUT HEX LOCK 5/16-24 NY INS
62	0D3700	8	NUT FLANGE M6-1.0 NYLOK
63	029333A	9	TIE WRAP UL 7.4" X .19" BLK (NOT SHOWN)
64	051769	3	WASHER LOCK M12
(4)65	072252	1	GROMMET 1.37 X .06 X 1.00
(4)66	055934M	1	CLAMP STL/VNL .75 X .343 Z
67	089961	2	FOAM STRIP 3/4"WIDE X 3/16"THK (12"LG)
68	048031C	1	CLAMP HOSE BAND .50
69	029032	1	HOSE 9/32 ID (27"LG)
70	085662	3	TIE WRAP UL 14.6 X .14 BLK (NOT SHOWN)

NOTES(UNLESS OTHERWISE SPECIFIED):

(1) APPLY MEDIUM STRENGTH BLUE THREAD LOCKING FLUID TO THREADS.

(2) INCLUDED WITH I/N 26.

(3) ITEM 57 IS INCLUDED WITH ITEM 1.

(4) ONLY REQUIRED ON CATALYZED UNITS.

(5) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.


- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

(6) FASTEN HOSE TO RADIATOR SUPPORT USING TIE WRAP I/N 70. DIRECT HOSE TOWARD BASE OF UNIT AND AWAY FROM EXHAUST COMPONENTS.

ITEM	PART#	QTY.	DESCRIPTION
------	-------	------	-------------

This page left blank intentionally

GROUP D




EXPLODED VIEW: EV ENGCOMPRT 5.4L CPL R/H**DRAWING #:0J5602A****GROUP D**

ITEM	PART#	QTY.	DESCRIPTION
1	0D9913	16	SCREW SHC M8-1.25 X 35 SS
2	0G7461	1	STARTER MOTOR 12V
3	0F3514	1	SPACER FLEXPLATE 5.4L/6.8L (1800 RPM ONLY)
4	0F9965C	1	FLEX PLATE 2 POLE 5.4L/6.8L (1800 RPM UNITS ONLY)
5	022097	1	WASHER LOCK M6-1/4
6	0D5417	8	SCREW HHC M10-1.0 X 25 G10.9
7	0A5768	8	WASHER FLAT M10 HEAVY DUTY
(1) 8	029333A	1	TIE WRAP UL 7.4" X .19" BLK (NOT SHOWN)
9	022131	1	WASHER FLAT 3/8-M10 ZINC
10	055596	1	BARBED STR 3/8 NPT X 3/8
11	057772	1	WASHER NYLON .565
(2) 12	0F7316C150	1	CAP, OIL FILLER
13	057765	1	ADAPTER M14-1.50 X 3/8 NPTA
14	0F3534	2	HEAT SHLD EXHAUST MANIFOLD
15	069860B	1	HOSE OIL DRAIN ASSY 16"
16	049821	2	SCREW SHC M8-1.25 X 30 G12.9
17	022129	4	WASHER LOCK M8-5/16
18	039253	1	SCREW HHC M8-1.25 X 20 G8.8
19	0D2244M	1	ASSY MAGPICKUP(3/8-24 MALE)
20	049340	1	BARBED EL 90 1/4NPT X 3/8
21	046526	6	WASHER LOCK M10
22	0F5454	1	PLATE MAG PICK-UP ADAPTOR
23	071623	4	SCREW SHC M10-1.5 X 55 G12.9
(2) 24	0F5114	1	DECAL REFER TO OWNERS MANUAL
25	0D2608	8	SCREW HHC 5/16-18 X 1/2 SSTL
26	0F1820	2	MACHINED MANIFOLD EXHAUST 5.4L
27	070008	8	WASHER FLAT M8 SS
28	070006	24	WASHER LOCK M8 SSTL
29	0C7649	1	CLAMP HOSE .38-.87
30	0F2929	1	ENGINE ADAPTER 5.4L/6.8L
31	047411	1	SCREW HHC M6-1.0 X 16 C8.8
32	0F5755	2	GASKET, EXHAUST MANIFOLD
33	048031P	2	CLAMP HOSE BAND .88"
34	0G0321	1	HOSE COOL 5/8"ID 250#WP (2" LG)
35	0G1462	1	HOSE BARB REDUCER 5/8"-3/8"ID
36	048031J	2	CLAMP HOSE BAND .63
37	047290	1	HOSE 3/8 ID SINGLE BRAID (15" LG)
38	055934M	1	CLAMP STL/VNL .75 X .343 Z
39	022473	1	WASHER FLAT 1/4-M6 ZINC

(1) I/N 8 USED FOR HOLDING SENSOR TO I/N 5.

(2) PART OF ENGINE MAKE P/N 0J6390A.

GROUP D



EXPLODED VIEW: EV ENGCOMPRT 5.4L CPL L/H

DRAWING #: 0H5602B

GROUP D

APPLICABLE TO:

ITEM	PART#	QTY.	DESCRIPTION
(1)1	0J6240	1	5.4L G3 - LONG BLOCK
(1)2	042568	1	SCREW HHC M6-1.0 X 20 C8.8
(1)3	0H56090ST03	1	BRACKET DIPSTICK TUBE
(1)4	0F2843	1	GASKET THERMOSTAT HOUSING
(1)5	0D5419	REF	OIL FILTER V-10 ENGINE
(1)6	0F7316C161	1	TUBE DIPSTICK
7	0D3488J	1	BELT SERPENTINE 65.3" (2650 RPM)
(1)8	051731	9	SCREW HHC M8-1.25 X 50 C8.8
9	0G0321	1	HOSE COOL 5/8"ID 250#WP (2" LG)
(1)10	0J6240E	1	5.4L G3 - THERMOSTAT
(1)11	055440	8	SCREW HHC M5-0.8 X 25 C8.8 BLK
(1)12	0G5515B	1	ADAPTER THERMOSTAT 4.6L G3
(1)13	0G5511	1	GASKET THERMOSTAT 4.2L
(1)14	0H3920	1	SPACER COOLANT BYPASS
15	035579	1	BSHG RDCR HEX 1/4 TO 1/8
(1)16	0J6240F	1	5.4L G3 - THERMOSTAT OUTLET
(1)17	0F7316C160	1	DIPSTICK
(1)18	0H0550	1	DECAL EPA STATIONARY EMERGENCY
(1)19	022097	1	WASHER LOCK M6-1/4
(1)20	022473	1	WASHER FLAT 1/4-M6 ZINC
21	042568	1	SCREW HHC M6-1.0 X 20 C8.8
22	022129	5	WASHER LOCK M8-5/16
23	0H7435	1	HARN LOW OIL PRESS SWITCH ASSY
24	0E9868A	1	ALTERNATOR DC W/OUT PULLEY
25	022145	5	WASHER FLAT 5/16 ZINC
(1)26	051713	8	WASHER FLAT M5
27	0F3216	1	PULLEY 80 OD DC ALTERNATOR (1800RPM)
	0F3216B	1	PULLEY 117 OD DC ALTERNATOR (2650 RPM)
	0F3216D	1	PULLEY 160 OD DC ALTERNATOR (3600 RPM)
28	0F3217	1	SPACER DC ALTERNATOR PULLEY
29	0F3287	1	BRKT DC ALTERNATOR UPPER
30	0F3017	1	BRKT DC ALTERNATOR LOWER
(2)31	0J6684	1	HARN ENG G5.4L G3
(1)32	0E3257	1	SCREW HWHTF M6-1.0 X 16
(1)33	0G5148	2	SCREW HHC M8-1.25 X 140 G8.8
34	0F4308	1	BRACKET DC ALT STABILIZER
(1)35	022129	2	WASHER LOCK M8-5/16
(1)36	022145	4	WASHER FLAT 5/16-M8 ZINC
(1)37	077996	2	CAP ANTIFREEZE 5/8"ID X 1.2"LG
38	052243	1	SCREW HHC M10-1.5 X 60 C8.8
(1)39	0H5406A	1	REWORK HARMONIC BALANCER 5.4L
40	039253	3	SCREW HHC M8-1.25 X 20 G8.8
41	064416	1	SCREW HHC M10-1.5 X 45 G8.8 FT
42	022131	3	WASHER FLAT 3/8-M10 ZINC
43	046526	2	WASHER LOCK M10
44	0D8027	REF	SCREW WP PULLEY M8-1.25 X 19
45	0D8025	1	BOLT HEX FL HD M8-1.25 X 28
46	0D8026	3	BOLT HEX FL HD M8-1.25 X 31
47	0D8030	1	TENSIONER ENG. AUTOMATIC BELT
(2)(4)48	0H0016	1	HARN EMSN OVERLAY G4.2L G3
49	0D8028	1	PULLEY GROOVED ENGINE IDLER

EXPLODED VIEW: EV ENGCOMPRT 5.4L CPL L/H**DRAWING #: 0H5602B****GROUP D****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
51	045772	1	NUT HEX M10-1.5 G8 YEL CHR
52	045771	1	NUT HEX M8-1.25 G8 YEL CHR
(1)53	0E0992A	8	PLUG EXPANSION 14 OD
(1)54	057823	3	CLAMP HOSE #10 .56-1.06
(2)(3) 55	029333A	2	TIE WRAP UL 7.4" X .19" BLK
(1)(2)56	0F6151	3	CAP RUBBER
57	0E0502	1	TEMPERATURE SENDER, DELPHI
58	REF	1	COUPLING FLEX HUB MACH
59	048031J	2	CLAMP HOSE BAND .63
(1)60	035473	2	CLAMP HOSE #12 .50-1.25
(1)61	045771	1	NUT HEX M8-1.25 G8 CLEAR ZIN
(1)62	0J6240B	1	5.4L G3 - INTAKE MANIFOLD
(1)63	0J6240C	1	5.4L G3 - INTAKE GASKET RH
(1)64	0J6240D	1	5.4L G3 - INTAKE GASKET LH
(1)65	0F2842	8	COIL & BOOT ASY-IGNITION
66	048031P	2	CLAMP HOSE BAND .88"
67	047290	1	HOSE 3/8 ID SINGLE BRAID (14.75" LG)
68	0G1462	1	HOSE BARB REDUCER 5/8"-3/8"ID
(1)69	022129	9	WASHER LOCK M8-5/16
(1)70	022145	9	WASHER FLAT 5/16 ZINC
71	022097	1	WASHER LOCK M6-1/4
72	022473	1	WASHER FLAT 1/4-M6 ZINC

(1) PART OF ENGINE MAKE P/N 0J6390A

(2) NOT SHOWN

(3) I/N 55 IS FOR HOLDING SENSOR TO I/N 50

(4) ONLY REQUIRED ON CATALYST GENERATORS

EXPLODED VIEW: EV ENGCOMPRT 5.4L CPL L/H


DRAWING #: 0H5602B

APPLICABLE TO:

GROUP D

THIS PAGE LEFT INTENTIONALLY BLANK


GROUP D



EXPLODED VIEW: EV EXHAUST 5.4L C2 CPL**DRAWING #: 0J5604A****GROUP D****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
1	0J5735	1	PIPE, EXH MANIFOLD 5.4L C2 RH (6.8L 70KW)
2	0J5718	1	PIPE, EXH MANIFOLD 5.4L C2 LH (6.8L 70KW)
3	0F2808B	1	PIPE, EXHAUST MUFFLER OUT
4	0A6765	2	RING GASKET, 2.5DIA
5	0F4710	6	WASHER LOCK M10 SS
6	0F7200	6	SCREW HHC M10-1.5 X 50 SS FTH
7	080762	6	BOLT U 3/8-16 X 2.62
8	0D3159	2	FLANGE, EXHAUST
9	0F2981A	1	MFLR 7" X 9" X 25" (2) 2.5" IN/2.5" OUT
10	0F2962	1	MUFFLER STRAP
11	045757	2	SCREW HHC M6-1.0 X 25 C8.8
12	022097	4	WASHER LOCK M6-1/4
13	0F2830	1	MUFFLER BRACKET STIFFENER
14	0F4505A	1	MUFF SEC 23.5" X 2.55IN/2.5OUT
15	0C2454	4	SCREW HWHT M6-1 X 16 N WA Z/JS
16	022473	6	WASHER FLAT 1/4-M6 ZINC
17	0G3770	2	EXHAUST BLANKET 737MM (6.8L 70KW)
18	088775	6	WASHER FLAT 3/8 SS
19	0G1007	1	BRACKET MUFFLER
20	0J5736	1	PIPE, EXHAUST RH CPL C2
21	0F6214B	1	PIPE ELBOW EXHAUST MUFFLER
22	0G0007	1	DIFFUSER EXHAUST WELDMENT
23	0F6803	2	MUFFLER STRAP UPPER/LOWER
24	049721	2	SCREW HHC M6-1.0 X 35 C8.8 CLR
25	049813	2	NUT HEX M6-1.0 G8 CLEAR ZINC

GROUP D



EXPLODED VIEW: EV EXHAUST 5.4L C2 CPL EM**DRAWING #: 0J5604B****GROUP D****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
1	0J6140	1	ASSY PIPE EXH MANF 5.4L C2 EM (6.8L 70KW)
2	0J5718	1	PIPE, EXH MANIFOLD 5.4L C2 LH (6.8L 70KW)
3	0J7825	1	BOLT U 3/8-16 X 3.25
4	0A6765	2	RING GASKET, 2.5DIA
5	0F4710	6	WASHER LOCK M10 SS
6	0F7200	6	SCREW HHC M10-1.5 X 50 SS FTH
7	080762	4	BOLT U 3/8-16 X 2.62
8	0D3159	1	FLANGE, EXHAUST
9	0J6648	1	MUFFLER CATALYST
10	0F2962A	1	MUFFLER STRAP
11	045757	2	SCREW HHC M6-1.0 X 25 C8.8
12	022097	2	WASHER LOCK M6-1/4
13	0F2830A	1	MUFFLER BRACKET STIFFENER
14	0F9071	1	SENSOR OXYGEN
15	0C2454	4	SCREW HWHT M6-1 X 16 N WA Z/JS
16	022473	2	WASHER FLAT 1/4-M6 ZINC
(1)17	0G3770	2	EXHAUST BLANKET 737MM (NOT SHOWN)
18	088775	6	WASHER FLAT 3/8 SS
19	0G1007	1	BRACKET MUFFLER
20	0J5736	1	PIPE, EXHAUST RH CPL C2
21	0F6214B	1	PIPE ELBOW EXHAUST MUFFLER
22	0J7105	1	WELDMENT EXHAUST DIFFUSER 3"
23	0K1526	6	TIE WRAP, 14.3" STAINLESS STL (NOT SHOWN)

NOTES (UNLESS OTHERWISE SPECIFIED):

(1) TWO TIE WRAPS ARE INCLUDED WITH EACH EXHAUST BLANKET, ONE AT EACH END.



IMPORTANT
SOLENOID MUST BE
INSTALLED WITH FLOW
ARROW POINTING IN
DIRECTION SHOWN IN
DETAIL BELOW.



EXPLODED VIEW: EV FUELSYS 48KW 5.4L C2**DRAWING #: 0J5603A****GROUP E****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
1	045757	4	SCREW HHC M6-1.0 X 25 G8.8
2	075580	1	FLANGE FUEL INLET
3	0J6348	1	REGULATOR ASSY 5.4L 48KW 49ST
	0J6348A	1	REGULATOR ASSY 5.4L 48KW EM
4	039253	2	SCREW HHC M8-1.25 X 20 G8.8
5	022145	2	WASHER FLAT 5/16-M8 ZINC
6	022129	2	WASHER LOCK M8-5/16
7	045771	2	NUT HEX M8-1.25 G8 CLEAR ZINC
8	047527	1	BARBED STR 1/2NPT X 3/4
9	0H7436	1	HARN FUEL JUMPER SINGLE REG
10	026812	2	ELBOW 90D 3/4 NPT
11	0E0697	1	NIPPLE PIPE 3/4NPT X 5-1/2 LG
12	042561	2	CLAMP HOSE #36 1.88-2.75
13	057823	2	CLAMP HOSE #10 .56-1.06
14	059057	1	HOSE 3/4 ID SAE-30R2 (40" LG)
15	026073A	1	PLUG STD PIPE 1/4 STEEL SQ HD
18	0F2756	1	MACHINING INTAKE ADAPTOR 40MM
19	0E6586	1	GASKET BOSCH 32 & 40
20	0E4394	1	ACTUATOR BOSCH 40 GOVERNOR
21	0K9704	1	HOSE COOLING 2IN ID 20R4 (2IN)
22	0G4573B	1	MIXER ACTUATOR 40MM MACHINED
23	0E7121	1	O-RING 47.625 ID X 2.38 WIDTH
24	0F7790E	1	VENTURI THROTTLE 26MM
25	026915	1	NIPPLE CLOSE 3/4 X 1.375
26	0D2157	4	SCREW SHC M6-1.0 X 50 C8.8
27	0F2119	1	O-RING 45.63 ID X 2.62 WIDTH
28	022097	8	WASHER LOCK M6-1/4
29	026490	1	NIPPLE PIPE 3/4NPT X 2
30	0E8286	1	ELBOW 45D STREET 1/2NPT BRASS
31	025655	1	PLUG STD PIPE 3/4 STEEL SQ HD

GROUP F



EXPLODED VIEW: EV ENCLOSURE C2 2.4L G2 TURBO**DRAWING #: 0J8688****GROUP F**

ITEM	PART#	QTY.	DESCRIPTION
(2)1	0G80180AL0R	1	REAR WRAP C2 G2 60KW
(1)2	0C2454	48	SCREW THF M6-1 X 16 N WA Z/JS
(2)3	0F58490AL0R	2	DOOR C2
4	087233	2	RIVET POP .1875 X .450 SS
(1)5	0E3257	10	SCREW TH-FRM M6 W/CAP SHKPRF W
(2)6	0F58520AL0R	2	DUCT DSCHRG LH&RH
(2)7	0F98330AL0R	2	FRONT CORNERS C2
(2)8	0F58510AL0R	1	DUCT DISCHARGE C2
9	049813	2	NUT HEX M6 X 1.0 G8 YEL CHR
(1)10	077992	17	NUT HEX LOCK M6-1.0 SS NY INS
(2)11	0F98350AL0R	1	ROOF C2
12	0F2786	2	SLITTER C4
13	0F2785	1	SPLITTER LOWER C4
14	0F3364	1	SPLITTER STINGER C2
15	0F4880	2	SUPPORT SPLITTER LH C2
16	0F5049B	2	PULL TAB DOOR LOCK SS
17	0F4487A	1	ASSEMBLY COVER ACCESS
18	022473	7	WASHER FLAT 1/4-M6 ZINC
19	022097	5	WASHER LOCK M6-1/4
20	022127	1	NUT HEX 1/4-20 STEEL
21	0F3072	10	INSULATION RETAINMENT HANGER
22	078115	26	WASHER SELF LOCKING DOME #4-40
23	0G5892	2	INSULATION DOOR C2
24	0G5892A	1	INSULATION ROOF TOP
25	0F5048D	2	WISE-ACTION LATCH SLOTTED CIR
26	0E5968	1	GASKET EXTRUDED TRIM (328" LG)
27	0G5892D	2	INSULATION SPLITTER
28	0G5892C	2	INSULATION SPLITTER
29	0F4051C	2	INSULATION DUCT
30	0F3890B	4	RETAINER INSULATION (820)
31	0F4051B	2	INSULATION DUCT SIDES
32	0F3890	4	RETAINER INSULATION (450)
33	078115A	6	WASHER SELF LOCKING DOME #8-32
34	0G5892E	1	INSULATION LOWER SPLITTER
35	042568	2	SCREW HHC M6-1.0 X 20 G8.8
36	0912970090	2	ASSY WIRE 14AWG GRN/YEL
37	022447	2	WASHER SHAKEPROOF INT 1/4
38	0G9473	1	DEFLECTOR INTAKE 2.4L G2 TURBO
39	0F8869D	1	KEY WISE-ACTION LATCH SLOT CIR
40	052250	1	TAPE FOAM 1X1 (71.0"LG)
41	066760	1	STRIP SEALANT 1/8 X 1 (44.52"LG)
42	0E5298L	1	FOAM 300 X 300 THERMAL ACO
43	0H1208A	1	RF COVER PLATE-PLASTIC-BISQUE
	0H1208B	1	RF COVER PLATE-PLASTIC-GREY
44	0H0412	4	NUT U M6-1.0 GEOMET
45	0C8566	4	SCREW HHFC M6-1.0 X 20 G8.8



UNLESS OTHERWISE SPECIFIED:

(1) ENCLOSURE NOTE: PANELS THAT FASTEN TO THE BASEFRAME (EXCEPT ITEM 1) MUST BE SECURED USING I/N 2 & 5 (THREAD FORMING FASTENERS) AND I/N 10 (LOCK NUT). LOCK NUT IS TO BE INSTALLED AFTER THREAD FORMING FASTENER HAS PENETRATED THROUGH EXTRUSIONS IN ENCLOSURE PANELS. ALL PANEL TO PANEL CONNECTIONS TO INCLUDE AT LEAST ONE CONNECTION POINT USING I/N 5 (THREAD FORMING FASTENER).

(2) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.
- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

GROUP F



EXPLODED VIEW: EV ENCL C2 PVT LBL**DRAWING #: 0J2818A****GROUP F****APPLICABLE TO:**

ITEM	PART#	QTY.	DESCRIPTION
(2) 1	0G80180AL0R	1	REAR WRAP C2 CPL
(1) 2	0C2454	58	SCREW THF M6-1 X 16 N WA Z/JS
(2) 3	0F58490AL0R	2	DOOR C2
4	087233	2	RIVET POP .1875 X .450 SS
(1) 5	0E3257	10	SCREW TH-FRM M6 W/CAP SHKPRF W
(2) 6	0J28190AL0R	1	DUCT DISCHARGE LH C2 AL
(2) 7	0F98330AL0R	2	FRONT CORNERS C2
(2) 8	0J28200AL0R	1	DUCT DISCHARGE MID C2
9	049813	2	NUT HEX M6 X 1.0 G8 YEL CHR
(1) 10	077992	19	NUT HEX LOCK M6-1.0 SS NY INS
(2) 11	0J28210AL0R	1	ROOF C2 CPL PVT LBL
12	0F2786	2	SLITTER C4
13	0F2785	1	SPLITTER LOWER C4
14	0F3364	1	SPLITTER STRINGER C2
15	0F4880	2	SUPPORT SPLITTER LH C2
16	0F5049B	2	PULL TAB DOOR LOCK SS
17	0F4487A	1	ASSEMBLY COVER ACCESS
18	022473	7	WASHER FLAT 1/4-M6 ZINC
19	022097	5	WASHER LOCK M6-1/4
20	022127	1	NUT HEX 1/4-20 STEEL
21	0F3072	10	INSULATION RETAINMENT HANGER
22	078115	26	WASHER SELF LOCKING DOME #4-40
23	0G5892	2	INSULATION DOOR C2
24	0G5892A	1	INSULATION ROOF TOP
25	0F5048D	2	WISE-ACTION LATCH SLOTTED CIR
26	0E5968	1	GASKET EXTRUDED TRIM (328" LG)
27	0G5892D	2	INSULATION SPLITTER
28	0G5892C	2	INSULATION SPLITTER
29	0F4051C	2	INSULATION DUCT
30	0F3890B	4	RETAINER INSULATION (820)
31	0F4051B	2	INSULATION DUCT SIDES
32	0F3890	4	RETAINER INSULATION (450)
33	078115A	6	WASHER SELF LOCKING DOME #8-32
34	0G5892E	1	INSULATION LOWER SPLITTER
35	042568	2	SCREW HHC M6-1.0 X 20 G8.8
36	0912970094	2	ASSY WIRE 14 AWG 34.8" GRN/YEL
37	022447	2	WASHER SHAKEPROOF INT 1/4
38	052250	1	TAPE FOAM 1X1 (150" LG)
39	0F8869D	1	KEY WISE-ACTION LATCH SLOT CIR
40	0E5298L	1	FOAM 300 X 300 THERMAL ACO (APPLIES TO 4.2L UNITS ONLY)
41	066760	1	STRIP SEALANT 1/8 X 1 (44.52"LG)
42	0H1208C	1	RF COVER PLATE-PLASTIC-DRK GRY (OPTIONAL)
(2) 43	0J29470AL0R	1	DUCT DISCHARGE RH C2 AL
44	0G6019	1	ASSY ENCLOSURE GEN SIDE RF
45	084543A	2	SCREW PPPH M3 X 12
46	052777	2	WASHER FLAT M3
47	0J2791	2	BADGE, HONEYWELL
48	0J4013	1	BAFFLE TOP EXHAUST C2 HW
49	0G9473	1	DEFLECTOR INTAKE 2.4L G2 TURBO
50	0H0412	4	NUT U M6-1.0 GEOMET
51	0C8566	4	SCREW HHFC M6-1.0 X 20 G8.8

(1) ENCLOSURE NOTE: PANELS THAT FASTEN TO THE BASEFRAME (EXCEPT ITEM 1) MUST BE SECURED USING I/N 2 & 5 (THREAD FORMING FASTENERS) AND I/N 10 (LOCK NUT). LOCK NUT IS TO BE INSTALLED AFTER THREAD FORMING FASTENER HAS PENETRATED THROUGH EXTRUSIONS IN ENCLOSURE PANELS. ALL PANEL TO PANEL CONNECTIONS TO INCLUDE AT LEAST ONE CONNECTION POINT USING I/N 5 (THREAD FORMING FASTENER).

(2) SHEET METAL PARTS LISTED IN THE BOM TABLE ARE REPRESENTING GENERIC PARTS (NO COLOR)

- MANUFACTURING: FOR CORRECT MATERIAL AND COLOR REFER TO AS400 BOM.
- CUSTOMER: WHEN ORDERING REPLACEMENT PARTS ENTER BASE NUMBER (FIRST 6 DIGITS ONLY) IN THE SYSTEM FOR CORRECT MATERIAL AND COLOR (FOR REFERENCE SEE GUIDELINE 0H7169).

LEGEND

- AFS — AIR/FUEL SOLENOID
- ALT — DC CHARGE ALTERNATOR
- AS — ALTERNATOR STATOR
- BA — BRUSH ASSEMBLY
- BAT — BATTERY
- BWR — BASIC WIRELESS RECEPTACLE
- CAM — CAMSHAFT SENSOR
- CAR — COMMON ALARM RELAY
- CB — CIRCUIT BREAKER
- CSS — CRANKSHAFT SENSOR
- CYL_ — CYLINDER IGNITION COIL
- DB_ — DIODE BRIDGE
- EC — EMISSIONS CONNECTOR
- F_ — FUSE INLINE
- FS_ — FUEL SOLENOID
- GND — GROUND CONNECTION
- GOV — ELECTRONIC GOVERNOR ACTUATOR
- HVP — HIGH VOLTAGE PLUG 12—PIN (BULKHEAD)
- HVR — HIGH VOLTAGE RECEPTACLE 12—PIN

- ICMJ_ — IGNITION CONTROL MODULE
- J1 — ENGINE CONTROL MODULE 35-PIN CONNECTOR
- J2 — ENGINE CONTROL MODULE 23-PIN CONNECTOR
- LFP — LOW FUEL PRESSURE SWITCH
- LOS — LOW OIL PRESSURE SWITCH
- LVP — LOW VOLTAGE PLUG 8-PIN (BULKHEAD)
- LVR — LOW VOLTAGE RECEPTACLE 8-PIN
- MLCB — MAIN LINE CIRCUIT BREAKER
- MOV — METAL OXIDE VARISTOR
- MPU — MAGNETIC PICKUP
- NB — NEUTRAL BLOCK
- OS — OXYGEN SENDER
- R1 — RESISTOR
- SC — STARTER CONTACTOR
- SM — STARTER MOTOR
- TB_ — TERMINAL BLOCK, CAGE CLAMP
- WLS — COOLANT LEVEL SENDER
- WTS — COOLANT TEMPERATURE SENDER

NOTE: ALL WIRES 18 AWG
300V UL LISTED UNLESS
SHOWN OTHERWISE



AWG SIZE


G SIZE

ST LICE
NUMBER

WIRE
SPLICE


NOTE: ALL WIRES ON THIS
PAGE ARE 600V RATED

COMPONENTS LOCATED IN CUSTOMER CONNECTION BOX




NOTE:
FOR FIELD WIRING TO CUSTOMER CONNECTIONS
(TERMINAL BLOCKS)
MAXIMUM WIRE SIZE: #12 AWG

COMPONENTS LOCATED ON ENGINE




COMPONENTS LOCATED ON ENGINE



HVR









LVR






BWR





EC




COMPONENTS LOCATED ON ENGINE









NOTE:
FOR FIELD WIRING TO CUSTOMER CONNECTIONS
(TERMINAL BLOCKS)
MAXIMUM WIRE SIZE: #12 AWG





BWR CONNECTOR

PIN	WIRE	TO	FUNCTION
1	820	J1-12	+5V POWER FOR BASIC REMOTE
2	817	J1-4	REMOTE DISPLAY SYSTEM READY
3	818	J1-5	REMOTE DISPLAY ALARM
4	819	J1-17	REMOTE DISPLAY MAINTENANCE
5	0	GND	NOTE 1

ICMJ1 CONNECTOR

PIN	WIRE	TO	FUNCTION
2	454	CYL4	IGNITION COIL DRIVE 4
3	456	CYL6	IGNITION COIL DRIVE 6
4	451	CYL1	IGNITION COIL DRIVE 1
5	452	CYL2	IGNITION COIL DRIVE 2
6	455	CYL5	IGNITION COIL DRIVE 5
7	457	CYL7	IGNITION COIL DRIVE 7
9	453	CYL3	IGNITION COIL DRIVE 3
10	SHLD	CUT	CAMSHAFT SENSOR DRAIN
14	79A	CSS-2	CRANKSHAFT SENSOR +
15	458	CYL8	IGNITION COIL DRIVE 8
16	15B	F2	NOTE 6
17	0	GND	NOTE 1
18	15D	CYL1-CYL6	NOTE 7
20	SHLDA	CUT	CRANKSHAFT SENSOR DRAIN
21	0A	CSS-1	CRANKSHAFT SENSOR -
22	0	CAM-1	CAMSHAFT SENSOR -
23	450	CAM-2	CAMSHAFT SENSOR +

NOTES:

- 1) WIRE #0 IS CHASSIS GROUND (BATTERY-) UNLESS NOTED OTHERWISE.
- 2) WIRE #13 IS UNFUSED +12VDC (BATTERY+).
- 3) WIRE #14 IS FUSED +12VDC WHEN GENERATOR IS CRANKING OR RUNNING.
- 4) WIRE #15 IS FUSED +12VDC FOR GENERAL USE.
- 5) WIRE #15A IS FUSED +12VDC FOR THE AIR/FUEL SOLENOID OPTION.
- 6) WIRE #15B IS FUSED +12VDC FOR THE IGNITION CONTROL MODULE.
- 7) WIRE #15D IS FUSED +12VDC FOR THE IGNITION COILS.

EC CONNECTOR

PIN	WIRE	TO	FUNCTION
1	0	GND	NOTE 1
2	14	J2-8	NOTE 3
3	15A	J2-23	NOTE 5
4	808	J2-2	AIR/FUEL RATIO SOLENOID DRIVER
5	805	J1-35	OXYGEN SENSOR RETURN
6	804	J1-34	OXYGEN SENSOR +

ICMJ2 CONNECTOR

PIN	WIRE	TO	FUNCTION
1	743	J1-29	CAN BUS HIGH
2	SHLDC	J1-27	CAN BUS DRAIN
5	744	J1-28	CAN BUS LOW

ENGINE CONTROL MODULE CONNECTIONS**J1**

PIN	WIRE	TO	FUNCTION
1	178	CUST CON	REMOTE START RETURN
4	817	BWR-2	REMOTE DISPLAY SYSTEM READY
5	818	BWR-3	REMOTE DISPLAY ALARM
6	15	F1	NOTE 4
7	15	F1	NOTE 4
8	0	GND	NOTE 1
9	0	GND	NOTE 1
10	0	MP1-2	FLYWHEEL SENSOR -
12	820	BWR-1	+5V POWER FOR BASIC REMOTE
13	SA	MLCB	OUTPUT VOLTAGE SENSING A
14	183	CUST CON	REMOTE START
16	SHLD	MP1-1	FLYWHEEL SENSOR DRAIN
17	819	BWR-4	REMOTE DISPLAY MAINTENANCE
18	767	GOV-2	THROTTLE POSITION FEEDBACK RETURN
19	765	GOV-3	THROTTLE POSITION FEEDBACK SOURCE
20	766	GOV-6	THROTTLE POSITION FEEDBACK SIGNAL
21	68	WTS-2	COOLANT TEMP SIGNAL
23	79	MP1-3	FLYWHEEL SENSOR +
24	SB	MLCB	OUTPUT VOLTAGE SENSING B
25	N1	CUST CON	UTILITY VOLTAGE SENSING 1
26	N2	CUST CON	UTILITY VOLTAGE SENSING 2
27	SHLDC	ICMJ2-2	CAN BUS DRAIN
28	744	ICMJ2-5	CAN BUS LOW
29	743	ICMJ2-1	CAN BUS HIGH
31	573A	WLS-A	COOLANT LEVEL SIGNAL RETURN
32	573	WLS-B	COOLANT LEVEL SIGNAL
33	86	LOS-NC	LOW OIL PRESSURE SIGNAL
34	804	EC-6	OXYGEN SENSOR +
35	805	EC-5	OXYGEN SENSOR RETURN

J2

PIN	WIRE	TO	FUNCTION
1	770	GOV-4	THROTTLE DRIVE HI
2	808	EC-4	AIR/FUEL RATIO SOLENOID DRIVER
3	56B	FS2	STARTING FUEL SOLENOID CONTROL
8	14	DB1/FS/EC-2	NOTE 3
9	771	GOV-1	THROTTLE DRIVE LO
11	209	CAR	COMMON ALARM RELAY
12	23	CUST CON	TRANSFER RELAY COIL CONTROL
13	194	CUST CON	TRANSFER RELAY COIL +
14	601	LFP	LOW FUEL PRESSURE
15	210	CAR	COMMON ALARM RELAY
16	6	DPE	EXCITER RETURN
17	162	CB	EXCITER OUTPUT (BREAKER PROTECTED)
18	4	FIELD	FIELD (BRUSH) +
19	1	FIELD	FIELD (BRUSH) -
20	T1	CUST CON	120VAC SOURCE FOR BATTERY CHARGER
21	NEU	CUST CON	120VAC RETURN FOR BATTERY CHARGER
22	56	SC	STARTER CONTACTOR DRIVER
23	15A	EC-3	NOTE 5

LEGEND

00 - NEUTRAL
 AFS - AIR/FUEL SOLENOID
 ALT - DC CHARGE ALTERNATOR
 BAT - BATTERY
 BWR - BASIC WIRELESS RECEPTACLE
 CAM - CAMSHAFT SENSOR
 CAR - COMMON ALARM RELAY
 CB - CIRCUIT BREAKER
 CSS - CRANKSHAFT SENSOR
 CYL_ - CYLINDER IGNITION COIL
 DB_ - DIODE BRIDGE


DPE - EXCITER
 EC - EMISSIONS CONNECTOR
 F_ - FUSE INLINE
 FS_ - FUEL SOLENOID
 GOV - ELECTRONIC GOVERNOR ACTUATOR
 ICM_ - IGNITION CONTROL MODULE
 J_ - ENGINE CONTROL MODULE CONNECTOR
 LFP - LOW FUEL PRESSURE SWITCH
 LOS - LOW OIL PRESSURE SWITCH
 MLCB - MAIN LINE CIRCUIT BREAKER
 MOV - METAL OXIDE VARISTOR

MP1 - MAGNETIC PICKUP
 OS - OXYGEN SENDER
 R1 - RESISTOR
 SC - STARTER CONTACTOR
 SHLD - SHIELD
 SM - STARTER MOTOR
 SP_ - SPARK PLUG
 WLS - COOLANT LEVEL SENDER
 WTS - COOLANT TEMPERATURE SENDER

WEIGHT DATA		
WEIGHT (GENSET ONLY) KG [LBS]	WEIGHT (WOODEN SHIPPING CRATE/SKID) KG [LBS]	SHIPPING WEIGHT (SKID AND GENSET) KG [LBS]
688 [1516]	44 [98]	732 [1614]

NOTES:

- 1) MINIMUM RECOMMENDED CONCRETE PAD SIZE: 1155 (45.5") WIDE X 2255 (88.8") LONG. REFERENCE INSTALLATION GUIDE SUPPLIED WITH UNIT FOR CONCRETE PAD GUIDELINES.
- 2) ALLOW SUFFICIENT ROOM ON ALL SIDES OF THE GENERATOR FOR MAINTENANCE AND SERVICING. THIS UNIT MUST BE INSTALLED IN ACCORDANCE WITH CURRENT APPLICABLE NFPA 37 AND NFPA 70 STANDARDS AS WELL AS ANY OTHER FEDERAL, STATE AND LOCAL CODES FOR MINIMUM DISTANCES FROM OTHER STRUCTURES.
- 3) CIRCUIT BREAKER INFORMATION:
SEE SPECIFICATION SHEET WITHIN OWNERS MANUAL
- 4) INSIDE STUB-UP AREA FOR AC LOAD LEAD CONDUIT CONNECTION, NEUTRAL CONNECTION, BATTERY CHARGER 120 VOLT AC (.5 AMP MAX.) CONNECTION, AND ACCESS TO TRANSFER SWITCH CONTROL WIRES. REMOVE FRONT COVER FOR ACCESS.
- 4A) FIELD CUT HOLE IS ONLY REQUIRED FOR MOUNTING OF GENERATOR ON AN EXISTING PAD.
- 5) REFERENCE OWNERS MANUAL FOR LIFTING WARNINGS.
- 6) REMOVE EITHER LEFT OR RIGHT HAND SIDE PANEL TO ACCESS EXHAUST MUFFLER AND FAN BELT.





EXPLODED VIEW:
INSTALLATION DRAWING 5.4L 48KW
DRAWING #: 0J7662

GROUP G

SERVICE ITEM ACCESSIBILITY CHART


SERVICE ITEM	
OIL FILL CAP	THRU RIGHT DOOR
OIL DIP STICK	THRU LEFT DOOR
OIL FILTER	THRU LEFT DOOR
OIL DRAIN HOSE	THRU RIGHT DOOR
RADIATOR DRAIN HOSE	THRU LEFT DOOR
AIR CLEANER ELEMENT	BOTH DOORS
SPARK PLUGS	BOTH DOORS
MUFFLER	SEE NOTE 6
FAN BELT	SEE NOTE 6
BATTERY	THRU RIGHT DOOR

REFERENCE OWNERS MANUAL FOR PERIODIC REPLACEMENT PART LISTINGS




EXPLODED VIEW:
INSTALLATION DRAWING 5.4L 48KW
DRAWING #: 0J7662


OPTION 1 - SINGLE PHASE, CPL CONTROL PANEL




OPTION 2 - THREE PHASE, CPL CONTROL PANEL, 120/208V




OPTION 3 - THREE PHASE, CPL CONTROL PANEL, 6-WIRE 277/480V




OPTION 4 - THREE PHASE DELTA, CPL CONTROL PANEL, 7-WIRE 120/240V




OPTION 5 - THREE PHASE, CPL CONTROL PANEL, GEARBOX (REVERSE ROTATION)



OPTION 6 - THREE PHASE, CPL CONTROL PANEL, GEARBOX (REVERSE ROTATION)



OPTION 7 - THREE PHASE SERIES DELTA, CPL CONTROL PANEL, GEARBOX (REVERSE ROTATION)



Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Warranty

GENERAC POWER SYSTEMS “FIVE YEAR” LIMITED WARRANTY FOR HONEYWELL SINGLE-PHASE LIQUID-COOLED STATIONARY EMERGENCY GENERATORS BELOW 50KW

For a period of five (5) years from the date of successful activation of the unit, Generac Power Systems, Inc. (Generac) will, at its option, repair or replace any part(s) which, upon examination, inspection, and testing by Generac or an Authorized/Certified Honeywell Generator Dealer, or branch thereof, is found to be defective under normal use and service, in accordance with the warranty schedule set forth below. Any equipment that the purchaser/owner claims to be defective must be examined by the nearest Generac or Authorized/Certified Honeywell Generator Dealer, or branch thereof. Repair or replacement pursuant to this limited warranty shall not renew or extend the original warranty period. Any repaired product shall be warranted for the remaining original warranty period only. This warranty applies only to Honeywell Generators used in “Standby” applications, as Generac has defined Standby, provided said generator has been initially installed and/or inspected on-site by Generac or an Authorized/Certified Honeywell Generator Dealer, or branch thereof. It is highly recommended that scheduled maintenance, as outlined by the generator owner’s manual, be performed by Generac or an Authorized/Certified Honeywell Generator Dealer, or branch thereof. This will verify service has been performed on the unit throughout the warranty period.

*****This warranty only applies to units sold for use in the US and Canada.*****

WARRANTY SCHEDULE

YEARS ONE AND TWO — Limited comprehensive coverage on mileage, labor, and parts listed.

- ALL COMPONENTS

YEARS THREE, FOUR AND FIVE — Limited comprehensive coverage on mileage, labor, and parts listed.

- ALL COMPONENTS

GUIDELINES:

Travel allowance is limited to 100 miles maximum and three (3) hours maximum (per occurrence, whichever is less), round trip from the nearest Authorized/Certified Honeywell Generator Dealer; and only applies to permanently wired and mounted units. Any additional required travel expense will not be covered by Generac.

1. This warranty only applies to permanently wired and mounted single-phase units.
2. All warranty repairs, must be performed and/or addressed by an Authorized/Certified Honeywell Generator Dealer, or branch thereof.
3. Units that have been resold are not covered under the Honeywell Warranty, as this Warranty is not transferable.
4. Unit enclosure is only covered during the first year of the warranty provision.
5. Use of Non-Generac replacement part(s) will void the warranty in its entirety.
6. Generac may choose to Repair, Replace or Refund a piece of equipment.
7. Warranty Labor Rates are based on normal working hours. Additional costs for overtime, holiday or emergency labor costs for repairs outside of normal business hours will be the responsibility of the customer.
8. Warranty Parts shipment costs are reimbursed at ground shipment rates. Costs related to requests for expedited shipping will be the responsibility of the customer.
9. Verification of required maintenance may be required for warranty coverage.

THIS WARRANTY SHALL NOT APPLY TO THE FOLLOWING:

1. Costs of normal maintenance (tune-ups, associated part (s), loose/leaking clamps, adjustments, installation and start-up).
2. Any failure caused by contaminated fuels, oils, coolants/antifreeze or lack of proper fuels, oils or coolants/antifreeze.
3. Units sold, rated or used for “Prime Power”, “Trailer Mounted” or “Rental Unit” applications as Generac has defined Prime Power, Trailer Mounted or Rental Unit. Contact a Generac Distributor for Prime Power, Trailer Mounted or Rental Unit definition and warranty.
4. Failures caused by any external cause or act of God such as, but not limited to, collision, fire, theft, freezing, vandalism, riot or wars, lightning, earthquake, wind-storm, hail, volcanic eruption, water or flood, tornado, hurricane, terrorist acts or nuclear holocaust.
5. Products that are modified or altered in a manner not authorized by Generac in writing.
6. Failures due, but not limited to, normal wear and tear, accident, misuse, abuse, negligence, or improper installation or sizing.
7. Any incidental, consequential or indirect damages caused by defects in materials or workmanship, or any delay in repair or replacement of the defective part(s).
8. Damage related to rodent and/or insect infestation.
9. Failure due to misapplication, misrepresentation, or bi-fuel conversion.
10. Telephone, facsimile, cellular phone, satellite, Internet, or any other communication expenses.
11. Rental equipment used while warranty repairs are being performed.
12. Modes of transportation deemed abnormal
13. Steel enclosures that are rusting due to improper installation, location in a harsh or saltwater environment or scratched where integrity of paint applied is compromised.
14. Any and all expenses incurred investigating performance complaints unless defective Generac materials and/or workmanship were the direct cause of the problem.
15. Starter Batteries, Fuses, light bulbs, and overnight freight cost for replacement part(s).

THIS WARRANTY IS IN PLACE OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, SPECIFICALLY, GENERAC MAKES NO OTHER WARRANTIES AS TO THE MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Any implied warranties which are allowed by law, shall be limited in duration to the terms of the express warranty provided herein. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to purchaser/owner.

GENERAC’S ONLY LIABILITY SHALL BE THE REPAIR OR REPLACEMENT OF PART(S) AS STATED ABOVE. IN NO EVENT SHALL GENERAC BE LIABLE FOR ANY INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF SUCH DAMAGES ARE A DIRECT RESULT OF GENERAC’S NEGLIGENCE. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to purchaser/ owner. Purchaser/owner agrees to make no claims against Generac based on negligence. This warranty gives purchaser/owner specific legal rights. Purchaser/owner also may have other rights that vary from state to state.

Honeywell International Inc. makes no representations or warranties with respect to this product.

The Honeywell Trademark is used under license from Honeywell International Inc.

GENERAC POWER SYSTEMS, INC. • P.O. BOX 8 • Waukesha, WI 53187 • Ph: 855-GEN-INFO

**To locate the nearest Authorized Dealer and to download schematics, exploded parts views and parts lists,
visit our website: www.honeywellgenerators.com**

