







LEA EL MANUAL ANTES DE UTILIZAR EL GENERADOR. LIRE LE MANUEL AVANT DE FAIRE FONCTIONNER LA GÉNÉRATRICE.

GUIDE DE PRÉPARATION RAPIDE GUÍA RÁPIDA DE CONFIGURACIÓN

XP SERIES








READ MANUAL BEFORE OPERATING GENERATOR.

QUICK SET-UP GUIDE


XP SERIES

1


Manual




2



3




4




5

Add engine oil.




The engine is full when the oil reaches the full mark on the dipstick.
Replace oil cap after filling.

6



7

Follow instructions.



GENERAC