CONTROL PANEL LEGEND:
AVR – AUTOMATIC VOLTAGE REGULATOR
BCH – BATTERY CHARGER
BR1 – DIODE (FIELD BOOST)
CB2 – CIRCUIT BREAKER (EXCITATION)
F1 – FUSE BAT POWER (15A ATO TYPE)
HM – HOUR METER
J2 – CONNECTOR 2 (ON PCB)
R4 – FIELD BOOST RESISTOR 15 OHM
RL1 – RELAY 1 (START RELAY)
RL2 – RELAY 2 (ENGINE RUN)
SW1 – AUTO/OFF/MANUAL SWITCH
SW2 – SET EXERCISER SWITCH
TR1 – TRANSFORMER (6VA UTIL/16 VAC)



NOTE 1: WIRING SHOWN FOR CB1, NB, BA AND STATOR IS TYPICAL FOR SINGLE PHASE. FOR 3–PHASE, SEE DWG #0F6839.

CUSTOMER CONNECTION & ALTERNATOR LEGEND:
BA – BRUSH ASSEMBLY (GENERATOR)
CB1 – MAINLINE CIRCUIT BREAKER
NB – NEUTRAL BLOCK
TB–BC – BATTERY CHARGER TERMINAL BLOCK
TBG – GTS CONNECT TERMINAL BLOCK
TBR – RTS CONNECT TERMINAL BLOCK

PAGE 1 OF 2

SCHEMATIC - DIAGRAM
2.4L R-200C
DRAWING #: 0H1274



PAGE 2 OF 2

SCHEMATIC - DIAGRAM

2.4L R-200C

DRAWING #: 0H1274