











COMPONENTS LOCATED IN CUSTOMER CONNECTION AREA



PAGE 2 OF 4



L1: GREEN = SYSTEM READY
L2: YELLOW = MAINTENANCE REQUIRED
L3: RED = ALARM



LEGEND	
BA	BRUSH ASSEMBLY
CB	CIRCUIT BREAKER
CT_	CURRENT TRANSFORMER
FS	FUEL SOLENOID
HOT	HIGH OIL TEMPERATURE SWITCH
IM_	IGNITION MODULE
J_	MAIN CONTROLLER CONNECTIONS
LED	LED BOARD
LOP	LOW OIL PRESSURE SWITCH
R	RESISTOR
SC	STARTER CONTACTOR
SCR	STARTER CONTROL RELAY
SM	STARTER MOTOR
SP_	SPARK PLUG