




LEGEND

BA - BRUSH ASSEMBLY
 BCR1 - BATTERY CHARGE RECTIFIER
 BCR2 - BATTERY CHARGE RECTIFIER, 10A
 CB1 - 6AMP AUTO RESET BREAKER
 CB2 - 10AMP AUTO RESET BREAKER
 D1 - 600V 12A DIODE
 D2, D3 - ENGINE SHUTDOWN DIODE
 F1 - 10A FUSE

FSS - FUEL SHUT OFF SOLENOID
 GND - GROUND STUD
 HM - HOUR METER
 I.C.T. - IDLE CONTROL TRANSFORMER
 IM1 - IGNITION MODULE, CYL. 1
 IM2 - IGNITION MODULE, CYL. 2
 LOP - LOW OIL PRESSURE
 R1 - 25 OHM, 25W RESISTOR

SC - STARTER CONTACTOR
 SCR - STARTER CONTACTOR RELAY
 SM - STARTER MOTOR
 SP1 - SPARK PLUG, CYL. 1
 SP2 - SPARK PLUG, CYL. 2
 SSR - START / STOP RELAY
 SW1 - START-RUN-STOP SWITCH
 SW2 - IDLE CONTROL SWITCH

NEUTRALS BONDED
 TO GROUND