



OUTPUT CONNECTION
120/240V. 1 - PHASE
E1 TO E2 240.
E1 TO 00 120V.
E2 TO 00

LEGEND	
AS - ALTERNATOR STATOR	SW2 - SET EXERCISE SWITCH
CAP - CAPACITOR	TR1 - TRANSFORMER, UTILITY SENSING
CB1 - CIRCUIT BREAKER	TS1 - TERMINAL STRIP 20 PDS.
CB2 - CIRCUIT BREAKER	TS2 - TERMINAL STRIP 2 PDS.
EC - ENGINE CONNECTION	TS3 - TERMINAL STRIP 7 PDS.
F - FUSE 15 AMPS	VR - VOLTAGE REGULATOR
F1 - FUSE, IN-LINE 7.5 AMP	SA - SUPPRESSION ASSEMBLY
	SW1 - AUTO/OFF/MANUAL SWITCH

FOR PRE-PACK TRANSFER SWITCH CONNECTIONS

BRUSH HOLDER MOUNTING SCREW
BRUSH WITH RED LEAD #4
CLOSEST TO BEARING

ALTERNATE TR1
(BLUE) - 225
(RED) - 224
(BLACK) - N1A
(BLACK) - N2