










44 —● 240VAC
GENERATOR
OUTPUT
11 —●

33 —●
22 —● NEUTRAL
00 —●

S2 —●
S1 —●
6 —● AVR
2 —●
4 —●
1 —●

N1 —● 240VAC
UTILITY
INPUT
N2 —●
T1 —● 120VAC
LOAD SUPPLY

0 —● DC COMMON
194 —● +12VDC
23 —● TRANSFER

LEGEND

AVR — AUTOMATIC VOLTAGE REGULATOR	J_ — CONTROLLER CONNECTIONS
BA — BRUSH ASSEMBLY	LOL — LOW OIL LEVEL SWITCH
CB — CIRCUIT BREAKER (MAIN OUTPUT)	R — RESISTOR
CS — CHOKE SOLENOID	SC — STARTER CONTACTOR
FS — FUEL SOLENOID	SM — STARTER MOTOR
HOT — HIGH OIL TEMPERATURE SWITCH	SP — SPARK PLUG
IM — IGNITION MODULE	