


LEGEND

BC-BATTERY CHARGER
C1-UTILITY COIL & RECTIFIER
C2-GENERATOR COIL & RECTIFIER
F1, F2, F3-5A, 600V FUSE
LC-CIRCUIT BREAKER (LOADS)
(16 CIRCUIT SHOWN FOR REFERENCE ONLY)
N-NEUTRAL
SW1-AUTOMATIC TRANSFER SWITCH
SW2, SW3-LIMIT SWITCHES
TB1-TERMINAL STRIP
TR1-TRANSFER RELAY

SCHEMATIC - DIAGRAM

HSB TRANSFER SWITCH

DRAWING #: 0G7959

REVISION: "A"

DATE: 03/07/08