




* - NOT USED WITH PREPACKAGED STANDBY GENERATORS

LEGEND

ATS	TRANSFER SWITCH CONTACTOR
C1	SOLENOID COIL (UTILITY CLOSING)
C2	SOLENOID COIL (STANDBY CLOSING)
TR	RELAY, TRANSFER
TB	TERMINAL STRIP (CUSTOMER CONNECTION)
XA1, XB1	LIMIT SWITCHES, ACTUATOR
F1, F2	FUSE, 5A
VR1, VR2	VARIATOR
NB	NB - NEUTRAL BLOCK

NOTE:
ALL CONTACTS SHOWN WITH
TRANSFER SWITCH IN UTILITY
POSITION.

SCHEMATIC - DIAGRAM

