


Exploded view diagram of a control panel assembly. The diagram shows the internal components, including a terminal block, a relay, a fuse, and a switch, mounted on a subplate. The components are labeled with numbers 1 through 72, indicating the sequence of assembly. The diagram also includes descriptive text for various components and details.

Labels and descriptions:

- 1 2
- 3 4
- 5 6 57 58
- 59 60 61
- 7 8 9 44 51
- 11 12 45 51
- 14 15 42 45
- 16 56
- 17 18
- 19
- 20
- 21
- 24
- 26
- 27
- 29
- 30
- 31
- 32
- 36
- 38
- 40 54 55
- 40 53
- 40 63 64 65
- 43
- 44 62
- 50
- 50
- 52
- 66
- SEE DETAIL A
- SEE DETAIL B
- SEE DETAIL C
- SEE DETAIL D
- SEE DETAIL E
- SEE DETAIL F
- SEE DETAIL G
- SEE DETAIL H
- SEE DETAIL I
- SEE DETAIL J
- SEE DETAIL K
- SEE DETAIL L
- SEE DETAIL M
- SEE DETAIL N
- SEE DETAIL O
- SEE DETAIL P
- SEE DETAIL Q
- SEE DETAIL R
- SEE DETAIL S
- SEE DETAIL T
- SEE DETAIL U
- SEE DETAIL V
- SEE DETAIL W
- SEE DETAIL X
- SEE DETAIL Y
- SEE DETAIL Z
- SEE DETAIL AA
- SEE DETAIL AB
- SEE DETAIL AC
- SEE DETAIL AD
- SEE DETAIL AE
- SEE DETAIL AF
- SEE DETAIL AG
- SEE DETAIL AH
- SEE DETAIL AI
- SEE DETAIL AJ
- SEE DETAIL AK
- SEE DETAIL AL
- SEE DETAIL AM
- SEE DETAIL AN
- SEE DETAIL AO
- SEE DETAIL AP
- SEE DETAIL AQ
- SEE DETAIL AR
- SEE DETAIL AS
- SEE DETAIL AT
- SEE DETAIL AU
- SEE DETAIL AV
- SEE DETAIL AW
- SEE DETAIL AX
- SEE DETAIL AY
- SEE DETAIL AZ
- SEE DETAIL BA
- SEE DETAIL BB
- SEE DETAIL BC
- SEE DETAIL BD
- SEE DETAIL BE
- SEE DETAIL BF
- SEE DETAIL BG
- SEE DETAIL BH
- SEE DETAIL BI
- SEE DETAIL BJ
- SEE DETAIL BK
- SEE DETAIL BL
- SEE DETAIL BM
- SEE DETAIL BN
- SEE DETAIL BO
- SEE DETAIL BP
- SEE DETAIL BQ
- SEE DETAIL BR
- SEE DETAIL BS
- SEE DETAIL BT
- SEE DETAIL BU
- SEE DETAIL BV
- SEE DETAIL BW
- SEE DETAIL BX
- SEE DETAIL BY
- SEE DETAIL BZ
- SEE DETAIL CA
- SEE DETAIL CB
- SEE DETAIL CC
- SEE DETAIL CD
- SEE DETAIL CE
- SEE DETAIL CF
- SEE DETAIL CG
- SEE DETAIL CH
- SEE DETAIL CI
- SEE DETAIL CJ
- SEE DETAIL CK
- SEE DETAIL CL
- SEE DETAIL CM
- SEE DETAIL CN
- SEE DETAIL CO
- SEE DETAIL CP
- SEE DETAIL CQ
- SEE DETAIL CR
- SEE DETAIL CS
- SEE DETAIL CT
- SEE DETAIL CU
- SEE DETAIL CV
- SEE DETAIL CW
- SEE DETAIL CX
- SEE DETAIL CY
- SEE DETAIL CZ
- SEE DETAIL DA
- SEE DETAIL DB
- SEE DETAIL DC
- SEE DETAIL DD
- SEE DETAIL DE
- SEE DETAIL DF
- SEE DETAIL DG
- SEE DETAIL DH
- SEE DETAIL DI
- SEE DETAIL DJ
- SEE DETAIL DK
- SEE DETAIL DL
- SEE DETAIL DM
- SEE DETAIL DN
- SEE DETAIL DO
- SEE DETAIL DP
- SEE DETAIL DQ
- SEE DETAIL DR
- SEE DETAIL DS
- SEE DETAIL DT
- SEE DETAIL DU
- SEE DETAIL DV
- SEE DETAIL DW
- SEE DETAIL DX
- SEE DETAIL DY
- SEE DETAIL DZ
- SEE DETAIL EA
- SEE DETAIL EB
- SEE DETAIL EC
- SEE DETAIL ED
- SEE DETAIL EE
- SEE DETAIL EF
- SEE DETAIL EG
- SEE DETAIL EH
- SEE DETAIL EI
- SEE DETAIL EJ
- SEE DETAIL EK
- SEE DETAIL EL
- SEE DETAIL EM
- SEE DETAIL EN
- SEE DETAIL EO
- SEE DETAIL EP
- SEE DETAIL EQ
- SEE DETAIL ER
- SEE DETAIL ES
- SEE DETAIL ET
- SEE DETAIL EU
- SEE DETAIL EV
- SEE DETAIL EW
- SEE DETAIL EX
- SEE DETAIL EY
- SEE DETAIL EZ
- SEE DETAIL FA
- SEE DETAIL FB
- SEE DETAIL FC
- SEE DETAIL FD
- SEE DETAIL FE
- SEE DETAIL FF
- SEE DETAIL FG
- SEE DETAIL FH
- SEE DETAIL FI
- SEE DETAIL FJ
- SEE DETAIL FK
- SEE DETAIL FL
- SEE DETAIL FM
- SEE DETAIL FN
- SEE DETAIL FO
- SEE DETAIL FP
- SEE DETAIL FQ
- SEE DETAIL FR
- SEE DETAIL FS
- SEE DETAIL FT
- SEE DETAIL FU
- SEE DETAIL FV
- SEE DETAIL FW
- SEE DETAIL FX
- SEE DETAIL FY
- SEE DETAIL FZ
- SEE DETAIL GA
- SEE DETAIL GB
- SEE DETAIL GC
- SEE DETAIL GD
- SEE DETAIL GE
- SEE DETAIL GF
- SEE DETAIL GG
- SEE DETAIL GH
- SEE DETAIL GI
- SEE DETAIL GJ
- SEE DETAIL GK
- SEE DETAIL GL
- SEE DETAIL GM
- SEE DETAIL GN
- SEE DETAIL GO
- SEE DETAIL GP
- SEE DETAIL GQ
- SEE DETAIL GR
- SEE DETAIL GS
- SEE DETAIL GT
- SEE DETAIL GU
- SEE DETAIL GV
- SEE DETAIL GW
- SEE DETAIL GX
- SEE DETAIL GY
- SEE DETAIL GZ
- SEE DETAIL HA
- SEE DETAIL HB
- SEE DETAIL HC
- SEE DETAIL HD
- SEE DETAIL HE
- SEE DETAIL HF
- SEE DETAIL HG
- SEE DETAIL HH
- SEE DETAIL HI
- SEE DETAIL HJ
- SEE DETAIL HK
- SEE DETAIL HL
- SEE DETAIL HM
- SEE DETAIL HN
- SEE DETAIL HO
- SEE DETAIL HP
- SEE DETAIL HQ
- SEE DETAIL HR
- SEE DETAIL HS
- SEE DETAIL HT
- SEE DETAIL HU
- SEE DETAIL HV
- SEE DETAIL HW
- SEE DETAIL HX
- SEE DETAIL HY
- SEE DETAIL HZ
- SEE DETAIL IA
- SEE DETAIL IB
- SEE DETAIL IC
- SEE DETAIL ID
- SEE DETAIL IE
- SEE DETAIL IF
- SEE DETAIL IG
- SEE DETAIL IH
- SEE DETAIL II
- SEE DETAIL IJ
- SEE DETAIL IK
- SEE DETAIL IL
- SEE DETAIL IM
- SEE DETAIL IN
- SEE DETAIL IO
- SEE DETAIL IP
- SEE DETAIL IQ
- SEE DETAIL IR
- SEE DETAIL IS
- SEE DETAIL IT
- SEE DETAIL IU
- SEE DETAIL IV
- SEE DETAIL IW
- SEE DETAIL IX
- SEE DETAIL IY
- SEE DETAIL IZ
- SEE DETAIL JA
- SEE DETAIL JB
- SEE DETAIL JC
- SEE DETAIL JD
- SEE DETAIL JE
- SEE DETAIL JF
- SEE DETAIL JG
- SEE DETAIL JH
- SEE DETAIL JI
- SEE DETAIL JJ
- SEE DETAIL JK
- SEE DETAIL JL
- SEE DETAIL JM
- SEE DETAIL JN
- SEE DETAIL JO
- SEE DETAIL JP
- SEE DETAIL JQ
- SEE DETAIL JR
- SEE DETAIL JS
- SEE DETAIL JT
- SEE DETAIL JU
- SEE DETAIL JV
- SEE DETAIL JW
- SEE DETAIL JX
- SEE DETAIL JY
- SEE DETAIL JZ
- SEE DETAIL KA
- SEE DETAIL KB
- SEE DETAIL KC
- SEE DETAIL KD
- SEE DETAIL KE
- SEE DETAIL KF
- SEE DETAIL KG
- SEE DETAIL KH
- SEE DETAIL KI
- SEE DETAIL KJ
- SEE DETAIL KK
- SEE DETAIL KL
- SEE DETAIL KM
- SEE DETAIL KN
- SEE DETAIL KO
- SEE DETAIL KP
- SEE DETAIL KQ
- SEE DETAIL KR
- SEE DETAIL KS
- SEE DETAIL KT
- SEE DETAIL KU
- SEE DETAIL KV
- SEE DETAIL KW
- SEE DETAIL KX
- SEE DETAIL KY
- SEE DETAIL KZ
- SEE DETAIL LA
- SEE DETAIL LB
- SEE DETAIL LC
- SEE DETAIL LD
- SEE DETAIL LE
- SEE DETAIL LF
- SEE DETAIL LG
- SEE DETAIL LH
- SEE DETAIL LI
- SEE DETAIL LJ
- SEE DETAIL LK
- SEE DETAIL LL
- SEE DETAIL LM
- SEE DETAIL LN
- SEE DETAIL LO
- SEE DETAIL LP
- SEE DETAIL LQ
- SEE DETAIL LR
- SEE DETAIL LS
- SEE DETAIL LT
- SEE DETAIL LU
- SEE DETAIL LV
- SEE DETAIL LW
- SEE DETAIL LX
- SEE DETAIL LY
- SEE DETAIL LZ
- SEE DETAIL MA
- SEE DETAIL MB
- SEE DETAIL MC
- SEE DETAIL MD
- SEE DETAIL ME
- SEE DETAIL MF
- SEE DETAIL MG
- SEE DETAIL MH
- SEE DETAIL MI
- SEE DETAIL MJ
- SEE DETAIL MK
- SEE DETAIL ML
- SEE DETAIL MM
- SEE DETAIL MN
- SEE DETAIL MO
- SEE DETAIL MP
- SEE DETAIL MQ
- SEE DETAIL MR
- SEE DETAIL MS
- SEE DETAIL MT
- SEE DETAIL MU
- SEE DETAIL MV
- SEE DETAIL MW
- SEE DETAIL MX
- SEE DETAIL MY
- SEE



EXPLODED VIEW: 150A SERVICE ENTRANCE GENERAC CB
DRAWING #: 0J2006A

GROUP C

APPLICABLE TO:


ITEM	PART #	QTY.	DESCRIPTION
1	0D9618	1	TRANSFER SW. HSB 200A 2P 250V
2	074908	5	SCREW HHTT M5-0.8 X 10 BP
3	0G4478	1	CIRCUIT BREAKER, 200A 2-POLE
4	053640	2	SCREW RHM #8-32 X 3-1/4
5	0F8843	2	BUSBAR, 200A LUG ADAPTER
6	0F8451	2	LUG 300 MCM-6STR
7	0G4413	2	SPACER 200 AMP TRANSFER
8	024334	2	BOLT CARR 1/4-20 X 1"
9	0G6352	2	BUSBAR, 200A TRANSFER SW N1,N2
10	0G6417	1	BUSBAR, NEUTRAL BLOCK
11	0E3375	4	LUG SOLDERLESS 250-#6 AL/CU
12	0F1252	4	SCREW BHSC 1/4-20 X 3/8
(1)13	0E6034	1	STRAIGHT SPADE CONNECTOR
14	0G6320	1	GROUND BAR(5) 2-14 AWG CONN
15	085889	4	NUT HEX 1/4-20 SS
16	0A1661	2	RIVET, P.O.P. .156 X .67
17	0E3717A	1	ASSY-NEUT BLK 200-400A W/TAP
18	090388	2	SCREW HHTT M6-1.0 X 12 MM
19	0H10860AL14	1	ENCLOSURE, 200A SE XFER SW
20	0G96490AL14	1	COVER, INSIDE 200A DUAL BREAKER
21	0H10870AL14	1	COVER, TRANSFER SWITCH
22	0H1485	1	CB RISER BRACKET 200A GENERAC
23	0G9650	1	SUBPLATE, 200A SE XFER SW
24	0G3369A	REF	DECAL, TRANSFER SWITCH DATA
	0J2699B	REF	DECAL, TRANSFER SWITCH DATA
	0J3804B	REF	DECAL, TRANSFER SWITCH DATA
25	0E3484	1	DECAL, MANUAL OPERATING HANDLE
26	0G9651A	1	DECAL, UTILITY SOURCE CONN
27	0G9651B	1	DECAL, GENERATOR/CUSTOMER CONN
28	0G9651C	1	DECAL, UTILITY DISCONNECT
29	0G8535	1	DECAL, TRANSFER SWITCH INFO
30	0G4220	1	DECAL, NEUTRAL CONNECTION

ITEM	PART #	QTY.	DESCRIPTION
31	0D3587	1	DECAL, FUSE REPLACEMENT
32	0H7917	1	DECAL, TERMINAL STRIP
33	0H1480	1	DECAL, TEST SEQUENCE
34	0G3274	1	DECAL, LIVE CIRCUIT ENG/FRN/SPN
35	0G3259	1	DECAL, TERMINAL SHOCK HZD BI
36	0G0900	1	DECAL, UL LIST HSB
37	PER ORDER	1	DECAL, FRNT CVR ATS 3R SER DIS
38	0H6389	1	DECAL, UTILITY LOAD SENSE 240V
39	0H7274	1	DECAL, 2008 NEC COMPLIANCE
40	0A1495	10	SCREW HHTT M4-0.7 X 10 BP
41	064761	4	TIE WRAP UL 5.6 X .10 (NOT SHOWN)
42	026850	2	WASHER SHAKEPROOF EXT 1/4 STL
43	0E7213	1	THUMB SCREW 1/4-20x1/2
44	0G8411	6	NUT HEX FL WHIZ 1/4-20
45	022097	7	WASHER LOCK M6-1/4
46	0H7259	1	WIRING HARNESS HSB (NOT SHOWN)
47	0E6193	1	BRACKET, ARM EXTENDER
48	0D6162	2	RIVET POP .156 X .362 AL
(1)49	0E6155	1	ARM EXTENDER PIN
50	0E6303	2	WIRE-A
(1)51	0E6033	4	90 DEGREE DN SPADE CONNECTOR
52	0E6303B	1	WIRE-E1
(2)53	063617	1	RELAY PNL 12VDC DPDT
(2)54	0D2572	1	FUSEBLOCK 30A 600V 3 POLE
55	073590A	3	FUSE 5A X BUSS HLDRT73591
(2)56	0H1605	1	BLOCK TERM 20A 5 X 6 X 1100V
57	049897	4	SCREW SHC M8-1.25 X 20 G8
58	022145	2	WASHER FLAT 5/16-M8 ZINC
59	022129	6	WASHER LOCK M8-5/16
60	045771	2	NUT HEX M8-1.25 G8 CLEAR ZINC
61	043107	2	SCREW HHC M8-1.25 X 25 C8.8
62	022473	4	WASHER FLAT 1/4-M6 ZINC
63	0H7376A	1	ASSY PCB AC LOAD CONTROLLER
64	0H7190	1	BRACKET LOAD SHED 200A RTS
65	0H7270	1	CHANNEL SNAPTRACK 76.2 X 101.2
66	026902	1	SCREW HHTT #8-32 X 1/4 CZ
67	058000E	1	NUT TRIC 1/4-20 X .525

(1) SUPPLIED WITH TRANSFER SWITCH ITEM #1
(2) SUPPLIED WITH HARNESS ITEM #46

GROUP C

DECAL DETAILS
VIEWS SHOWN WITH ITEMS #19 & #20 FULLY ASSEMBLED



EXPLODED VIEW:
150A SERVICE ENTRANCE GENERAC CB
DRAWING #: 0J2006A

EXPLODED VIEW: 150A SERVICE ENTRANCE GENERAC CB
DRAWING #: 0J2006A
APPLICABLE TO:

GROUP C

THIS PAGE IS LEFT INTENTIONALLY BLANK