





Parts Manual

iX2000 Inverter (Model 0057933)




NOTICE!

The information in this manual is known to be accurate as of the date of release shown on the cover. However, engineering changes can occur without notice. To obtain the proper parts, please be sure to use the serial number of the unit being serviced when ordering from this manual. Always refer to any parts notes and changes before ordering. All other parts not shown in this manual can be found on Generac's exploded view drawings online on GENservice at www.generac.com.




2000 Watt Model 0057933



ITEM	PART NO.	DESCRIPTION	QTY.
1	0K2094	ENGINE ASSY	1
2	0J95780135	CAP, FUEL	1
3	0J95710110	GUARD, RUBBER SPILL	1
4	0J95780133	FILTER, FUEL (TANK)	1
5	0J95710111	TANK, FUEL	1
6	0H43470114	MOUNT, RUBBER	4
7	0H43470115	COVER, LOWER SHELL	1
8	0H43470116	SHELL, LOWER	1
9	0H43470117	CLIP, SCREW (LOCK, SLICE)	8
10	0H43470118	FEET, VIBRATION MOUNTS	4
11	0H56810160	SCREW, PHILLIPS ST6.3X16	4
12	0H43470120	PIN, MOUNTING, BOTTOM	2
13	0H43470168	BOLT, HH, FL, M6X14	5
14	0H43470122	WRAPPER, SIDE	1
15	0H43470123	GASKET/WASHER	4
16	0H43470124	SLEEVE, DAMPING	4
17	0J95710114	KEY, WOODRUFF, 3X6.5X13	1
18	0H43470126	STATOR ASSY.	1
19	0H43470127	BOLT, HH, W/FL M6X45	4
20	0H43470128	ASSY., ROTOR/FLYWHEEL	1
21	0H43470129	NUT, HH, W/FG, M12X1.25-8	1
22	0H43470130	BLADE, FAN	1
23	0H43470131	SEAT, STARTING JAW	1
24	0J95780115	BOLT, HH, FLANGE	2
25	0H43470133	PULLEY, STARTER	1
26	0H43470134	COVER	1
27	0J95780127	SLEEVE, RUBBER, HIGH VOLT.	1
28	0H43470136	COIL, IGNITION	1
29	0H43470137	SCREW, PHILLIPS ST4.8X22	2
30	0H43470138	PIN, MOUNTING, TOP	1
31	0H43470139	BRACE, ENGINE	1
32	0H43470140	CLEANER, AIR	1
33	0H43470141	COVER, AIR CLEANER	1
34	0H43470142	BOLT, HH, W/FL M5X16	6

ITEM	PART NO.	DESCRIPTION	QTY.
35	0H43470143	GASKET, CARBURETOR (OUT B)	1
36	0H43470144	SPACER, CARBURETOR	1
37	0J95710115	GASKET, CARBURETOR, (OUT A)	1
38	0H43470146	CARBURETOR ASSY.	1
39	0H43470147	GASKET, CARBURETOR (IN)	1
40	0H43470148	NUT, HH, W/FG, M6	6
41	0H43470149	SPACER, OIL SPLASH CVR	2
42	0H43470150	CASE, OIL SUB ASSY.	1
43	0H43470151	CIRCLIP, ADAPTER	2
44	0H43470152	SLEEVE, FILTER ADAPTER	1
45	0J95780132	CAP, THREADED	1
46	0J95710117	HOSE, FUEL (185MM)	1
47	0J95710116	BRACKET, FUEL TANK	1
48	0H43470156	RECOIL ASSY.	1
49	0H43470157	SUB ASSY., INVERTER	1
50	0H43470158	BRACE, CONTROL PANEL	1
51	0H43470159	FRONT, CONTROL PANEL	1
52	0H63620149	SCREW, PHILLIPS PAN HEAD	4
53	0H43470161	WASHER	4
54	0H43470162	SCREW, PHILLIPS PH (M6X130)	2
55	0J95780111	HOSE, FUEL (45MM)	1
56	0H63620151	SCREW, M6X14	1
57	0H43470165	UPPER SHELL COVER	1
58	0H43470214	SCREW, PHILLIPS PH M4X12	1
59	0H43470167	KNOB, FUEL SWITCH (ON/OFF)	1
60	0H43470168	SCREW, X-PH, M6X14	5
61	0J95710119	SHELL A, UPPER	1
62	0H43470170	SWITCH, IGNITION (ON/OFF)	1
63	0H43470171	COVER, SWITCH	1
64	0J95780119	SCREW, PHILLIPS, ST4.2X9.5	2
65	0H43470173	SWITCH, OIL	1
66	0H43470174	HOSE, OUTLET	1
67	0H43470175	SHIELD, PIPE SPRING	2
68	0J95710120	HOSE, FUEL (205MM)	1



2000 Watt Model 0057933

ITEM	PART NO.	DESCRIPTION	QTY.
69	0H43470177	O-RING GASKET, DIP STICK	1
70	0J95780142	CAP, OIL FILL	1
71	0J95710121	STUD	2
72	0H43470180	FILTER, FUEL	1
73	0J95710122	HOSE, OUTLET (90MM)	1
74	0H43470182	HOSE, FUEL PUMP (AIR)	1
75	0J95710123	HOSE, FUEL (115MM)	1
76	0H43470184	PUMP ASSY., FUEL	1
77	0H43470185	SCREW, PHILLIPS ST4.8X19	1
78	0H43470186	WRAPPER, UPPER ENGINE	1
79	0H56810153	SCREW, PHILLIPS, ST4.2X13	6
80	0H43470188	REDUCER	1
81	0H43470189	GASKET, MUFFLER	1
82	0J95710124	MUFFLER ASSY A	1
83	0H43470191	BOLT, HH, W/FLNG M6X60	2
84	0H43470192	SEAL, EXHAUST COVER	1
85	0H43470193	COVER, EXHAUST	1
86	0H63620168	SCREW, PHILLIPS-PH M5X20	4

ITEM	PART NO.	DESCRIPTION	QTY.
87	0H43470195	CLIP, RETAINING	1
88	0H43470196	O-RING, RUBBER	1
89	0H43470213	WASHER, STAR LOCK	2
90	0J95780113	CLAMP, FUEL HOSE	10
91	0H43470199	BOLT, HH, W/FLNG, M6X80	1
92	0H43470200	BOLT, HH, W/FLNG, M5X12	1
93	0H43470201	PIN, GUIDE, A	2
94	0H43470202	PIN, GUIDE, B	2
95	0H43470203	GASKET, HOOK	2
96	0H56810160	SCREW, PHILLIPS, ST6.3X16	1
98	0J95780137	BULB, FUEL PRIMER	1
NOT SHOWN	0J95710125	RING, PRIMER BULB SEALING	1
NOT SHOWN	0J95710126	SEAT, PRIMER BULB FIXED	1
NOT SHOWN	0J95710127	SEAT, PRIMER BULB CONNECTED	1
NOT SHOWN	0J95710128	CASING, PRIMER BULB SEAL	1
NOT SHOWN	0K82060SRV	KIT, PRIMER BULB ASSEMBLY	1