


Parts Manual

iX1600 Inverter (Model 0057923)




NOTICE!

The information in this manual is known to be accurate as of the date of release shown on the cover. However, engineering changes can occur without notice. To obtain the proper parts, please be sure to use the serial number of the unit being serviced when ordering from this manual. Always to refer to any parts notes and changes before ordering. All other parts not shown in this manual can be found on Generac's exploded view drawings online on GENservice at www.generac.com.




1600 Watt Model 0057923



ITEM	PART NO.	DESCRIPTION	QTY.
1	0K2093	Engine	1
2	0J95780135	Fuel Cap	1
3	0H63620111	Rubber Ring, Fuel Chging Inlet	1
4	0J95780133	Filter, Fuel (In Tank)	1
5	0J95780136	Fuel Tank	1
6	0H43470114	Absorb Shock Block	4
7	0H63620118	Lower Casing of the Engine	1
8	0J95780124	Lower Shell	1
9	0J95780126	Lower Shell Cover	1
10	0H43470117	Clip, Screw (Lock Slice)	8
11	0H43470121	Bolt, Hex Head W/Flange M6x12	2
12	0H63620117	Alignment Pin	2
13	0H43470118	Feet, Vibration Mounts	4
14	0H43470119	Cross Recessed Pan Head Tapping Screw	5
15	0H43470195	Clip, Retaining	1
16	0H43470123	Gasket-Washer	4
17	0H43470124	Damping Sleeve	4
18	0H63620120	Oil Sensor Seal Cover	1
19	0H43470125	Woodruff Key	1
20	0J95780138	Stator Assembly	1
21	0H63620122	Hex. Flange Face Bolt	2
22	0H63620123	Flywheel Rotor Assembly	1
23	0J95780114	Hex. Flange Face Nut	1
24	0H63620125	Fan	1
25	0H63620126	Starting Jaw Seat	1
26	0J95780115	Hex. Flange Face Bolt	5
27	0H63620128	Starting Jaw Coupler	1
28	0H63620129	Hex. Flange Face Bolt	1
29	0H63620130	Cover Assy. Cowling & Inlet	1
30	0H43470196	O-Ring, Rubber	1
31	0J95780127	High-Voltage Rubber Sleeve	1
32	0H63620132	Pothook Damping Pillar	1
33	0H63620133	Pothook	1
34	0H43470136	Ignition Coil	1

ITEM	PART NO.	DESCRIPTION	QTY.
35	0H63620179	Cross Recessed Pan Head Tapping Screw	2
36	0H63620145	Starter Assembly	1
37	0H43470200	Cross Recessed Hexagon Head Bolt and Plain Washer Assy	1
38	0H63620136	Cross Recessed Pan Head Tapping Screw	6
39	0H63620134	Element, Air Cleaner	1
40	0H63620135	Air Filter Cover	1
41	0H43470151	Adapter Circlip	2
42	0H43470152	Filter Adapter Sleeve	1
43	0H63620144	Filter Case Assembly	1
44	0H63620142	Hex. Flange Face Nut	4
45	0H43470161	Flat Washer	2
46	0H63620143	Pin, Alignment Fil/Case Liner	2
47	0H63620137	Carburetor Seal Gasket B (Out)	1
48	0H63620138	Carburetor Cushion Block	1
49	0H63620139	Gasket, Carb. A Out	1
50	0J95780129	Carburetor Regulating Assembly	1
51	0J95780144	Carburetor seal gasket (in)	1
52	0J95780139	Inverter Assembly	1
53	0H63620147	Front Panel Frame	1
54	0J95780140	Control Panel	1
55	0J95780123	Upper Shell A	1
56	0H43470168	Cross Recessed Pan Head Screw	5
57	0J95780117	Cross Recessed Pan Head Screw	2
58	0J95780143	Filter, Fuel , (In-line)	1
59	0H63620151	Screw	1
60	0J95780125	Cover, Left Side Shell (Upper)	1
61	0H43470214	Cross Recessed Pan Head Screw	3
62	0H43470167	Fuel Switch Turn-Knob	1
63	0J95780128	Fuel Tanker Bracket	1
64	0H43470170	Switch, Ignition, On/Off	1
65	0H43470171	Cover, Switch	1
66	0J95780119	Cross Recessed Pan Head Tapping Screw	2
67	0H43470173	Fuel Switch	1



1600 Watt Model 0057923

ITEM	PART NO.	DESCRIPTION	QTY.
68	0J95780131	Outlet Pipe-A	1
69	0H43470175	Shield Pipe Spring	1
70	0J95780120	Fuel Pipe B	1
71	0H43470177	Oil Cover Washer	1
72	0J95780142	Oil Cover	1
73	0H43470179	Stud Bolt	2
74	0H43470180	Gasoline Filter (In-line)	1
75	0J95780121	Hose, Fuel D (70MM)	1
76	0H63620158	Fuel Pump Hose	1
77	0J95780122	Hose, Fuel, C	2
78	0J95780113	Fuel Hose Clamp	19
79	0H43470184	Fuel Pump Assembly	1
80	0H43470185	Cross Recessed Pan Head Tapping Screw	3
81	0H63620160	Upper Casing of the Engine	1
82	0J95780118	Cross Recessed Pan Head Tapping Screw	4
83	0H63620162	Respirator Adapter Sleeve	1
84	0H63620163	Shim for Muffler	1
85	0J95780130	Muffler Assembly	1
86	0H63620165	Hex. Flange Face Bolt	3
87	0H63620166	Seal Rubber, Back Window	1
88	0H63620167	Window, Back (Exh Cvr)	1
89	0H63620168	Cross Recessed Pan Head Screw	4
90	0H56810151	Cross Recessed Pan Head Screw	6
91	0H43470208	Standard Type Spring Washer	8
92	0H43470207	Flat Washer	8

ITEM	PART NO.	DESCRIPTION	QTY.
93	0H63620178	Decal, Control Plate	1
94	0H43470210	Ignition Apparatus (With Indicator)	1
95	0H43470211	Diode, Rectifier	1
96	0J95780141	Control Plate Assembly	1
97	0H43470161	Flat Washer	7
98	0H56810172	Hexagonal Nut	2
99	0H56810173	Standard Type Spring Washer	1
100	0H43470215	Switch, Flexpower	1
101	0H43470217	Holder, DC Components	1
102	0H43470218	Receptacle, 12 VDC	1
103	0H43470216	Breaker, DC Circuit	1
104	0J95780116	Cross Recessed Pan Head Screw	4
105	0J95780145	Outlet	1
106	0H43470206	Nut, M4	2
107	0J95780132	Pipe Cap	1
108	0J95780121	Hose, Fuel D (70MM)	1
109	0H63620149	Screw Pan Head Recessed M5X25	1
110	0J95780134	Connector, Tee-Pipe	2
111	0K82060SRV	Kit Primer Bulb Assy. Include All Parts Shown Below	1
N/S	0J95710125	Ring, Primer Bulb Sealing	1
N/S	0J95710126	Seat, Primer Bulb Fixed	1
N/S	0J95710127	Seat, Primer Bulb Connected	1
N/S	0J95710128	Casing, Primer Bulb Seal	1
N/S	0J95710137	Bulb Fuel Primer	1