

GROUP G

NOTE: INSTALLATION TO BE DONE BY A LICENSED ELECTRICIAN AND MUST MEET ALL NATIONAL, STATE AND LOCAL ELECTRICAL CODES.

RTS TRANSFER SWITCH  
800A-3 PHASE SHOWN

LEFT INSIDE VIEW

FRONT VIEW

QT SERIES ENGINE GENERATOR  
CONNECTION PANEL

NOTE:  
MATCH WIRE  
NUMBERS TO  
TERMINAL NUMBERS

SINGLE PHASE

NEUTRAL BLOCK

GROUND

CUSTOMER  
CONTROL  
WIRING SUPPORT

N1  
N2  
23/194

N1  
N2  
(N3)  
T1  
T2  
(T3)  
E1  
E2  
(E3)

T1

T2

(T3)

E1

E2

(E3)

NOTE:  
N3, E3 AND T3 WIRES ARE ONLY  
USED ON 3 PHASE SYSTEMS.

LIQUID COOLED INSTALLATION

CUSTOMER LOAD  
(DISTRIBUTION PANEL)

UTILITY SUPPLY FROM  
SERVICE DISCONNECT

EXPLODED VIEW: RTS 600-800A

DRAWING #: 0J0911

APPLICABLE TO:

GROUP G

**THIS PAGE IS LEFT INTENTIONALLY BLANK**