

GROUP G

NOTE: INSTALLATION TO BE DONE BY A LICENSED ELECTRICIAN AND MUST MEET ALL NATIONAL, STATE AND LOCAL ELECTRICAL CODES.

RTS TRANSFER SWITCH
800A-3 PHASE SHOWN

LEFT INSIDE VIEW

FRONT VIEW

QT SERIES ENGINE GENERATOR
CONNECTION PANEL

NOTE:
MATCH WIRE
NUMBERS TO
TERMINAL NUMBERS

SINGLE PHASE

NEUTRAL BLOCK

GROUND

CUSTOMER
CONTROL
WIRING SUPPORT

NEUTRAL
BLOCK

GROUND

N1
N2
23/194

T1
E1
T2
E2
T3
E3

CUSTOMER LOAD
(DISTRIBUTION PANEL)

UTILITY SUPPLY FROM
SERVICE DISCONNECT

LIQUID COOLED INSTALLATION

NOTE:
N3, E3 AND T3 WIRES ARE ONLY
USED ON 3 PHASE SYSTEMS.

EXPLODED VIEW: RTS 600-800A

DRAWING #: 0J0911

APPLICABLE TO:

GROUP G

THIS PAGE IS LEFT INTENTIONALLY BLANK