





LEGEND

ATS - TRANSFER SWITCH CONTACTOR
 C - CONTACTOR ACTUATING COIL
 PM - POWER MONITOR, 3 PHASE UTILITY
 SC - COIL, SELECTIVE
 TC - COIL, TRIP
 TR - RELAY, TRANSFER
 TS - TERMINAL STRIP (CUSTOMER CONNECTION)
 LS1,LS2,LS3 - LIMIT SWITCHES, ACTUATOR
 F1,F2 - FUSE 5A SENSING & SWITCH OPERATION
 F3,F4,F5,F6 - FUSE 5A XFMR
 TR1,TR2 - TRANSFORMER STEP DOWN



NOTES:

- 1.) ALL CONTACTS SHOWN WITH TRANSFER SWITCH IN UTILITY POSITION.

SCHEMATIC - DIAGRAM

600-800A AMP 480VAC

DRAWING #: 0J0914

