





LEGEND

ATS - TRANSFER SWITCH CONTACTOR
 C - CONTACTOR ACTUATING COIL
 PM - POWER MONITOR, 3 PHASE UTILITY
 SC - COIL, SELECTIVE
 TC - COIL, TRIP
 TR - RELAY, TRANSFER
 TS - TERMINAL STRIP (CUSTOMER CONNECTION)
 F1,F2 - FUSE 5A SENSING & SWITCH OPERATION
 F3,F4 - FUSE 5A SENSING



NOTES:

- 1.) ALL CONTACTS SHOWN WITH TRANSFER SWITCH IN UTILITY POSITION.

SCHEMATIC - DIAGRAM

600-800 AMP 3Ø

DRAWING #: 0J0913

