

190.5
[7.5]

190.5
[7.5]

1

Manual

If equipped.

2

2

1

3

3

2

If equipped, attach red battery wire.

4

4

5

Add oil until it reaches the full mark on the dipstick.
Replace oil dipstick after filling.

6

Do not fill past this lip!
Replace gas cap.
E85 E20
Never add fuel while unit is running or hot!

7

Follow quick start instructions.

Need Help? Call 1-888-GENERAC

GENERAC

GP SERIES
CENTURION SERIES

F

F

0J9065
FRONT
ENGLISH

F

PART NUMBER & REVISION
(SEE NOTE 5)

190.5
[7.5]

190.5
[7.5]

1

Manual

If equipped.

2

2

1

3

3

2

If equipped, attach red battery wire.
Si está equipado, conecte el cable rojo de la batería.

4

4

5

Verser TOUTE la bouteille d'huile moteur.
Agrega una botella ENTERA de aceite de motor.
Ne pas remplir plus haut que le flet inférieur! Remettre le bouchon du réservoir d'huile après le remplissage.
No lo llenes por encima de la rosca!
Vuelva a colocar la tapa de aceite después del llenar.

6

¡No lo llenes por encima de este borde!
Vuelva a colocar la tapa de la gasolina.
E85 E20
¡Nunca pongas gasolina mientras la unidad está encendida o caliente!

7

Suivez les instructions de démarrage.
Siga las instrucciones de arranque.

Need Help? Call 1-888-GENERAC

GENERAC

GP SERIES
CENTURION SERIES

F

F

0J9065
BACK
SPANISH CASTILIAN
FRENCH CANADIAN

F

SEE NOTE 4

SLATE BORDER PMS 5415
PANTONE BLACK TEXT
TYP

GRAPHIC PANTONE BLACK
BACKGROUND PANTONE WHITE
TYP

BORDER & TEXT
GRAY PMS 422
TYP

GRAPHIC
PANTONE BLUE PMS 280

NOTES:
1. FONT STYLE, TEXT SIZE, AND COLORS PER SUPPLIED ARTWORK (SEE TABLE).
2. MATERIAL: 80 GSM, 102-104% BRIGHTNESS UNCOATED WHITE PAPER (MINIMUM)
3. DIMENSIONS [] ARE IN INCHES.
4. GENERAC LOGO MUST MEET SPECIFICATIONS ON DRAWING OH1888.
5. LOCATION OF PART NUMBER: AS SHOWN ABOVE. PART NUMBER AND REVISION TO BE ADDED BY DECAL SUPPLIER. LETTERING TO BE HELVETICA, FONT SIZE 10 POINT, BLACK.

F

DRAWING CREATED FROM PRO/ENGINEER 3D FILE. ECO MODIFICATION TO BE APPLIED TO SOLID MODEL ONLY.

02/29/12	-A	RELEASED.			
04/13/12	J-1762-C	ADDED 0J9065A, TABLE, AND SHEET 2 REV B WAS SKIPPED			
5/10/12	J-1912-D	UPDATED ARTWORK ON PAGE 2			
06/04/12	J-1995-E	UPDATED ARTWORK ON BOTH PAGES			
6/27/12	J-2139-F	SHIT UP GP SERIES REMOVE TEXT "5000W/5500W/6500W/7500W" CENTURION SERIES REMOVE TEXT "5000W" STEP 3. ADD GRAPHIC 3. ADD PN AND NOTE 5. UPDATE HANDLE HARDWARE GRAPHIC 0J9065 TITLE REMOVE "5-75"			

GENERAL TOLERANCES UNLESS NOTED

ALL XX : ± 1 MM
XXX : ± 1 MM
XXX : ± 1 MM
ALL ANG : ± 1°
INTERPRET DIM AND TOL PER ASME Y14.5M-1994

THIRD ANGLE PROJECTION

DATUM INDICATING SYMBOL

PERPENDICULARITY

POSITION

ANGULARITY

PROFILE OF A SURFACE

CIRCULAR RUNOUT

FLATNESS

PARALLELISM

GENERAC POWER SYSTEMS OWNS THE COPYRIGHT OF THIS DRAWING WHICH IS SUPPLIED IN CONFIDENCE AND MUST NOT BE USED FOR ANY PURPOSE OTHER THAN FOR WHICH IT IS SUPPLIED WITHOUT THE EXPRESS WRITTEN CONSENT OF GENERAC POWER SYSTEMS. © GENERAC POWER SYSTEMS 2010

APPROVALS

DATE

DRAWN BY

GCC

02/29/2012

CHECKED BY

KP

02/29/2012

MFG ENG

APPROVED BY

CDT

03/01/2012

FIRST USE:

0061103

ELECTRONICALLY APPROVED INSIDE WINDCHILL

LIFECYCLE STATE: In Work

QUICK START GUIDE GP

SIZE C

CAGE NO N/A

DWG NO 0J9065\$

SCALE 1.000

WT-KG 0.00

SHEET 1 of 2

GENERAC

QUICK START GUIDE GP

GENERAC SPECIFICATION SURFACE FINISH AS ABOVE N/A

REV F

P/N	DESCRIPTION	ARTWORK	SHEET
0J9065	QUICK START GUIDE GP E/S/F	0J9065.EPS	1
0J9065A	QUICK START GUIDE GP 50HZ E/R	0J9065A.EPS	2

4

3

↑


2

1

A

READ MANUAL BEFORE OPERATING GENERATOR.
QUICK SET-UP GUIDE


GP SERIES



0J9065A
FRONT
ENGLISH
SAME AS EXCEPT ARTWORK

ПЕРЕД ВКЛЮЧЕНИЕМ ГЕНЕРАТОРА ОЗНАКОМЬТЕСЬ С РУКОВОДСТВОМ ПО ЭКСПЛУАТАЦИИ
ИНСТРУКЦИЯ ПО БЫСТРОЙ НАСТРОЙКЕ

СЕРИЯ GP



0J9065A
BACK
RUSSIAN
SAME AS EXCEPT ARTWORK

DRAWING CREATED FROM PRO/ENGINEER
3D FILE. ECO MODIFICATION TO BE
APPLIED TO SOLID MODEL ONLY.

GENERAL TOLERANCES UNLESS NOTED			THIRD ANGLE PROJECTION			
INTERPRET DIM AND TOL PER ASME Y14.5M-1994						
SIZE	CAGE NO	DWG NO	0J9065\$			
C	N/A		REV F			
SCALE	1.000	WT-KG	0.00	SHEET	2 of 2	

GENERAC

D

C

↓

SH 2/2 REV F

A